

JVM-407

HMI



User Manual

Jetter

Variant: Jetter

Item # 60877112

Revision 1.17.4

November 2011 / Printed in Germany

Jetter AG reserve the right to make alterations to their products in the interest of technical progress. These alterations will not necessarily be documented in every single case.

This user manual and the information contained herein have been compiled with due diligence. However, Jetter AG assume no liability for printing or other errors or damages arising from such errors.

The brand names and product names mentioned in this manual are trade marks or registered trade marks of the respective title owner.

Address

How To Contact us:

Jetter AG
Graeterstrasse 2
D-71642 Ludwigsburg
Germany

Phone - Switchboard:	+49 7141 2550-0
Phone - Sales:	+49 7141 2550-433
Phone - Technical Hotline:	+49 7141 2550-444
Fax - Sales:	+49 7141 2550-484
E-Mail - Sales:	sales@jetter.de
E-Mail - Technical Hotline:	hotline@jetter.de

Assignment to Product

This user manual is an integral part of JVM-407:

Type: _____
Serial #: _____
Year of construction: _____
Order #: _____



To be entered by the customer:

Inventory #: _____
Place of operation: _____

Significance

Significance of this user manual

The user manual is an integral part of JVM-407:

- It must be kept in a way that it is always at hand, until the JVM-407 will be disposed of.
- If the JVM-407 is sold or loaned/leased out, the user manual has to be passed on.

In any case you encounter difficulties to clearly understand this user manual, please contact the manufacturer.

We would appreciate any suggestions and contributions on your part and would ask you to contact us by our e-mail address info@jetter.de. This will help us to produce manuals that are more user-friendly and to address your wishes and requirements.

This user manual contains important information on how to transport, erect, install, operate, maintain and repair the JVM-407.

Therefore, the persons carrying out these jobs must carefully read, understand and observe this user manual, and especially the safety instructions.

Missing or inadequate knowledge of the user manual results in the loss of any claim of liability on part of Jetter AG. Therefore, the operating company is recommended to have the instruction of the persons concerned confirmed in writing.

Table of Contents

1	Safety Instructions	11
	Basic Safety Instructions.....	12
	Instructions on EMI	14
2	Product Description and Design	17
	Product Description - JVM-407	18
	Parts and Interfaces	19
	Order Reference / Options	23
	Physical Dimensions	24
3	Identifying the JVM-407	27
3.1	Identification by Means of the Nameplate	28
	Nameplate	29
3.2	Version Registers	30
	Software Versions	31
4	Installing the JVM-407	33
4.1	Interfaces	34
	Example of Wiring Layout	35
	Connecting the Power Supply.....	36
	Connecting Digital Inputs and Outputs	38
	HMI Switch Off Delay	41
	Ethernet Interface.....	43
	CAN Interface.....	45
	Specification - CANopen® Bus Cable.....	49
	Connecting a Video Camera	51
4.2	Interfaces on the Center Console with Mounted Support Arm	54
	Connection Cable - Power Supply	55
	Connection Cable - Inputs and Outputs	57
	Connection Cable - CANopen®	59
	Connection Cable - Video	61
4.3	Installing the JVM-407	62
	Installing the HMI	63
	Mounting the Support Arm	66
4.4	IP Configuration	68
	Factory Settings	69
	Configuration Memory.....	70
	Configuration File cfgvar.ini.....	71
	Configuration Registers	75
	Modifying the IP Address of the Controller.....	76
	Setting the IP Address via the File cfgvar.ini.....	77
	Setting the IP Address During Runtime	78
	Using Names for IP Address.....	79
5	Initial Commissioning	81
	Preparatory Work for Initial Commissioning.....	82

	Initial Commissioning in JetViewSoft.....	83
	Initial Commissioning in JetSym	86
6	CANopen® STX API	93
	STX Function CanOpenInit	94
	STX Function CanOpenSetCommand	96
	STX Function CanOpenUploadSDO	98
	STX Function CanOpenDownloadSDO	103
	STX Function CanOpenAddPDORx	108
	STX Function CanOpenAddPDOTx.....	114
	CANopen® Object Directory for JVM-407	120
7	SAE J1939 STX API	123
	Content of a J1939 Message	124
	STX Function SAEJ1939Init.....	126
	STX Function SAEJ1939SetSA	128
	STX Function SAEJ1939GetSA	129
	STX Function SAEJ1939AddRx.....	130
	STX Function SAEJ1939AddTx	134
	STX Function SAEJ1939RequestPGN	138
	STX Function SAEJ1939GetDM1	141
	STX Function SAEJ1939GetDM2	144
	STX Function SAEJ1939SetSPNConversion	147
	STX Function SAEJ1939GetSPNConversion	149
8	File System	151
8.1	Properties.....	152
	Flash Disk - Properties	153
	SD Card - Properties	154
	USB Stick - Properties.....	155
8.2	User Administration	156
	User Administration	158
	As-Delivered Condition / Predefined Users and Keys	160
	Assigning a Lock	161
	Assigning Names to Locks/Keys	163
8.3	Reviewing the Flash Disk Capacity Used	165
	Flash Disk Capacity Used	166
8.4	Operating System Update and Application Program	169
8.5	Formatting and Checking	170
	Formatting the Flash Disk	171
	Formatting the SD Card	172
	Formatting the USB Stick	173
	Checking the SD Card.....	174
	Checking the USB Stick	175
9	FTP Server	177
	Login.....	178
	Supported Commands	179
	Example: Windows FTP Client.....	180

10	HTTP Server	181
10.1	Server Side Includes	182
	Name Space Tag.....	183
	Inserting Realtime Controller Values.....	184
	Example of an HTML page.....	189
11	Programming	191
	Abbreviations, Module Register Properties and Formats.....	192
11.1	Memory Overview	193
	Operating System Memory.....	194
	File System Memory.....	195
	Application Program Memory.....	196
	Memory for Volatile Application Program Variables.....	197
	Memory for Non-Volatile Application Program Registers.....	198
	Memory for Non-Volatile Application Program Variables.....	199
	Special Registers.....	201
	Inputs and Outputs.....	202
	Flag.....	203
11.2	Inputs and Outputs	205
	Function Keys.....	206
	Digipot.....	207
	Digital Inputs and Outputs.....	208
	Ignition and Switching Off Delay.....	209
11.3	Realtime Clock (RTC)	211
	Technical Data.....	212
	Sample Program for Real-Time Clock.....	213
11.4	Runtime Registers	215
	Description of Runtime Registers.....	216
	Sample Program - Runtime Registers.....	218
11.5	Monitoring the Interface Activity	219
	Operating Principle.....	220
	Programming.....	222
11.6	E-Mail	224
11.6.1	Configuring the E-Mail Feature	225
	Configuration File "/EMAIL/email.ini".....	226
	Section [SMTP].....	227
	Section [POP3].....	229
	Section [DEFAULT].....	231
	Configuration File - Examples.....	232
11.6.2	Creating E-Mails	233
	Name of the E-Mail Template File.....	234
	Structure of the E-Mail Template File.....	235
	Inserting Realtime Controller Values.....	237
11.6.3	Sending an E-Mail	240
	Sending E-Mails Using the System Function.....	241
	Sample Program.....	242
11.6.4	Registers	244
	Overview of Registers.....	245
	Register Description.....	246
11.7	Modbus/TCP	249
11.7.1	Modbus/TCP Server	250
	Addressing.....	251
	Supported Commands - Class 0.....	252
	Supported Commands - Class 1.....	253

11.7.2	Supported Commands - Class 2	254
11.7.2	Modbus/TCP Client	255
	System Function 65: Acyclical Reading of Registers	257
	System Function 67: Acyclical Reading of Registers	259
	System Function 66: Acyclical Writing of Registers	261
	System Function 68: Acyclical Writing of Registers	263
	Example of an Application	265
11.8	User-programmable IP Interface	268
11.8.1	Programming	270
	Initializing the User-Programmable IP Interface	271
	Establishing a Connection	272
	Sending Data	276
	Receiving Data	278
	Terminating a Connection	281
11.8.2	Registers	282
	Register Numbers	283
	Register Description	284
11.8.3	Sample Programs	287
	Server	288
	Client	292
11.9	User-Programmable CAN-PRIM Interface	296
	User-programmable CAN-PRIM interface - Operating Principle	297
	Restrictions Regarding the CAN-PRIM Interface	298
	Programming the CAN-PRIM Interface	299
	Internal Processes of the CAN-PRIM Interface	302
	Register Description - CAN-PRIM Interface	303
	CAN-PRIM Interface - Sample Program	309
<hr/>		
12	Automatic Copying of Controller Data	312
<hr/>		
12.1	Operating Principle	314
	Activating the AutoCopy Feature	315
	Executing AutoCopy Commands	316
	Terminating AutoCopy Mode	317
12.2	The File "autocopy.ini"	318
	Section [OPTIONS]	319
	Command Sections	320
	Example of a Command File	328
12.3	Log File	330
	File Contents	331
12.4	Data Files	332
	File Format	333
<hr/>		
13	Operating System Update	335
<hr/>		
13.1	Updating the Operating System of the HMI	336
	Operating System Update from within JetSym	337
	Operating System Update by Means of FTP	338
	Automatic OS Update from SD Card and USB stick	339
	Operating System Update from within the Application Program	340
<hr/>		
14	Application Program	343
<hr/>		
	Loading an Application Program	344
	Application Program - Default Path	345
	Storing the Application Program to an SD Card	346

15	Quick Reference JVM-407	349
Appendix		353
A:	Technical Data	354
	Technical Data.....	355
	Physical Dimensions.....	357
	Operating Parameters - Environment and Mechanics.....	360
	Operating Parameters - EMC	361
B:	Index	362

1 Safety Instructions

Introduction

This chapter informs the user of general safety instructions and warns of residual dangers, if applicable. Furthermore, it contains information on EMC.

Contents

Topic	Page
Basic Safety Instructions	12
Instructions on EMI	14

Basic Safety Instructions

Introduction

This device complies with the valid safety regulations and standards. Special emphasis was given to the safety of the users.

Of course, the user should adhere to the following regulations:

- relevant accident prevention regulations;
 - accepted safety rules;
 - EC guidelines and other country-specific regulations
-

Intended Conditions of Use

Usage according to the intended conditions of use implies operation in accordance with this user manual.

The device has been designed for use in commercial vehicles and mobile machines. The device JVM-407 is an HMI with integrated controller for exchange of data with peripheral devices.

The HMI JVM-407 meets the requirement of the European Automotive EMC Directive for electric/electronic subassemblies.

The HMI JVM-407 must be operated within the limits and conditions established in the technical specifications. The operating voltage of the HMI JVM-407 is classified as SELV (Safety Extra Low Voltage). Therefore, the HMI JVM-407 is not subject to the EU Low Voltage Directive.

Usage Other Than Intended

This device must not be used in technical systems which to a high degree have to be fail-safe, e.g. ropeways and aeroplanes.

The JVM-407 is no safety-related part as per Machinery Directive 2006/42/EC. This device is not qualified for safety-relevant applications and must, therefore, NOT be used to protect persons.

If the device is to be run under ambient conditions which differ from the allowed operating conditions, Jetter AG is to be contacted beforehand.

Personnel Qualification

Depending on the life cycle of the product, the persons involved must possess different qualifications. These qualifications are required to ensure proper handling of the device in the corresponding life cycle.

Product Life Cycle	Minimum Qualification
Transport / Storage:	Trained and instructed personnel with knowledge in handling electrostatic sensitive components.
Mounting / Installation:	Specialized personnel with training in electrical/automotive engineering, such as automotive mechatronics fitters.
Commissioning / Programming:	Trained and instructed experts with profound knowledge of, and experience with, automotive / automation technology, such as automotive engineers for mobile machinery.
Operation:	Trained, instructed and assigned personnel with knowledge in operating electronic devices for mobile machinery.
Decommissioning:	Specialized personnel with training in electrical/automotive engineering, such as automotive mechatronics fitters.

Modifications and Alterations to the Device

For safety reasons, no modifications and changes to the device and its functions are permitted.

Any modifications to the device not expressly authorized by Jetter AG will result in a loss of any liability claims to Jetter AG.

The original parts are specifically designed for the device. Parts and equipment from other manufacturers are not tested on our part, and are, therefore, not released by Jetter AG.

The installation of such parts may impair the safety and the proper functioning of the device.

Any liability on the part of Jetter AG for any damages resulting from the use of non-original parts and equipment is excluded.

Transport

The JVM-407 contains electrostatic sensitive components which can be damaged if not handled properly.

To exclude damages to the JVM-407 during transport it should only be shipped in its original packaging or in packaging protecting against electrostatic discharge. This is particularly true for transport via mail.

- Use an appropriate outer packaging to protect the JVM-407 against impact or shock.
 - In case of damaged packaging inspect the device for any visible damage. Inform your freight forwarder and the manufacturer, if applicable.
-

Storing

When storing the JVM-407 observe the environmental conditions given in the technical specification.

Repair and Maintenance

This device must not be repaired by the operators themselves. The device does not contain any parts that could be repaired by the operator.

The device must be sent to Jetter AG for repair.

Disposal


When disposing of devices, the local environmental regulations must be complied with.

Instructions on EMI

Wiring Instructions - CAN Cable

To meet the requirements with regard to EMI the shielding of the CAN cable must be connected to the housing of the device. If you connect only pin 16 (shield), effective shielding is not ensured.

Connect the shielding of the CAN cable to the stud bolt of the device housing:




Caption:

Number	Element
1	Threaded stud of the device housing
2	Plain washer
3	Wire lug
4	Lock washer
5	Nut

Wiring Instructions - Video Cable

To meet the requirements with regard to EMI the shielding of the Video cable must be connected to the housing of the device. If you connect only ground connections (pin 4 and pin 7), effective shielding is not ensured.

Connect the shielding of the video cable to the stud bolt of the device housing:



Caption:

Number	Element
1	Threaded stud of the device housing
2	Plain washer
3	Wire lug
4	Lock washer
5	Nut

2 Product Description and Design

Introduction

This chapter covers the design of the device, as well as how the order reference is made up including all options.

Contents

Topic	Page
Product Description - JVM-407	18
Parts and Interfaces.....	19
Order Reference / Options	23
Physical Dimensions	24

Product Description - JVM-407

HMI JVM-407

The HMI JVM-407 is extremely versatile thanks to its compact design and the integrated controller.

The JVM-407 can replace a complete instrument cluster.

The JVM-407 has been specially designed for use in the harsh environment of commercial vehicles and mobile machines.

Product Features

The features of this product are listed below:



- Display: 7" TFT with LED backlight
 - Resolution: WVGA (800 x 480 pixels)
 - 4 function keys
 - 1 digipot
 - 10 status LEDs available for selection via 10 digital inputs, rated for a power supply of 12 V and 24 V on the vehicle
 - Adjustable night-lighting
 - Buzzer (93 dB)
 - Powerful programming language JetSym STX
 - Non-volatile registers: 6,000
 - RAM memory: 16 MBytes
 - Flash memory: 64 MBytes
 - 1 Ethernet interface
 - 3 CAN-2.0B interfaces
 - An additional 5 digital inputs freely available, rated for a power supply of 12 V and 24 V on the vehicle
 - 1 protected digital output, 3 A
 - 1 composite color signal (FBAS) video input for rearview camera
 - 1 USB port
 - SD card slot for SD cards up to 8 GBytes
 - Real-time clock with battery backup
 - Integrated Web server / e-mail feature
 - Modbus/TCP
-


Parts and Interfaces

Introduction

This chapter describes the parts and interfaces for the JVM-407.

Controls

The diagram shows the controls on the front panel.




Number	Control	
1	USB port behind protective cover	
2	Function key F1	The digipot functions and the function keys are defined by the customer in the program.
3	Function key F2	
4	Function key F3	
5	Function key F4	
6	Digipot (control dial with pushbutton feature)	

2 Product Description and Design

Displays

The diagram shows the display elements on the front panel.




Number	Control or display element
1	LED 1
2	LED 2
3	LED 3
4	LED 4
5	LED 5
6	LED 6
7	LED 7
8	LED 8
9	LED 9
10	LED 10
11	Display screen

The LEDs illuminate the pictograms on the display.

Connectors and Parts on the Rear Panel


The diagram shows the connectors and parts on the rear panel.



Number	Connector or part
1	CANopen® connector
2	Name plate
3	Video connector
4	Power supply connector, inputs and outputs
5	4 threaded pins for installation panel
6	Backup battery on the circuit board
7	Buzzer

Connectors and Parts on the Underneath Panel

The diagram shows the connectors and parts on the underneath panel.




2 Product Description and Design

Number	Connector or part
1	Connector jack for the ethernet cable
2	SD memory card slot

LEDs on the Underneath Panel

The diagram shows the LEDs for the connector jack for the Ethernet cable.



Number	Color	Description
1	amber	blinks when active (data transfer)
2	green	lights up when connection established

Order Reference / Options

Order Reference

The following variants exist for the JVM-407. They can be ordered from Jetter AG using the following part numbers.

Part Number	Order Reference	Name
10000821	JVM-407-K00-O01	HMI with support arm
10000822	JVM-407-K00-O12	HMI for panel mounting


Physical Dimensions

Introduction

This chapter details the physical dimensions of the JVM-407 and the conditions for installation.


Physical Dimensions

The diagram shows the dimensions of the JVM-407.



Permissible Installation Positions

The diagram shows the positions permitted for installation.




Explanations are as follows:

Number	Permissible Installation Positions
1	horizontally or tilted
2	vertical or tilted

Prohibited Installation Positions


The diagram shows the positions prohibited for installation.



The rear panel of the HMI JVM-407 has no moisture protection, particularly against spray or water droplets. If the installation location cannot be guaranteed to be moisture-free, this method of installation (see diagram above) is prohibited. The accumulation of moisture and water droplets in the device can lead to current leakages and corrosion.

Space Required for Installation and Service

The diagram shows the space required for the HMI JVM-407.



Ensure there is enough space around the housing for servicing requirements.

- It should be possible to disconnect the connector at any time.
- It should be possible to exchange the SD card at any time.
- It must be possible to easily loosen the wing nut on the SD card locking device.


2 Product Description and Design

Explanations are as follows:

Number	Description
1	Connectors for CANopen®, video, power supply, inputs and outputs
2	Wing nut to secure the SD card
3	Network connector
4	SD memory card

Space Required to Protect Against Overheating

The diagram indicates the safe distance to protect against overheating.



Please note:

- The JVM-407 increases the temperature of the environment as a result of heat emission under load. Power consumption is 7.8 W.
- The JVM-407 operates without interruption at an ambient temperature of up to +65 °C.

Consider the heat emission from the device, in particular when installing it in a critical environment:

- in the vicinity of the fuel tank
 - in the vicinity of the fuel pipe
 - in the vicinity of flammable vehicle components
 - in the vicinity of thermally malleable vehicle components
-

Installation Location

The JVM-407 must be installed in the driver's cab.

3 Identifying the JVM-407

Purpose of this Chapter	<p>This chapter is for supporting you in identifying the following information with regard to JVM-407:</p> <ul style="list-style-type: none"> ▪ Hardware revision. ▪ Electronic data sheet (EDS). Numerous manufacturing-relevant data are stored to EDS. ▪ OS release of the controller and software components. 						
Prerequisites	<p>To be able to identify technical data about the HMI JVM-407 the following prerequisites must be fulfilled:</p> <ul style="list-style-type: none"> ▪ The controller is connected to a PC. ▪ The programming tool JetSym 4.1.2 or higher is installed on the PC. 						
Information for Hotline Requests	<p>If you have to contact the hotline of Jetter AG in case of a problem, please have the following information on the HMI JVM-407 ready:</p> <ul style="list-style-type: none"> ▪ Serial number ▪ OS release of the HMI ▪ Hardware revision 						
Contents	<table border="0" style="width: 100%;"> <thead> <tr> <th style="text-align: left;">Topic</th> <th style="text-align: right;">Page</th> </tr> </thead> <tbody> <tr> <td>Identification by Means of the Nameplate</td> <td style="text-align: right;">28</td> </tr> <tr> <td>Version Registers.....</td> <td style="text-align: right;">30</td> </tr> </tbody> </table>	Topic	Page	Identification by Means of the Nameplate	28	Version Registers.....	30
Topic	Page						
Identification by Means of the Nameplate	28						
Version Registers.....	30						

3.1 Identification by Means of the Nameplate

Introduction

Each HMI JVM-407 can be identified by its nameplate attached to its enclosure. If you have to contact the hotline of Jetter AG in case of a problem, you need to have the hardware revision data and the serial number at hand.


Contents

Topic	Page
Nameplate.....	29

Nameplate

Nameplate

The nameplate of a JVM-407 contains the following information:



Number	Description
1	Serial number
2	Hardware revision
3	HMI
4	Part number

3.2 Version Registers

Introduction

The operating system of the JVM-407 provides several registers which can be used to read out the version numbers of the OS and its components. You will need this information when contacting the hotline of Jetter AG in case of a problem.

Contents

Topic	Page
Software Versions	31

Software Versions

Introduction

The HMI JVM-407 features software with unique version numbers which can be read out via special registers.

Format of Software Version Numbers

The software version number of the HMI JVM-407 is a four-figure value.

1	.	2	.	3	.	4
---	---	---	---	---	---	---

Entry	Description
1	Major or main version number
2	Minor or secondary version number
3	Branch or intermediate version number
4	Build version number

Released Version

A released version can be recognized by both Branch and Build having got value zero.


Overview of Registers

The following registers are used for reading out software versions:

Register	Description
200168	Boot loader version
200169	Operating system version
210001	Version of the execution unit for the STX application program (JetVM version)

Version Numbers in JetSymb Setup

The following screenshot shows a JetSymb setup window displaying version registers. For displaying the version number in the setup window of JetSymb, please select the format "IP address".



Number	Entry	Function
1	V 1.15.01.00	OS version of the HMI. JetSymb displays this information in the title bar of each setup window.

4 Installing the JVM-407

Purpose of this Chapter This chapter supports the installing of the HMI JVM-407 in the vehicle as regards the following points:

- Wiring layout for the JVM-407
- Installation
- Configuration of the IP interface for the JVM-407

Contents

Topic	Page
Interfaces	34
Interfaces on the Center Console with Mounted Support Arm	54
Installing the JVM-407	62
IP Configuration	68

4.1 Interfaces

Connector for the Power Supply and the Digital Inputs/Outputs

The connector has the following functions:

- Power supply for the JVM-407
 - Digital I/Os
-

Ethernet Interface

The function of the RJ45 jack is as follows:

- Ethernet interface to a PC
-

Three CAN interfaces

The function of the CAN interfaces is as follows:

- Interface CAN 0: Configurable as CAN-PRIM interface
 - Interfaces CAN 0 through CAN 2: Configurable as CANopen® bus interface
-

Connector for Video Camera

The connector has the following functions:

- Option to connect a video camera, e.g. a rearview camera, with a voltage rating of 12 VDC.
-

Contents

Topic	Page
Example of Wiring Layout.....	35
Connecting the Power Supply	36
Connecting Digital Inputs and Outputs	38
HMI Switch Off Delay	41
Ethernet Interface	43
CAN Interface	45
Specification - CANopen® Bus Cable	49
Connecting a Video Camera.....	51


Example of Wiring Layout

Introduction

This chapter uses an example to show how the JVM-407 is connected.

Example

The diagram shows an example of a wiring layout.



Explanations are as follows:

1	CANopen® bus
2	Video camera
3	Power supply (battery)
4	Ignition lock
5	Input to control the display LEDs
6	Output, e.g. to control a bypass relay

Connecting the Power Supply

Introduction


This chapter describes the pin assignment for the connector for the JVM-407 power supply. The connector type is the 22-pin Molex Micro-Fit 3.0 connector (manufacturer's item number 43045-2218).

Use of the Connector

This connector is also used for digital inputs and outputs.

Power Supply

The diagram shows the pin assignment for the connector for the power supply (cable panel view):



The pin assignment is as follows:

Pin	Function	Terminal name in vehicle
1	Supply voltage +U BATT (+12 VDC or +24 VDC)	KL 30
2	Ignition (+)	KL 15
11	GND	KL 31
12	Supply voltage U BATT (+12 VDC or +24 VDC)	KL 30
22	GND	KL 31

Important Note on Supply Voltage

In order to halve the current load on pins 1 and 12, as well as on pins 11 and 22, all four pins should be connected to the supply voltage as per the above pin assignment.

Note on Ignition

To start the JVM-407, pin 2 (ignition +) must be connected with pin 1 or pin 12. The ignition control signal is issued when the key is in position "Ignition ON". When the key is in position "Ignition OFF", the JVM-407 is able to keep its status as ON.

Technical Data


Parameter	Description
Rated voltage	DC 12 V or DC 24 V
Permissible voltage range	9 ... 32 VDC
Input current without camera	typ. 650 mA for DC 12 V
Input current without camera	typ. 320 mA for DC 24 V
Power consumption without camera	7.8 W


Note on Current Consumption

When the JVM-407 is switched on, the current consumption is temporarily higher. To ensure that the JVM-407 can be activated, the supplied current should be at least 3-times the typical current.

Mating Parts

Compatible mating parts for the 22-pin Molex Micro-Fit 3.0 connector are as follows:

	Manufacturer	Molex
	Manufacturer's item number - case	43025-2200
	Manufacturer's item number - crimp contact (jack)	43030-0007
	Diameter of the cable apt for connecting	0.2 ... 0.5 mm ² (AWG 24 ... 20)

	Manufacturer	Würth
	Manufacturer's item number - case	662 022 113 322
	Manufacturer's item number - crimp contact (jack)	662 001 137 22
	Diameter of the cable apt for connecting	0.2 ... 0.5 mm ² (AWG 24 ... 20)

Connecting Digital Inputs and Outputs

Introduction


This chapter describes the pin assignment for the connector for the inputs and outputs on the JVM-407. The connector type is the 22-pin Molex Micro-Fit 3.0 connector (manufacturer's item number 43045-2218).

Use of the Connector

This connector is also used for the power supply.

Pin Assignment of Inputs and Outputs

The diagram shows the pin assignment for the connector for inputs and outputs (cable panel view):



The pin assignment is as follows:

Pin	Function
3	Output 1
4	Input # 2
5	Input # 4
6	Input # 6
7	Input # 8
8	Input # 10
9	Input # 12
10	Input # 14
11	GND
12	Supply voltage (+12 VDC or +24 VDC)
13	Output 1
14	Input # 1
15	Input # 3
16	Input # 5
17	Input # 7
18	Input # 9

Pin	Function
19	Input # 11
20	Input # 13
21	Input # 15

Note on Output 1

Because output 1 can source a current of up to 3 A, output 1 has been assigned to pins 3 and 13. This halves the current load on the individual pins. For this reason, both pins need to be connected.

Note on LEDs

Because inputs 1 through 10 are directly connected with LEDs, the vehicle status can be displayed even when the display is disabled. A possible vehicle status can be e.g. full beam, flashing indicators, fault, etc.

Technical Data of Digital Inputs

Parameter	Description
Type of inputs	Transistor, npn
Rated voltage	DC 9 ... 32 V
Threshold level OFF	~ 8.5 V, 10 mA
Threshold level ON	~ 8.3 V, min. 50 mA
Electrical isolation	none


Technical Data of Digital Outputs


Parameter	Description
Type of outputs	Transistor, pnp
Rated voltage	Supply voltage
Signal voltage OFF	< 1.0 V
Signal voltage ON	$U_{\text{Supply}} - 0.025 \text{ V}$
Load current	max. 3.0 A

4 Installing the JVM-407

Mating Parts

Compatible mating parts for the 22-pin Molex Micro-Fit 3.0 connector are as follows:

	Manufacturer	Molex
	Manufacturer's item number - case	43025-2200
	Manufacturer's item number - crimp contact (jack)	43030-0007
	Diameter of the cable apt for connecting	0.2 ... 0.5 mm ² (AWG 24 ... 20)

	Manufacturer	Würth
	Manufacturer's item number - case	662 022 113 322
	Manufacturer's item number - crimp contact (jack)	662 001 137 22
	Diameter of the cable apt for connecting	0.2 ... 0.5 mm ² (AWG 24 ... 20)

HMI Switch Off Delay

Introduction

This chapter describes how the switch off delay for the HMI JVM-407 is implemented.

Objective


After switching off the ignition, the HMI should still remain switched on for a specific length of time. Only after this time has elapsed, it should switch itself off automatically.

Duration of Switch Off Delay

The duration for the switch off delay is defined in the JVM-407 program.

Wiring

The diagram shows the wiring for the switch of delay (cable panel view for jacks):



Explanations are as follows:

1	Battery
2	Ignition lock
3	Bypass relay
4	Vehicle

4 Installing the JVM-407

Pin Assignment

The pin assignment is as follows:

Pin	Function	Terminal name in vehicle
1	Supply voltage +U BATT (+12 VDC or +24 VDC)	KL 30
2	Ignition (+)	KL 15
3	Bypass relay	-
11	GND	KL 31
12	Supply voltage +U BATT (+12 VDC or +24 VDC)	KL 30
22	GND	KL 31


Ethernet Interface

Introduction

This chapter describes the pin assignment for the connector jack for the ethernet cable on the HMI JVM-407.

Pin Assignment of Ethernet Interface

The diagram shows the pin assignment for the connector jack for the Ethernet cable:



The pin assignment is as follows:

Pin	Function
1	TX+
2	TX-
3	RX+
6	RX-

Technical Data

Parameter	Description
Type of terminal	RJ45 Ethernet jack
Number of ports	1
Baud rate	10 Mbit/s, 100 Mbit/s
Auto cross-over	Yes

Cable for Ethernet Interface

For connecting devices to the ethernet interface, you can order the following cables separately from Jetter AG :

Item #	Item
60537500	Patch cable 1:1, 1 m gray Hirose, Cat 5e, shielded
60854512	Patch cable 1:1, 2 m grey Hirose, Cat 5e, shielded
60854514	Patch cable 1:1, 5 m grey Hirose, Cat 5e, shielded
60854515	Patch cable 1:1, 10 m grey Hirose, Cat 5e, shielded
60854078	Patch cable cross-over, 1 m gray Hirose, Cat 5e, shielded

4 Installing the JVM-407

Item #	Item
60851216	Patch cable cross-over, 3 m blue Hirose, Cat 5e, shielded
60854079	Patch cable cross-over, 5 m gray Hirose, Cat 5e, shielded


CAN Interface

Introduction

This chapter describes the pin assignment for the connector for the CANopen® bus on the JVM-407. The connector type is the 16-pin Molex Micro-Fit 3.0 connector (manufacturer's item number 43045-1618).

Pin Assignment CANopen® 0

The diagram shows the pin assignment for the connector for the CANopen® bus 0 (cable panel view):




The pin assignment is as follows:

Pin	Function
1	IN_CAN_0_H
2	TERM_CAN_0
3	OUT_CAN_0_L
9	IN_CAN_0_L
10	OUT_CAN_0_H
16	Shield

4 Installing the JVM-407

Pin Assignment CANopen® 1

The diagram shows the pin assignment for the connector for the CANopen® bus 1 (cable panel view):




The pin assignment is as follows:

Pin	Function
11	IN_CAN_1_H
4	IN_CAN_1_L
12	TERM_CAN_1
5	OUT_CAN_1_H
13	OUT_CAN_1_L
16	Shield

Pin Assignment CANopen® 2

The diagram shows the pin assignment for the connector for the CANopen® bus 2 (cable panel view):



The pin assignment is as follows:

Pin	Function
6	IN_CAN_2_H
7	TERM_CAN_2
8	OUT_CAN_2_L
14	IN_CAN_2_L
15	OUT_CAN_2_H
16	Shield


Activating the Bus Termination Resistor

To enable the resistor in the JVM-407 as the bus termination resistor, the TERM_CAN_x pin must be connected to the Pin OUT_CAN_x_H.

Shield

To satisfy EMC requirements, the CAN cable shield must be connected to the module housing. Connection of pin 16 (shield) alone is insufficient for effective shielding.

Connect the video cable shield to the threaded pins of the module housing:




Explanations are as follows:


Number	Part
1	Threaded pins of the module housing
2	Washer
3	Cable lug
4	Lock washer
5	Screw nut

4 Installing the JVM-407

Mating Parts

Compatible mating parts for the 16-pin Molex Micro-Fit 3.0 connector are as follows:


	Manufacturer	Molex
	Manufacturer's item number - case	43025-1600
	Manufacturer's item number - crimp contact (jack)	43030-0007
	Diameter of the cable apt for connecting	0,2 ... 0.5 mm ² (AWG 24 ... 20)

	Manufacturer	Würth
	Manufacturer's item number - case	662 016 113 322
	Manufacturer's item number - crimp contact (jack)	662 001 137 22
	Diameter of the cable apt for connecting	0,2 ... 0.5 mm ² (AWG 24 ... 20)

Specification - CANopen® Bus Cable

Layout of CAN Bus Wiring

Jetter AG CANopen® devices are wired in accordance with the following diagram.



Number	Description
1	CAN bus
2	Jetter AG CANopen® devices

There is an option to enable a resistor in the device as a bus termination resistor of 120 Ohm.

The stub length with this type of wiring is practically zero.

The CAN_L and CAN_H cables must be twisted together.

4 Installing the JVM-407

CAN Bus Cable Specification

Parameter	Description
Core cross-sectional area	1000 kBaud: 0.25 ... 0.34 mm ² 500 kBaud: 0.34 ... 0.50 mm ² 250 kBaud: 0.34 ... 0.60 mm ² 125 kBaud: 0.50 ... 0.60 mm ²
Cable capacitance	60 pF/m max.
Resistivity	1000 kBaud: max. 70 Ω/km 500 kBaud: max. 60 Ω/km 250 kBaud: max. 60 Ω/km 125 kBaud: max. 60 Ω/km
Number of cores	2
Shield	Complete shielding, no paired shielding
Twisting	Core pairs CAN_L and CAN_H are twisted

Cable Lengths

The maximum permitted cable length depends on the baud rate used and the number of CANopen® devices connected.

Baud Rate	Cable length	Stub length	Overall stub length
1000 kBaud	max. 25 m	max. 0.3 m	3 m
500 kBaud	max. 100 m	max. 1.0 m	39 m
250 kBaud	max. 200 m	max. 3.0 m	78 m
125 kBaud	max. 200 m	-	-


Connecting a Video Camera

Introduction

This chapter describes the pin assignment for the connector for the video camera on the JVM-407. The connector type is the 8-pin Molex Micro-Fit 3.0 connector (manufacturer's item number 43045-0818).

Pin Assignment - Video Input

The diagram shows the pin assignment for the connector for the video camera (cable panel view):



The pin assignment is as follows:

Pin	Function
1	Supply voltage (+12 VDC) e.g. for a camera
2	Video signal (+)
3	Shield
4	Ground (GND)
5	Video signal (-)
6	Ground (GND)
7	Video signal (-)
8	Reserved (do not connect!)

Note on Video Signal


If no differential video signal is used, video signal (-) (pin 7) and GND (pin 6) should be connected.

Shield

To satisfy EMC requirements, the video cable shield must be connected to the module housing. The ground connections (pin 4 and pin 7) are insufficient for effective shielding.

Connect the video cable shield to the threaded pins of the module housing:

4 Installing the JVM-407



Explanations are as follows:


Number	Part
1	Threaded pins of the module housing
2	Washer
3	Cable lug
4	Lock washer
5	Screw nut


Technical Data

Parameter	Description
Power supply for a camera	DC 12 V, max. 1 A
Type of video input	analog, differential composite color signal (FBAS) video input with PAL signal or NTSC signal.

Mating Parts

Compatible mating parts for the 8-pin Molex Micro-Fit 3.0 connector are as follows:

	Manufacturer	Molex
	Manufacturer's item number - case	43025-0800
	Manufacturer's item number - crimp contact (jack)	43030-0007
	Diameter of the cable apt for connecting	0.2 ... 0.5 mm ² (AWG 24 ... 20)

	Manufacturer	Würth
	Manufacturer's item number - case	662 008 113 322
	Manufacturer's item number - crimp contact (jack)	662 001 137 22
	Diameter of the cable apt for connecting	0.2 ... 0.5 mm ² (AWG 24 ... 20)

4.2 Interfaces on the Center Console with Mounted Support Arm

Interconnecting Cable to the Center Console

This chapter covers the layout of the connection cables already installed in the support arm, if the HMI JVM-407 is mounted on the support arm.

It also covers the connector types required to connect the JVM-407 to the center console.

In the support arm, connection cables have been installed for the following purposes:

- Power supply
 - Digital inputs/outputs
 - CANopen® interfaces
 - Video
-


Contents

Topic	Page
Connection Cable - Power Supply.....	55
Connection Cable - Inputs and Outputs.....	57
Connection Cable - CANopen®.....	59
Connection Cable - Video.....	61

Connection Cable - Power Supply

Wiring

The diagram shows the wiring for the power supply in the support arm (cable panel view in each case):



Explanations are as follows:

A	Connector for the HMI JVM-407
B	Connector for the center console

Pin Assignment

The pin assignment is as follows:

Pin (A)	Function	Terminal name in vehicle	Pin (B)
1	+U BATT	KL 30	1
2	Ignition (+)	KL 15	3
11	GND	KL 31	21
12	+U BATT	KL 30	2
22	GND	KL 31	22

Use of Connector B

This connector is also used for digital inputs and outputs.


Specification of Connector B

Type	AMP Junior Power Timer (male)
Number of pins	22

4 Installing the JVM-407

Mating part


The following is a compatible mating part for the 22-pin connector AMP Junior Power Timer:

	Manufacturer	AMP
	Manufacturer's item number - Socket housing	929504-7
	Manufacturer's item number - Crimp contact (jack)	927771 (reel) 927779 (single)
	Diameter of the cable apt for connecting	0.5 ... 1.0 mm ² (AWG 20 ... 16)

Connection Cable - Inputs and Outputs

Wiring

The diagram shows the wiring for the digital inputs and digital outputs in the support arm (cable panel view in each case):



Explanations are as follows:

A	Connector for the HMI JVM-407
B	Connector for the center console

Pin Assignment

The pin assignment is as follows:

Pin (A)	Function	Pin (B)
3	Output 1	4
4	Input # 2	7
5	Input # 4	9
6	Input # 6	11
7	Input # 8	13
8	Input # 10	15
9	Input # 12	17
10	Input # 14	19
11	GND	21
13	Output 1	5
14	Input # 1	6
15	Input # 3	8
16	Input # 5	10
17	Input # 7	12
18	Input # 9	14

4 Installing the JVM-407

Pin (A)	Function		Pin (B)
19	Input # 11	For free use	16
20	Input # 13		18
21	Input # 15		20

Note on Output 1

Because the ignition coil is controlled via output 1 and consumes a high volume of power, output 1 has been assigned to pins 3 and 13 (A) or 4 and 5 (B). This halves the current load on the individual pins. For this reason, both pins need to be connected.

Use of Connector B


This connector is also used for the power supply.

Specification of Connector B

Type	AMP Junior Power Timer (male)
Number of pins	22

Mating part


The following is a compatible mating part for the 22-pin connector AMP Junior Power Timer:

	Manufacturer	AMP
	Manufacturer's item number - Socket housing	929504-7
	Manufacturer's item number - Crimp contact (jack)	927771 (reel) 927779 (single)
	Diameter of the cable apt for connecting	0.5 ... 1.0 mm ² (AWG 20 ... 16)

Connection Cable - CANopen®

Wiring

The diagram shows the wiring for the CAN cable in the support arm (cable panel view in each case):



CAN_0_H and CAN_0_L must be twisted together.
 CAN_1_H and CAN_1_L must be twisted together.

Explanations are as follows:

A	Connector for the HMI JVM-407
B	Connector for the center console

Pin Assignment

The pin assignment is as follows:

Pin (A)	Function	Pin (B)
1	IN_CAN_0_H	1
2	TERM_CAN_0	
3	OUT_CAN_0_L	4
4	IN_CAN_1_L	6
5	OUT_CAN_1_H	
6	IN_CAN_2_H	
7	TERM_CAN_2	
8	OUT_CAN_2_L	
9	IN_CAN_0_L	2
10	OUT_CAN_0_H	3
11	IN_CAN_1_H	5
12	TERM_CAN_1	
13	OUT_CAN_1_L	
14	IN_CAN_2_L	

4 Installing the JVM-407

Pin (A)	Function	Pin (B)
15	OUT_CAN_2_H	
16	Shield	9
		10


CAN 1 is terminated on the connector for JVM-407 (jumper between pin 6-8).

Specification of Connector B

Type	AMP Junior Power Timer (male)
Number of pins	10

Mating part


The following is a compatible mating part for the 10-pin connector AMP Junior Power Timer:

	Manufacturer	AMP
	Manufacturer's item number - Socket housing	929504-4
	Manufacturer's item number - Crimp contact (jack)	927771 (reel) 927779 (single)
	Diameter of the cable apt for connecting	0.5 ... 1.0 mm ² (AWG 20 ... 16)

Connection Cable - Video

Wiring

The diagram shows the wiring for the video cable in the support arm (cable panel view in each case):



Explanations are as follows:

A	Connector for the HMI JVM-407
B	Connector for the center console

Pin Assignment

The pin assignment is as follows:

Pin (A)	Function	Pin (B)
1	Supply voltage +12 V	2
2	Video signal (+)	4
3	Shield	1
4	Ground	3
5	Video signal (-)	5
6	Ground	3
7	Video signal (-)	5
8	Reserved (do not connect!)	

Note on Video Signal

By default, cables in the support arm are connected to A pin 6 and 7, i.e. no differential video signal is used.

Specification of Connector B

Type	Jack M12
Number of pins	5

Mating Part

The 5-pin M12 connector is a compatible mating part.

4.3 Installing the JVM-407

Introduction

This chapter describes how to install the JVM-407.

Contents

Topic	Page
Installing the HMI	63
Mounting the Support Arm	66

Installing the HMI

Introduction

This chapter describes how to install the HMI JVM-407.

Selecting a Place for Installation

Select a suitable place for the device to be mounted.

A place is suitable if it fulfils the following requirements:

- The installation surface must be made from one of the following materials:
 - aluminum plate
 - galvanized steel plate
 - lacquered steel plate
 - plastic
- The installation surface must be level.
- The installation surface should be no more than 5 mm thick.
- The installation location must allow air to circulate.
- The installation location must be accessible for servicing.
- The installation location must be of sufficient size.

Avoiding Unsuitable Installation Locations

Do not install the device in inappropriate locations.

The following installation locations are unsuitable for mounting the HMI:

Unsuitable installation location	Reason
Outdoor installation	The HMI must not be exposed to rain or a jet of water. Therefore, do not use a steam jet or other such devices to clean the HMI.
Unventilated installation location	The HMI could overheat as heat builds up.
Installation location close to heat-sensitive materials	The materials could become warped or misshapen as a result of heat produced by the HMI.
Installation surfaces are uneven	The installation surface could become misshapen when fitting the HMI. Installation is unstable and precarious.

Consider Ergonomic Principles

Consider ergonomic principles.

Select a user-friendly place for installation:

- The controls must be easy to reach.
- The HMI screen must be easy to read.

Avoid installation locations that are ergonomically unsuitable:


- Extreme angles, which could make it difficult to see the HMI
- Unsuitable lighting conditions with reflection and glare
- Concealed installation locations that are difficult for the user to access

4 Installing the JVM-407

Preparing for Installation

Make a square opening.

The diagram shows the dimensions:




Explanations are as follows:

1	Opening
2	Outline of the front panel

Installing the HMI

The diagram shows how to install:



Explanations are as follows:

1	Threaded pins on the JVM-407 housing
---	--------------------------------------

2	Opening
3	Fitting panel
5	SD card holder
6	4 x wing nut


Step	Action
1	Insert the HMI into the front of the opening.
2	Attach the fitting panel at the back. Ensure it is correctly positioned: Hole over the buzzer.
3	Push the SD card holder onto the threaded pins for the SD card slot.
4	Screw the holder firmly into place with a wing nut.
5	Screw the fitting panel firmly into place with the remaining three wing nuts.

Installing the Strain Relief

Install the strain relievers for the connection cable.

Take care to leave enough space for the connectors.

Connectors should not be obstructed, so that they can be removed in the event of a service requirement.



Mounting the Support Arm

Introduction

This chapter describes how to mount the support arm for the HMI JVM-407.

Selecting a Place for Installation

Select a suitable place for the device to be mounted.

A place is suitable if it fulfils the following requirements:

- The installation surface must be level. The surface should not be uneven.
- The mounting surface must be rigid to be able to withstand the leverage force of the support arm.
- Underneath the mounting area, there must be enough space for cable guides.
- The installation location must be accessible for tightening and loosening screws.

Consider Ergonomic Principles

Consider ergonomic principles.

Select a user-friendly place for installation.


- The controls must be easy to reach.
- The HMI screen must be easy to read.

Avoid installation locations that are ergonomically unsuitable:

- Extreme angles, which could make it difficult to see the HMI.
- Unsuitable lighting conditions with reflection and glare
- Concealed installation locations that are difficult for the user to access

Preparing for Installation

Drill the following holes. The diagram shows the dimensions:




Deburr the holes.

Explanations are as follows:

1	Holes for screws and cable feed-through
2	Outline of the support arm base

Mounting the Support Arm Base

The diagram shows how to install:



Explanations are as follows:

1	4 x screws M 5 x 14 mm + thickness of mounting surface (It is permitted to use e.g. hexagon socket head cap screws DIN 912)
2	4 x lock washers
3	4 x screw holes
5	Support arm base
6	Support arm

Step	Action
1	Place the support arm on the installation surface.
2	Screw the support arm firmly into place from underneath using four screws and four lock washers.
3	Guide the cable through the support arm base.
4	Push the support arm onto the support arm base. It must click into place.
5	Loosen the locking lever.
6	Adjust the angle of the HMI so that it is comfortable for the user.
7	Lock the HMI into place by tightening the locking lever.

4.4 IP Configuration

Introduction

This chapter describes how the IP configuration for the HMI JVM-407 is implemented. To this end, the following parameters can be set:

- IP address of the HMI
- Subnet mask
- IP address of default gateway
- IP address of DNS server
- HMI name
- IP port number for the JetSym debugger
- Base port number for communication via JetIP

Engineer's Skills Required

To carry out IP configuration of the HMI JVM-407, knowledge of IP networks is required, for example:

- IP addressing (e.g. IP address, port number, subnet masks etc.)
- FTP (connection setup, data transmission, etc.)

Contents

Topic	Page
Factory Settings	69
Configuration Memory.....	70
Configuration File cfgvar.ini.....	71
Configuration Registers	75
Modifying the IP Address of the Controller	76
Setting the IP Address via the File cfgvar.ini.....	77
Setting the IP Address During Runtime	78
Using Names for IP Address.....	79

Factory Settings

Introduction

Before the HMI JVM-407 is shipped, various parameters are set to a certain value.

These parameters can be modified by the user.

Factory Settings

Parameter	Value
IP address of the controller	192.168.10.15
Subnet mask	255.255.255.0
IP address of default gateway	0.0.0.0
IP address of DNS server	0.0.0.0
Controller name	JVM-4xx
IP port number for debugger	52000
IP port number for JetIP	50000
Administrator password	admin
System password	system

Configuration Memory

Introduction

The parameters for initializing the IP interface are uploaded from the configuration memory by the HMI during the boot process. Data stored to the configuration memory can be accessed in the following ways:

- Configuration data can be read out of a file located in the system directory of the file system. They can also be modified in this file.
- Configuration data can be read out via registers.

Enabling Conditions

The HMI reads data located in the configuration memory only during the boot process. If changes are made to the configuration memory, the HMI must be rebooted for these changes to become effective.

Default Values

Before data from the configuration memory are used, the HMI checks them for plausibility. If entries are invalid or absent, the following default values are used:

Parameter	default
IP address of the controller	192.168.10.15
Subnet mask	255.255.255.0
IP address of default gateway	0.0.0.0
IP address of DNS server	0.0.0.0
Controller name	JVM-4xx
Suffix type of the name	0
IP port number for debugger	52000
IP port number for JetIP	50000

Related Topics

- **Configuration File `cfgvar.ini`** on page 71
 - **Configuration Registers** on page 75
-

Configuration File *cfgvar.ini*

Introduction

The configuration file *cfgvar.ini* can be used to access the configuration memory of the JVM-407.

Properties

- The file can be accessed via the file system of the HMI.
- For an FTP connection, the user must have administrator or system rights.
- This file is located in the subdirectory "/System".
- This file cannot be deleted; it can only be overwritten.
- Formatting the flash disk has no impact on this file.

File Structure

This configuration file is a text file, the entries of which are grouped into several sections. For missing IP configuration parameters default values are used.

Example for *cfgvar.ini*

This is an example for a configuration file *cfgvar.ini*:

```
;JVM-407 System Configuration
;Copyright (c) 2009 by Jetter AG, Ludwigsburg, Germany

[IP]
Address      = 192.168. 50.  1
SubnetMask   = 255.255.255.  0
DefGateway   = 192.168. 50. 11
DNSServer    = 192.168.  1. 44

[HOSTNAME]
SuffixType   = 0
Name         = JVM-4xx

[PORTS]
JetIPBase    = 50000
JVMDebug     = 52000
```

Section [IP]

In the section [IP] the required IP addresses and the subnet mask are specified.

Address

In the given example	192.168.50.1
Function	IP address of the HMI
Allowed values	<ul style="list-style-type: none">▪ > 1.0.0.0▪ < 223.255.255.255
Illegal values	<ul style="list-style-type: none">▪ Network address▪ Broadcast address
in the event of an illegal value	the HMI will set all 4 values to their default values.

SubnetMask

In the given example	255.255.255.0
Function	Subnet mask
Allowed values	<ul style="list-style-type: none">▪ >= 128.0.0.0
Illegal values	<ul style="list-style-type: none">▪ 1 and 0 mixed
in the event of an illegal value	the HMI will set all 4 values to their default values.

DefGateWay

In the given example	192.168.50.11
Function	IP address of the gateway to other subnets; The HMI must be able to reach the subnet (Address/SubnetMask), otherwise it will set this parameter to 0.0.0.0.
Allowed values	<ul style="list-style-type: none">▪ > 1.0.0.0 and▪ < 223.255.255.255
Illegal values	<ul style="list-style-type: none">▪ Network address▪ Broadcast address▪ A value (Address/SubnetMask) which cannot be reached by the HMI.▪ The address value
in the event of an illegal value	will be set to 0.0.0.0 by the controller.

DNSServer

In the given example	192.168.1.44
Function	IP address of the server for the Domain Name System.
Allowed values	<ul style="list-style-type: none">▪ 1.0.0.0▪ 223.255.255.255
in the event of an illegal value	the HMI will set the value to 0.0.0.0

Section [HOSTNAME]

In the section [HOSTNAME] the name of the HMI is specified. The HMI is able to generate an individual name automatically. This host name is not currently used.

SuffixType	
In the given example	0
Function	The type of the automatically generated suffix is attached to the HMI name.
Allowed values	<ul style="list-style-type: none"> ▪ 0: No attachment ▪ 1: Low-order byte of the IP address in decimal notation. ▪ 2: Low-order byte of the IP address in hexadecimal notation.
in the event of an illegal value	0
Name	
In the given example	JVM-4xx
Function	Specifies the HMI name.
Allowed values	<ul style="list-style-type: none"> ▪ First character: 'A' ... 'Z', 'a' ... 'z' ▪ Next character: 'A' ... 'Z', 'a' ... 'z', '0' ... '9', '-'
in the event of an illegal value	JVM-4xx

Section [PORTS]

In the section [PORTS] the IP port numbers of data and debug servers within the HMI are specified. These values must be consistent with the values set in JetSym, for example the port numbers.

JetIPBase	
In the given example	50000
Function	IP port for OS update and communication with the PC
Allowed values	<ul style="list-style-type: none"> ▪ 1024 ... 65535
In the event of an illegal value	50000
JVMDebug	
In the given example	52000
Function	IP port for debugger/setup in JetSym
Allowed values	<ul style="list-style-type: none"> ▪ 1024 ... 65535
In the event of an illegal value	52000

4 Installing the JVM-407

Changing IP Configuration

Step	Action
1	Use a text editor to create a configuration file on your PC named <i>cfgvar.ini</i> and make the corresponding entries.
2	Open an FTP connection between the PC and JVM-407.
3	Log in as user with administrator or system rights. Standard: User: admin; Password: admin
4	Browse to subdirectory "/System" of the JVM-407.
5	Copy the configuration file <i>cfgvar.ini</i> you created on the JVM-407.
6	Close the FTP connection.
7	Reboot the device. Result: The new configuration is active.

Related Topics

- **Configuration Memory** on page 70
 - **Configuration Registers** on page 75
-

Configuration Registers

Introduction

The IP configuration parameters can be read via configuration registers. A range of registers holds the data contained in the configuration memory. Another range contains the parameters actually used for initializing the IP interface.

Register Numbers

The basic register numbers of both ranges are dependent on the device. The register number is calculated by adding the number of the module register (MR) and the basic register number.

HMI	Data Range	Basic Register Number	Register Numbers
JVM-407	Configuration Memory	101100	101100 ... 101165
	Used parameter	101200	101200 ... 101265

Configuration Registers

The following table provides an overview of the registers of both ranges, as well as their connection to the entries in the configuration file "/System/cfgvar.ini".

Registers	Section in config.ini	Name in config.ini	Function
MR 0	IP	Address	IP address of the controller
MR 1		SubnetMask	Subnet mask
MR 2		DefGateWay	IP address of the gateway to other subnets
MR 3		DNSServer	IP address of the server for the Domain Name System.
MR 32	HOSTNAME	SuffixType	The type of the automatically generated suffix is attached to the controller name.
MR 33 to MR 51		Name	Specifies the controller name
MR 64	PORTS	JetIPBase	IP port for OS update and communication between controllers
MR 65		JVMDebug	IP port for debugger/setup in JetSym

Related Topics

- **Configuration Memory** on page 70
- **Configuration file cfgvar.ini** on page 71

Modifying the IP Address of the Controller

Introduction

To be able to communicate with the JVM-407 via Ethernet, a unique IP address has to be set on the HMI.

Configuration Options

The IP address can be configured in the following ways:

- Default IP address
 - Configuration via the file `cfgvar.ini`
 - Configuration during runtime via special registers
-

Related Topics

- **Setting the IP Address via the File `cfgvar.ini`** on page 77
 - **Setting the IP Address During Runtime** on page 78
-

Setting the IP Address via the File cfgvar.ini

The File cfgvar.ini

The IP address of the HMI JVM-407 can be set using the "cfgvar.ini" file.

```
[IP]
Address      = aaa.bbb.ccc.ddd
...
```

Element	Function
Address	Line for entering the IP-address
aaa	1st byte of IP address
bbb	2nd byte of IP address
ccc	3rd byte of IP address
ddd	4th byte of IP address

Note

The IP address setting in the file cfgvar.ini is only copied if the data in the configuration memory are not OK.

Transmitting the File cfgvar.ini

Step	Action
1	Establish an FTP connection to the JVM-407.
2	Log in as user with administrator or system rights. Standard: User: admin; Password: admin (default)
3	Open the directory /System.
4	Copy the cfgvar.ini file into the directory /System.
5	Clear the FTP connection.
6	Restart the JVM-407.

Setting the IP Address During Runtime

Introduction

The parameters for initializing the IP interface are read out of the configuration memory during the boot process. The following settings can also be changed during the runtime of the JVM-407 via registers:

- IP Address
- Subnet mask
- IP address of default gateway

Settings made during runtime do not affect the parameters stored in the configuration memory, but will be lost when the JVM-407 is switched off.

Prerequisites

- These settings must only be made when there is no active communication via IP interface, otherwise data may be lost.
 - It must be ensured that the values entered are valid (e.g. through proper programming within the application program), as the JVM-407 will not validate the values which are set during runtime.
-

Overview of Registers

Registers	Description
104531	IP address of JVM-407
104532	Subnet mask
104533	IP address of default gateway

Setting IP Addresses and Subnet Mask

To set the IP address and the subnet mask proceed as follows:

Step	Action
1	Enter the value 0.0.0.0 into 104533.
2	Enter the value 0.0.0.0 into 104532.
3	Enter the desired IP address of the JVM-407 into 104531.
4	Enter the desired subnet mask into 104532.
5	Enter the desired IP address of the default gateway into 104533.

Result: The settings are made and communication is enabled.

Related Topics

- **Configuration Memory** on page 70
-

Using Names for IP Address

Introduction

When specifying IP addresses of target systems (e.g. when configuring the e-mail client), names can be used as IP addresses. Then the JVM-407 translates these names into IP addresses. A configuration file or the Domain Name System is used to assign names to their corresponding IP address.

Name Resolution

Names are resolved to IP addresses in the following way:

Stage	Description						
1	During the boot process the JVM-407 reads the IP address of the DNS server from the configuration memory.						
2	During the boot process the JVM-407 reads the file "/etc/hosts", creates a translation table with the names and IP addresses found in this file.						
3	After the boot process the JVM-407 detects a name instead of an IP address.						
4	Based on this translation table, the JVM-407 tries to resolve the name into a related IP address. <table border="1" data-bbox="667 943 1437 1077"> <thead> <tr> <th>If ...</th> <th>... Then ...</th> </tr> </thead> <tbody> <tr> <td>the name was resolved</td> <td>the JVM-407 continues with step 6</td> </tr> <tr> <td>the name could not be resolved</td> <td>the JVM-407 continues with step 5</td> </tr> </tbody> </table>	If Then ...	the name was resolved	the JVM-407 continues with step 6	the name could not be resolved	the JVM-407 continues with step 5
If Then ...						
the name was resolved	the JVM-407 continues with step 6						
the name could not be resolved	the JVM-407 continues with step 5						
5	The JVM-407 tries to resolve the name into a related IP address by sending a request to the DNS server. <table border="1" data-bbox="667 1211 1437 1458"> <thead> <tr> <th>If ...</th> <th>... Then ...</th> </tr> </thead> <tbody> <tr> <td>the name was resolved</td> <td>it enters the name and IP address into the translation table and proceeds with step 6</td> </tr> <tr> <td>the name could not be resolved</td> <td>the controller aborts the function (e.g. system function for sending an e-mail) with an error message</td> </tr> </tbody> </table>	If Then ...	the name was resolved	it enters the name and IP address into the translation table and proceeds with step 6	the name could not be resolved	the controller aborts the function (e.g. system function for sending an e-mail) with an error message
If Then ...						
the name was resolved	it enters the name and IP address into the translation table and proceeds with step 6						
the name could not be resolved	the controller aborts the function (e.g. system function for sending an e-mail) with an error message						
6	The IP address found is used for further communication.						

Configuration File "hosts"

A static assignment between name and IP address is specified in this file. This file is read once when the JVM-407 is booting.

File format: Text
Location: /etc
File name: hosts

Example:

```
# Example hosts file for JC-9xx
192.168.33.209    jetter_mail
```

4 Installing the JVM-407

```
192.168.33.208    jetter_demo
192.168.1.1      JC940MC
192.168.1.2      JC940MC
```

Domain Name System (DNS)

If a name cannot be found in the file "/etc/hosts", the controller tries to resolve the IP address by obtaining the corresponding IP address from a DNS server. During the booting process of the JVM-407, the IP address of the DNS server is read from the configuration memory.

Related Topics

- **Configuration Memory** on page 70
-

5 Initial Commissioning

Purpose of this Chapter This chapter covers the initial commissioning of the JVM-407 with the aid of the following steps:

- Creating IOP files in JetViewSoft for the JVM-407 device.
- Transferring the IOP files to the JVM-407 device.
- Creating an STX project in JetSym and configuring the hardware.
- Including the .iop.h file in the STX project.
- Including the ISO library in the STX project.
- Creating a compilable program.

Everything is then prepared as far as possible for creating a program.

Minimum Requirements The instructions for initial commissioning apply to JetSym from version 4.3 and JetViewSoft from version 3.2.


ISO Functions The ISO functions are defined in the ISO 11783-6 standard.

Contents

Topic	Page
Preparatory Work for Initial Commissioning	82
Initial Commissioning in JetViewSoft.....	83
Initial Commissioning in JetSym.....	86

Preparatory Work for Initial Commissioning

Ethernet Connection to the Controller	The HMI JVM-407 default IP address is 192.168.10.15. Configure the Ethernet interface of your PC so that it is able to communicate with the JVM-407 via this IP address.
Requirement for Power-up	The JVM-407 only powers up if the supply voltage +U BATT is applied to the ignition (+).
Behavior after Power-up	If you press function keys F1 and F3 at the same time when powering up, the application program is not launched.
Default Display	The default application program launched on the JVM-407 after powering up displays the following input mask on the JVM-407 display.



The node ID displayed is the address of the CANopen® 0 bus set in the JVM-407. This address can be set by using the function keys F1 to F4. The function key F1 increases the address in steps of 10. The function key F4 decreases the address in steps of 10. The function key F2 increases the address in steps of 1. The function key F3 decreases the address in steps of 1.

The IP address, MAC address and OS version are also displayed.

Initial Commissioning in JetViewSoft

Introduction

With JetViewSoft, the **IOP files** are created for the HMI JVM-407 and transferred to the device. The following is detailed here:

- Creating a project in JetViewSoft
- Executing Project Settings
- Creating an IOP file and transferring it to the HMI

The visualization created is programmed with JetSym STX.


Prerequisites

The following requirements must be satisfied:


- JetViewSoft is installed on the PC used
- JetViewSoft has been licensed (see online help in JetView Soft)
- An active Ethernet connection between the PC and the HMI is set up

Creating a Project

A new project for the HMI is created in JetViewSoft as follows:

Step	Action
1	Start JetViewSoft
2	Open the menu item File and select the entry New . Result: The following dialog box opens:
	
3	In Project name , enter the name of the project.
4	If necessary, change the project menu path under Location .
5	Under Target platform , select JetView ER-STX(S).
6	Under Display template , select the appropriate one for the HMI.
7	Under Display name , select a program-internal name for the HMI. Several displays can be created in one project.


5 Initial Commissioning

Step	Action
8	<p>Confirm your settings by clicking OK.</p> <p>Result: The dialog box closes and the Add New Mask dialog box opens.</p> 
9	<p>Under Name, enter the name of the first DataMask. You can retain the other settings. This mask is automatically the active mask when launching the HMI.</p>
10	<p>Confirm by clicking OK.</p>

Result: A project has now been created.

Configuring Deployment

In order to be able to transfer the IOP files created with JetViewSoft to the HMI, the required deployment settings need to be made:

Step	Action
1	<p>Open the menu item Project and select the entry Properties.</p> <p>Result: A dialog box with the same name opens.</p>
2	<p>Open the Deployment pane from the navigation panel on the left-hand side of the dialog box.</p> 
3	<p>Under Deployment Target (right at the top of the dialog box), select FTP.</p>
4	<p>Click on the + sign next to Target to expand the settings.</p>
5	<p>Under Host Name/IP, enter the IP address for the HMI. The default IP address for a JVM-407 is 192.168.10.15.</p>
6	<p>Confirm your settings by clicking OK.</p>

Result: The Deployment settings have now been made and the IOP files can now be transferred to the HMI.

IOP Files

The IOP files are created and transferred from a JetViewSoft project as follows:

Step	Action
1	Open the menu item File and select the entry Save all .
2	Press the F7 key for a project build. Result: The IOP files are created as long as no errors have occurred.
3	Open the menu item Build and select the entry Deploy . Result: The IOP files are transferred to the HMI as long as no errors have occurred.
4	Restart the HMI so that the IOP files can be imported

Result: The IOP files are now displayed on the device.

Initial Commissioning in JetSym

Introduction

The STX program for the visualization of the HMI JVM-407 is created with JetSym. The following is detailed here:

- Creating a project in JetSym
- Configuring the Hardware
- Including the JetViewSoft .iop.h file
- Including the ISO Library
- Creating a program that can be compiled and transferred to the HMI


Prerequisites

The following requirements must be satisfied:

- JetSym is installed on the PC used.
- JetSym has been licensed (see online help in JetSym).
- An active Ethernet connection between the PC and the HMI is set up.
- Initial commissioning in JetViewSoft has been completed.

Creating a Project



A new project for the programming is created in JetSym as follows:

Step	Action
1	Start JetSym.
2	Open the menu item File and select the entry New . Result: The dialog box New opens
	
3	Select JetSym STX project as the project type.
4	Enter the project name.
5	Confirm your settings by clicking OK .

Result: A project has now been created.

Configuring the Hardware

To establish a connection between JetSym and the HMI, you need to configure the hardware as follows:



Step	Action
1	Switch to the Hardware view by clicking on the tab with the same name. 
2	Fully expand the Hardware tree .
3	Double-click on CPU , if the HMI JVM-407 is not set as the hardware. Result: The Configuration pane opens. 
4	Under Controller/Type , select JVM-407.
5	Under Interface/IP address , enter the IP address for the HMI. The default IP address for a JVM-407 is 192.168.10.15 .
6	Test the connection by clicking on the Test button. If this is unsuccessful, check the IP address and the Ethernet connection for the JVM-407.
7	Save your settings using the shortcut Ctrl + S .

Result: The hardware settings are now configured in JetSym.

Header File .iop.h

In order for the description of the ISO objects and masks for visualization to be



available for programming, the .iop.h file must be included as follows:


Step	Action
1	Switch to Files view. 
2	Expand the Program folder.
3	Click on the Include folder and open the context menu (right-click with the mouse).
4	Select the context menu entry Add Files to Directory . Result: An Explorer window opens, which can be used to select a file.
5	Navigate to the Output folder for the JetViewSoft project. The default location for this is under Own Files/JetViewSoft Projects/Name of JVS project/Output .
6	Select file type All Files (*.*) .
7	Select the .iop.h file.
8	Click the Open button. 

Result: The .iop.h file is now included in the JetSym project.

Including the ISO library

In order for the ISO library with the ISO functions to be available in JetSym, it must be included as follows:


Step	Action
1	<p>Open the menu item Tools and select the entry Library Manager.</p> <p>Result: A dialog box with the same name opens.</p> 
2	<p>Click the Add button.</p> <p>Result: An Explorer window opens in the Lib folder of the JetSym installation.</p>
3	<p>Select ISO_Library_1.0.0.0.libpackage.</p>
4	<p>Click the Open button.</p> <p>Result: The libpackage file is included in Library Manager and can now be included in the JetSym project.</p>
5	<p>Switch to Files view.</p> 
6	<p>Select the Library folder and open the context menu by right-clicking with the mouse.</p>

Step	Action
7	Select the option Add Libraries . Result: The Library Manager opens.
8	Select the libpackage file and click on the Use button. 

Result: The file is now included in the project.

Creating a Compilable Program.

A compilable program is created and compiled as follows:

Step	Action
1	Switch to Files view. 
2	Double-click on the program file (in this example JS_Sample_Project_JVM407_Manual.stxp). The program file has the same name as the project, plus the extension stxp . Result: The program file opens in JetSym-Editor.
3	Enter the following program code. The .iop.h file has the same name as the project, plus the extension iop.h . Please note this for the Include instruction. <pre>#Include "JVS_Sample_Project_JVM407_Manual.iop.h"; Task Main Autorun End_Task;</pre>
4	Press the F7 key to trigger a project build. Result: The ISO functions and the IOP header file are now available for programming.

Result:

The program can now be enhanced. In **IntelliSense (Ctrl + Space Bar)**, the ISO functions and the information from the IOP header file are now available. You can use the shortcut **Ctrl+F5** to transfer the program to the HMI .

However, it has no function as yet.

Related Topics:

- **Initial Commissioning in JetViewSoft** on page 83

6 CANopen® STX API

Introduction	This chapter describes the STX functions of the CANopen® STX API.
The CANopen® Standard	<p>CANopen® is an open standard for networking and communication in the automobile sector, for example.</p> <p>The CANopen® protocol has been further developed by the CiA e.V. (CAN in Automation) and works on the physical layer with CAN Highspeed in accordance with ISO 11898.</p>
Application	These STX functions are used in communication between the controller JVM-407 and e.g. the peripheral modules JXM-IO-E02, JXM-IO-E09, JXM-IO-E10, JXM-IO-E11 and JXM-MUX.
Documentation	<p>The CANopen® specifications can be obtained from the CiA e.V. http://www.can-cia.org homepage. The key specification documents are:</p> <ul style="list-style-type: none"> ▪ CiA DS 301 - This document is also known as the communication profile and describes the fundamental services and protocols used under CANopen®. ▪ CiA DS 302 - Framework for programmable devices (CANopen® Manager, SDO Manager) ▪ CiA DR 303 - Information on cables and connectors ▪ CiA DS 4xx - These documents describe the behavior of a number of device classes in, what are known as, device profiles.

Contents

Topic	Page
STX Function CanOpenInit.....	94
STX Function CanOpenSetCommand	96
STX Function CanOpenUploadSDO	98
STX Function CanOpenDownloadSDO	103
STX Function CanOpenAddPDORx.....	108
STX Function CanOpenAddPDOTx	114
CANopen® Object Directory for JVM-407	120

STX Function CanOpenInit

Introduction

Calling up the CanOpenInit () function initializes one of the CAN busses. The JVM-407 then automatically sends the heartbeat message every second with the following communication object identifier (COB-ID): Node ID + 0x700

Function Declaration

```
Function CanOpenInit (
    CANNNo: Int,
    NodeID: Int,
    const ref SWVersion: String,
) : Int;
```

Function Parameters

The CanOpenInit () function has the following parameters.

Parameter	Description	Value
CANNNo	CAN channel number	0 ... CANMAX
NodeID	Own Node ID	1 ... 127
SWVersion	Reference to own software version This software version is entered into the index 0x100A in the object directory.	String up to 255 characters

Return Value

The function transfers the following return values to the higher-level program.

Return Value

0	ok
-1	Error when checking parameters
-3	Initialization has not worked

Parameter CANNNo

The value of the CANMAX parameter depends on the device. The following table provides information on this point.

Device	CANMAX
JVM-407	2
BTM 07	2
BTM 012	1 - 2
BTM 011	0
JCM-350	4
JCM-620	2

Using this Function

Initializing the CAN bus 0. The JVM-407 has node ID 20 (0x14).

```
Result := CanOpenInit(0, 20, 'Version: 01.00.0.00');
```

How it Works

During initialization, the JVM-407 processes the following process steps:

Stage	Description
1	First, the bootup message is sent as a heartbeat message.
2	As soon as the JVM-407 goes into Pre-operational status, it sends the Pre-operational heartbeat message.

Access to the Object Directory

The Object Directory can only be accessed via SDO, if the JVM-407 is in "Pre-operational" status.

NMT Messages

After initialization, NMT messages can be sent and received. The own heartbeat status can be changed with the "CanOpenSetCommand" function.

Related Topics:

- **STX Function CanOpenSetCommand** on page 96
-

STX Function CanOpenSetCommand

Introduction

By calling up the CanOpenSetCommand () function, the own heartbeat status and the heartbeat status for all other devices (NMT slaves) can be changed on the CAN bus.

Function Declaration

```
Function CanOpenSetCommand (
    CANNNo: Int,
    iType: Int,
    Value: Int,
) : Int;
```

Function Parameters

The CanOpenSetCommand () function has the following parameters.

Parameter	Description	Value
CANNNo	CAN channel number	0 ... CANMAX
iType	Command selection	CAN_CMD_HEARTBEAT: Only the own heartbeat status is changed. CAN_CMD_NMT: The heartbeat status is changed for all other devices or for a specific device on the CAN bus.
Value	Selection of the heartbeat status for command CAN_CMD_HEARTBEAT: CAN_HEARTBEAT_STOPPED (0x04) CAN_HEARTBEAT_OPERATIONAL (0x05) CAN_HEARTBEAT_PREOPERATIONAL (0x7F) Selection of the heartbeat status for command CAN_CMD_NMT (NMT master): CAN_NMT_OPERATIONAL (0x01) or CAN_NMT_START (0x01) CAN_NMT_STOP (0x02) CAN_NMT_PREOPERATIONAL (0x80) CAN_NMT_RESET (0x81) CAN_NMT_RESETCOMMUNICATION (0x82)	

Note

The command CAN_CMD_NMT is selected via the macro function CAN_CMD_NMT_Value (NodeID, CAN_CMD_NMT).

Values from 0 to 127 are permitted for the node ID parameter. 1 to 127 is the node ID for a specific device. If the command should be sent to all devices on the CAN bus, the parameter CAN_CMD_NMT_ALLNODES (0) is used.

Parameter CANN0

The value of the CANMAX parameter depends on the device. The following table provides information on this point.

Device	CANMAX
JVM-407	2
BTM 07	2
BTM 012	1 - 2
BTM 011	0
JCM-350	4
JCM-620	2

Return Value

The function transfers the following return values to the higher-level program.

Return Value

0	ok
-1	Error when checking parameters Command not known

Using the Function (Example 1)

The own heartbeat status should be set to Operational.

```
Result := CanOpenSetCommand(0, CAN_CMD_HEARTBEAT,
CAN_HEARTBEAT_OPERATIONAL);
```

Using the Function (Example 2)

The own heartbeat status and the status of all other devices on the CAN bus should be set to Operational.

```
Result := CanOpenSetCommand(0,
CAN_CMD_NMT_Value(CAN_CMD_NMT_ALLNODES, CAN_CMD_NMT),
CAN_NMT_OPERATIONAL);
```

Using the Function (Example 3)

The heartbeat status of the device with the node ID 60 (0x3C) should be set to Operational.

```
Result := CanOpenSetCommand(0, CAN_CMD_NMT_Value(60, CAN_CMD_NMT),
CAN_NMT_OPERATIONAL);
```

STX Function CanOpenUploadSDO

Introduction

Calling up the CanOpenUploadSDO () function is aimed at accessing a particular object in the Object Directory of the message recipient and the value of the object is read. Data is exchanged in accordance with the SDO upload protocol. Supported transfer types are "segmented" (more than 4 data bytes) and "expedited" (up to 4 data bytes).

Function Declaration

```
Function CanOpenUploadSDO (
    CANNNo: Int,
    NodeID: Int,
    wIndex: Word,
    SubIndex: Byte,
    DataType: Int,
    DataLength: Int,
    const ref DataAddr,
    ref Busy: Int,
) : Int;
```

Function Parameters

The CanOpenUploadSDO () function has the following parameters.

Parameter	Description	Value
CANNNo	CAN channel number	0 ... CANMAX
NodeID	Node ID of the message recipient	1 ... 127
wIndex	Index number of the object	0 ... 0xFFFF
SubIndex	Sub-index number of the object	0 ... 255
DataType	Type of object to be received	2 ... 27
DataLength	Volume of data for the global variable DataAddr	
DataAddr	Global variable into which the received value is to be entered	
Busy	Status of the SDO transmission	

Return Value

The function transfers the following return values to the higher-level program.

Return Value	
0	ok
-1	Error when checking parameters
-2	Controller in Stop status
-3	DataType is greater than DataLength
-4	insufficient memory

Parameter CANNo

The value of the CANMAX parameter depends on the device. The following table provides information on this point.

Device	CANMAX
JVM-407	2
BTM 07	2
BTM 012	1 - 2
BTM 011	0
JCM-350	4
JCM-620	2

Parameter DataType

The following data types can be received.

Byte types	CANopen® format	Jetter format
1	CANOPEN_INTEGER8 CANOPEN_UNSIGNED8	Byte
2	CANOPEN_INTEGER16 CANOPEN_UNSIGNED16	Word
3	CANOPEN_INTEGER24 CANOPEN_UNSIGNED24	-
4	CANOPEN_INTEGER32 CANOPEN_UNSIGNED32 CANOPEN_REAL	Int
5	CANOPEN_INTEGER40 CANOPEN_UNSIGNED40	-
6	CANOPEN_INTEGER48 CANOPEN_UNSIGNED48 CANOPEN_TIME_OF_DAY CANOPEN_TIME_DIFFERENCE	-
7	CANOPEN_INTEGER56 CANOPEN_UNSIGNED46	-
8	CANOPEN_INTEGER64 CANOPEN_UNSIGNED64 CANOPEN_REAL64	-
n	CANOPEN_VISIBLE_STRING CANOPEN_OCTET_STRING CANOPEN_UNICODE_STRING CANOPEN_DOMAIN	String

Busy

After calling up the function, the Busy parameter is set to SDOACCESS_INUSE. With an error in transmission, Busy is set to SDOACCESS_ERROR. With a successful transmission, the number of bytes transmitted is returned.

"Busy" Error Codes

With an error in transmission, Busy returns an error code. The following error codes are available:

SDOACCESS_STILLUSED

Another task is communicating with the same node ID.

SDOACCESS_TIMEOUT

The task has been timed out because the device with the given node ID is not responding.

If the specified device does not respond within 1 second, the timeout code is set

SDOACCESS_ILLCMD

The response to the request is invalid.

SDOACCESS_ABORT

The device with the node ID was aborted.

SDOACCESS_SYSERROR

General internal error

Macro Definitions

The following macros have been defined in connection with this function:

SDOACCESS_FINISHED (busy)

This macro checks whether communication has finished.

SDOACCESS_ERROR (busy)

This macro checks whether an error has occurred.

Using this Function

```
Result := CanOpenUploadSDO (  
    0,  
    66,  
    0x100A,  
    0,  
    CANOPEN_STRING,  
    sizeof(var_Versionstring),  
    var_Versionstring,  
    busy);
```

JetSym STX Program

In the following example, the manufacturer's software version is read from the CANopen® Object Directory of the device with the addressed node ID.

```
#Include "CanOpen.stxp"

Const
    // CAN no.
    CAN_CONTROLLER_0 = 0;
    // Node ID Node_1
    NodeID_Node_0 = 10;
    // Node ID node 2
    NodeID_Node_1 = 66;
End_Const;

Var
    busy: Int;
    Versionstring: String;
    Objectindex: Word;
    Subindex: Byte;
End_Var;

Task main autorun

Var
    SW_Version: String;
End_Var;

SW_Version := 'v4.3.0.2004';

// Initialization CAN 0
CanOpenInit(CAN_CONTROLLER_0, NodeID_Node_0, SW_Version);

// All devices on the CAN bus have the status of PREOPERATIONAL

// Request manufacturer's software version per SDO
Objectindex := 0x100A;
Subindex := 0;
CanOpenUploadSDO(CAN_CONTROLLER_0, NodeID_Node_1, Objectindex,
Subindex, CANOPEN_STRING, sizeof(Versionstring), Versionstring,
busy);

When SDOACCESS_FINISHED(busy) Continue;

If (SDOACCESS_ERROR(busy)) Then
    // Troubleshooting

End_If;

//     ...
//     ...
```

6 CANopen® STX API

```
// ...  
End_Task;
```

STX Function CanOpenDownloadSDO

Introduction

Calling up the CanOpenDownloadSDO () function is aimed at accessing a particular object in the Object Directory of the message recipient and the value of the object is specified. Data is exchanged in accordance with the SDO download protocol. Supported transfer types are "segmented" or "block" (more than 4 data bytes) and "expedited" (up to 4 data bytes).

Function Declaration

```
Function CanOpenDownloadSDO (
    CANNo: Int,
    NodeID: Int,
    wIndex: Word,
    SubIndex: Byte,
    DataType: Int,
    DataLength: Int,
    const ref DataAddr,
    ref Busy: Int,
) : Int;
```

Function Parameters

The CanOpenDownloadSDO () function has the following parameters.

Parameter	Description	Value
CANNo	CAN channel number	0 ... CANMAX
NodeID	Node ID of the message recipient	1 ... 127
wIndex	Index number of the object	0 ... 0xFFFF
SubIndex	Sub-index number of the object	0 ... 255
DataType	Type of object to be sent	2 ... 27
DataLength	Volume of data for the global variable DataAddr	
DataAddr	Global variable into which the sent value is to be entered	
Busy	Status of the SDO transmission	

Return Value

The function transfers the following return values to the higher-level program.

Return Value	Description
0	ok
-1	Error when checking parameters
-2	HMI in Stop status (own heartbeat status)
-3	DataType is greater than DataLength
-4	insufficient memory

Parameter CANNo

The value of the CANMAX parameter depends on the device. The following table provides information on this point.

Device	CANMAX
JVM-407	2
BTM 07	2
BTM 012	1 - 2
BTM 011	0
JCM-350	4
JCM-620	2

Parameter DataType

The following data types can be received.

Byte types	CANopen® format	Jetter format
1	CANOPEN_INTEGER8 CANOPEN_UNSIGNED8	Byte
2	CANOPEN_INTEGER16 CANOPEN_UNSIGNED16	Word
3	CANOPEN_INTEGER24 CANOPEN_UNSIGNED24	-
4	CANOPEN_INTEGER32 CANOPEN_UNSIGNED32 CANOPEN_REAL	Int
5	CANOPEN_INTEGER40 CANOPEN_UNSIGNED40	-
6	CANOPEN_INTEGER48 CANOPEN_UNSIGNED48 CANOPEN_TIME_OF_DAY CANOPEN_TIME_DIFFERENCE	-
7	CANOPEN_INTEGER56 CANOPEN_UNSIGNED46	-
8	CANOPEN_INTEGER64 CANOPEN_UNSIGNED64 CANOPEN_REAL64	-
n	CANOPEN_VISIBLE_STRING CANOPEN_OCTET_STRING CANOPEN_UNICODE_STRING CANOPEN_DOMAIN	String

Busy

After calling up the function, the Busy parameter is set to SDOACCESS_INUSE. With an error in transmission, Busy is set to SDOACCESS_ERROR. With a successful transmission, the number of bytes transmitted is returned.

"Busy" Error Codes

With an error in transmission, Busy returns an error code. The following error codes are available:

SDOACCESS_STILLUSED

Another task is communicating with the same node ID.

SDOACCESS_TIMEOUT

The task has been timed out because the device with the node ID is not responding.

If the specified node ID does not respond within 1 second, the timeout code is set

SDOACCESS_ILLCMD

The response to the request is invalid.

SDOACCESS_ABORT

The device with the node ID was aborted.

SDOACCESS_BLKSIZEINV

Communication error with Block Download

SDOACCESS_SYSERROR

General internal error

Macro Definitions

The following macros have been defined in connection with this function:

SDOACCESS_FINISHED (busy)

This macro checks whether communication has finished.

SDOACCESS_ERROR (busy)

This macro checks whether an error has occurred.

Using this Function

```
Result := CanOpenDownloadSDO (  
    0,  
    68,  
    0x1017,  
    0,  
    CANOPEN_WORD,  
    sizeof(var_Heartbeat_time),  
    var_Heartbeat_time,  
    busy);
```

JetSym STX Program

In the following example, the heartbeat time is entered in the CANopen® Object Directory of the device with the addressed node ID.

```
#Include "CanOpen.stxp"

Const
    // CAN no.
    CAN_CONTROLLER_0 = 0;
    // Node ID Node_1
    NodeID_Node_0 = 10;
    // Node ID Node 2
    NodeID_Node_1 = 68;
End_Const;

Var
    busy: Int;
    Heartbeat_time: Int;
    Objectindex: Word;
    Subindex: Byte;
End_Var;

Task main autorun

Var
    SW_Version: String;
End_Var;

SW_Version := 'v4.3.0.2004';

// Initialization CAN 0
CanOpenInit(CAN_CONTROLLER_0, NodeID_Node_0, SW_Version);

// Set device with the node ID NodeID_Node_1 on the CAN bus to
// PREOPERATIONAL status
CanOpenSetCommand(0, CAN_CMD_NMT_Value(NodeID_Node_1,
CAN_CMD_NMT), CAN_NMT_PREOPERATIONAL);

// Change heartbeat time of the addressed device per SDO
Objectindex := 0x1017;
Subindex := 0;
CanOpenDownloadSDO(CAN_CONTROLLER_0, NodeID_Node_1, Objectindex,
Subindex, CANOPEN_WORD, sizeof(Heartbeat_time), Heartbeat_time,
busy);

When SDOACCESS_FINISHED(busy) Continue;

If (SDOACCESS_ERROR(busy)) Then
    // Troubleshooting

End_If;
```

```
// Reset all devices on the CAN bus to OPERATIONAL status
CanOpenSetCommand(CAN_CONTROLLER_0,
CAN_CMD_NMT_Value(CAN_CMD_NMT_ALLNODES, CAN_CMD_NMT),
CAN_NMT_OPERATIONAL);

//      ...
//      ...
//      ...

End_Task;
```

STX Function CanOpenAddPDORx

Introduction

By calling up the CanOpenAddPDORx () function, process data, sent by other CANopen® devices, can be entered on receipt.

Process data are only received if sent by a CANopen® device.

Notes

- The PDO telegram is, however, only then transmitted if the CANopen® devices on the bus have a status of "Operational".
- The smallest time unit for the Event Time is 1 ms.
- The smallest time unit for the Inhibit Time is 1 ms.

Function Declaration

```
Function CanOpenAddPDORx (
    CANNNo: Int,
    CANID: Int,
    BytePos: Int,
    DataType: Int,
    DataLength: Int,
    const ref VarAddr,
    EventTime: Int,
    InhibitTime: Int,
    Paramset: Int,
) : Int;
```

Function Parameters

The CanOpenAddPDORx () function has the following parameters.

Parameter	Description	Value
CANNNo	CAN channel number	0 ... CANMAX
CANID	CAN identifier 11-bit CAN identifier 29-bit	0 ... 0x7FF 0 ... 0x1FFFFFFF
BytePos	Starting position of data to be received	0 ... 7
DataType	Data type of data to be received	2 ... 13, 15 ... 27
DataLength	Volume of data for the global variable VarAddr	
VarAddr	Global variable into which the received value is entered	
EventTime	Time lag between two telegrams (> Inhibit Time)	
InhibitTime	Minimum time lag between two telegrams received (< EventTime)	
Paramset	Parameter bit-coded	

Return Value

The function transfers the following return values to the higher-level program.

Return Value

0	ok
-1	Error when checking parameters
-3	DataType is greater than DataLength
-4	insufficient memory

Parameter CANNb

The value of the CANMAX parameter depends on the device. The following table provides information on this point.

Device	CANMAX
JVM-407	2
BTM 07	2
BTM 012	1 - 2
BTM 011	0
JCM-350	4
JCM-620	2

Parameter CANID

The CANID parameter is used to transfer the CAN identifier. The CAN identifier is generated with a macro. The CAN identifier depends on the node ID of the other communicating user and on whether it is a PDO1, PDO2, PDO3 or PDO4 message.

Macro definitions:

```
#Define CANOPEN_PDO1_RX (NodeID) ((NodeID) + 0x180)
#Define CANOPEN_PDO2_RX (NodeID) ((NodeID) + 0x280)
#Define CANOPEN_PDO3_RX (NodeID) ((NodeID) + 0x380)
#Define CANOPEN_PDO4_RX (NodeID) ((NodeID) + 0x480)

#Define CANOPEN_PDO1_TX (NodeID) ((NodeID) + 0x200)
#Define CANOPEN_PDO2_TX (NodeID) ((NodeID) + 0x300)
#Define CANOPEN_PDO3_TX (NodeID) ((NodeID) + 0x400)
#Define CANOPEN_PDO4_TX (NodeID) ((NodeID) + 0x500)
```

Example for calling up the macro:

CANOPEN_PDO2_RX (64)

⇒ The resulting CAN identifier is: 2C0h = 40h + 280h

Default CAN Identifier Distribution

For CANopen® the following CAN identifier distribution is predefined. In this case, the node number is embedded in the identifier.

11-bit identifier (binary)	Identifier (decimal)	Identifier (hexadecimal)	Function
000000000000	0	0	Network Management
000100000000	128	80h	Synchronization
0001xxxxxxx	129 - 255	81h - FFh	Emergency
0011xxxxxxx	385 - 511	181h - 1FFh	PDO1 (tx)
0100xxxxxxx	513 - 639	201h - 27Fh	PDO1 (rx)
0101xxxxxxx	641 - 767	281h - 2FFh	PDO2 (tx)
0110xxxxxxx	769 - 895	301h - 37Fh	PDO2 (rx)
0111xxxxxxx	897 - 1023	381h - 3FFh	PDO3 (tx)
1000xxxxxxx	1025 - 1151	401h - 47Fh	PDO3 (rx)
1001xxxxxxx	1153 - 1279	481h - 4FFh	PDO4 (tx)
1010xxxxxxx	1281 - 1407	501h - 57Fh	PDO4 (rx)
1011xxxxxxx	1409 - 1535	581h - 5FFh	Send SDO
1100xxxxxxx	1537 - 1663	601h - 67Fh	Receive SDO
1110xxxxxxx	1793 - 1919	701h - 77Fh	NMT Error Control
xxxxxxx = Node number 1 - 127			

Parameter DataType

The following data types can be received.

Byte types	CANopen® format	Jetter format
1	CANOPEN_INTEGER8 CANOPEN_UNSIGNED8	Byte
2	CANOPEN_INTEGER16 CANOPEN_UNSIGNED16	Word
3	CANOPEN_INTEGER24 CANOPEN_UNSIGNED24	-
4	CANOPEN_INTEGER32 CANOPEN_UNSIGNED32 CANOPEN_REAL	Int
5	CANOPEN_INTEGER40 CANOPEN_UNSIGNED40	-
6	CANOPEN_INTEGER48 CANOPEN_UNSIGNED48 CANOPEN_TIME_OF_DAY CANOPEN_TIME_DIFFERENCE	-
7	CANOPEN_INTEGER56 CANOPEN_UNSIGNED46	-

Byte types	CANopen® format	Jetter format
1	CANOPEN_INTEGER8 CANOPEN_UNSIGNED8	Byte
8	CANOPEN_INTEGER64 CANOPEN_UNSIGNED64 CANOPEN_REAL64	-
n	CANOPEN_VISIBLE_STRING CANOPEN_OCTET_STRING CANOPEN_UNICODE_STRING CANOPEN_DOMAIN	String

Parameter Paramset

The following parameters can be transferred to the function. Several parameters can be linked together using the Or function.

CANOPEN_ASYNCPDORTRONLY

Receive asynchronous PDOs by sending an RTR frame (after expired EventTime) to the sender.

CANOPEN_ASYNCPDO

Receive asynchronous PDOs.

CANOPEN_PDINVALID

PDO not received. Disk space is reserved.

CANOPEN_NORTR

PDO cannot be requested by RTR (Remote Request).

CANOPEN_29BIT

Use 29-bit identifier


Default: 11-bit identifier

Using this Function

```
Result := CanOpenAddPDORx (
    0,
    662,
    0,
    CANOPEN_DWORD,
    sizeof(var_Data_1_of_Node_1),
    var_Data_1_of_Node_1,
    1000,
    10,
    CANOPEN_ASYNCPDO | CANOPEN_NORTR);
```

JetSym STX Program

JVM-407 with node ID 10 wants to receive a PDO from two CANopen® devices with node ID 64 and 102. The function CanOpenAddPDORx () is called up for this purpose. After running the program, the JVM-407 receives the cyclic PDO telegrams.



```
#Include "CanOpen.stxp"
```

```
Const
```

```
    // CAN no.
    CAN_CONTROLLER_0 = 0;
    // Node ID Node_1
    NodeID_Node_0 = 10;
    // Node ID Node 2
    NodeID_Node_1 = 64;
    // Node ID Node 3
    NodeID_Node_2 = 102;
    // Event_Time in ms
    Event_Time = 1000;
    // Inhibit time in ms
    Inhibit_Time = 10;
```

```
End_Const;
```

```
Var
```

```
    Data_1_of_Node_1: Int;
    Data_2_of_Node_1: Int;
    Data_1_of_Node_2: Int;
```

```
End_Var;
```

```
Task main autorun
```

```
Var
```



```
        SW_Version: String;
End_Var;

SW_Version := 'v4.3.0.2004';

// Initialization CAN 0
CanOpenInit(CAN_CONTROLLER_0, NodeID_Node_0, SW_Version);

// Enter process data on receipt
CanOpenAddPDORx(CAN_CONTROLLER_0,
CANOPEN_PDO2_RX(NodeID_Node_1), 0, CANOPEN_DWORD,
sizeof(Data_1_of_Node_1), Data_1_of_Node_1, Event_Time,
Inhibit_Time, CANOPEN_ASYNCPDORTRONLY | CANOPEN_NORTR);
CanOpenAddPDORx(CAN_CONTROLLER_0,
CANOPEN_PDO2_RX(NodeID_Node_1), 4, CANOPEN_DWORD,
sizeof(Data_2_of_Node_1), Data_2_of_Node_1, Event_Time,
Inhibit_Time, CANOPEN_ASYNCPDORTRONLY | CANOPEN_NORTR);
CanOpenAddPDORx(CAN_CONTROLLER_0,
CANOPEN_PDO3_RX(NodeID_Node_2), 0, CANOPEN_BYTE,
sizeof(Data_1_of_Node_2), Data_1_of_Node_2, Event_Time,
Inhibit_Time, CANOPEN_ASYNCPDO | CANOPEN_NORTR);

// All devices on the CAN bus have the status of PREOPERATIONAL
// Setting all devices on the CAN bus to OPERATIONAL status
CanOpenSetCommand(CAN_CONTROLLER_0,
CAN_CMD_NMT_Value(CAN_CMD_NMT_ALLNODES, CAN_CMD_NMT),
CAN_NMT_START);

//As from now, PDO telegrams will be transmitted.
//      ...
//      ...
//      ...

End_Task;
```

STX Function CanOpenAddPDOTx

Introduction

By calling up the CanOpenAddPDOTx () function, process data can be deposited on the bus.

However, that should not mean that other CANopen® devices on the bus can also read this process data.

Notes

- The PDO telegram is, however, only then transmitted if the CANopen® devices on the bus have a status of "Operational".
- As soon as there are any changes to the process data, another PDO telegram is transmitted immediately.
- The smallest time unit for the Event Time is 1 ms.
- The smallest time unit for the Inhibit Time is 1 ms.
- Any unused bytes of a telegram are sent as null.

Function Declaration

```
Function CanOpenAddPDOTx (
    CANNNo: Int,
    CANID: Int,
    BytePos: Int,
    DataType: Int,
    DataLength: Int,
    const ref VarAddr,
    EventTime: Int,
    InhibitTime: Int,
    Paramset: Int,
) : Int;
```

Function Parameters

The CanOpenAddPDOTx () function has the following parameters.

Parameter	Description	Value
CANNNo	CAN channel number	0 ... CANMAX
CANID	CAN identifier 11-bit CAN identifier 29-bit	0 ... 0x7FF 0 ... 0x1FFFFFFF
BytePos	Starting position of data to be sent	0 ... 7
DataType	Data type of data to be sent	2 ... 13, 15 ... 27
DataLength	Volume of data for the global variable VarAddr	
VarAddr	Global variable into which the value to be sent is entered	
EventTime	Time lag between two telegrams (> Inhibit Time)	
InhibitTime	Minimum time lag between two telegrams sent (< EventTime)	
Paramset	Parameter bit-coded	

Return Value

The function transfers the following return values to the higher-level program.

Return Value

0	ok
-1	Error when checking parameters
-3	DataType is greater than DataLength
-4	insufficient memory

Parameter CANNo

The value of the CANMAX parameter depends on the device. The following table provides information on this point.

Device	CANMAX
JVM-407	2
BTM 07	2
BTM 012	1 - 2
BTM 011	0
JCM-350	4
JCM-620	2

Parameter CANID

The CANID parameter is used to transfer the CAN identifier. The CAN identifier is generated with a macro. The CAN identifier depends on the node ID of the other communicating user and on whether it is a PDO1, PDO2, PDO3 or PDO4 message.

Macro definitions:

```
#Define CANOPEN_PDO1_RX (NodeID) ((NodeID) + 0x180)
#Define CANOPEN_PDO2_RX (NodeID) ((NodeID) + 0x280)
#Define CANOPEN_PDO3_RX (NodeID) ((NodeID) + 0x380)
#Define CANOPEN_PDO4_RX (NodeID) ((NodeID) + 0x480)

#Define CANOPEN_PDO1_TX (NodeID) ((NodeID) + 0x200)
#Define CANOPEN_PDO2_TX (NodeID) ((NodeID) + 0x300)
#Define CANOPEN_PDO3_TX (NodeID) ((NodeID) + 0x400)
#Define CANOPEN_PDO4_TX (NodeID) ((NodeID) + 0x500)
```

Example for calling up the macro:

CANOPEN_PDO2_RX (64)

⇒ The resulting CAN identifier is: 2C0h = 40h + 280h

Default CAN Identifier Distribution

For CANopen® the following CAN identifier distribution is predefined. In this case, the node number is embedded in the identifier.

11-bit identifier (binary)	Identifier (decimal)	Identifier (hexadecimal)	Function
000000000000	0	0	Network Management
000100000000	128	80h	Synchronization
0001xxxxxxx	129 - 255	81h - FFh	Emergency
0011xxxxxxx	385 - 511	181h - 1FFh	PDO1 (tx)
0100xxxxxxx	513 - 639	201h - 27Fh	PDO1 (rx)
0101xxxxxxx	641 - 767	281h - 2FFh	PDO2 (tx)
0110xxxxxxx	769 - 895	301h - 37Fh	PDO2 (rx)
0111xxxxxxx	897 - 1023	381h - 3FFh	PDO3 (tx)
1000xxxxxxx	1025 - 1151	401h - 47Fh	PDO3 (rx)
1001xxxxxxx	1153 - 1279	481h - 4FFh	PDO4 (tx)
1010xxxxxxx	1281 - 1407	501h - 57Fh	PDO4 (rx)
1011xxxxxxx	1409 - 1535	581h - 5FFh	Send SDO
1100xxxxxxx	1537 - 1663	601h - 67Fh	Receive SDO
1110xxxxxxx	1793 - 1919	701h - 77Fh	NMT Error Control
xxxxxxx = Node number 1 - 127			

Parameter DataType

The following data types can be received.

Byte types	CANopen® format	Jetter format
1	CANOPEN_INTEGER8 CANOPEN_UNSIGNED8	Byte
2	CANOPEN_INTEGER16 CANOPEN_UNSIGNED16	Word
3	CANOPEN_INTEGER24 CANOPEN_UNSIGNED24	-
4	CANOPEN_INTEGER32 CANOPEN_UNSIGNED32 CANOPEN_REAL	Int
5	CANOPEN_INTEGER40 CANOPEN_UNSIGNED40	-
6	CANOPEN_INTEGER48 CANOPEN_UNSIGNED48 CANOPEN_TIME_OF_DAY CANOPEN_TIME_DIFFERENCE	-
7	CANOPEN_INTEGER56 CANOPEN_UNSIGNED46	-

Byte types	CANopen® format	Jetter format
1	CANOPEN_INTEGER8 CANOPEN_UNSIGNED8	Byte
8	CANOPEN_INTEGER64 CANOPEN_UNSIGNED64 CANOPEN_REAL64	-
n	CANOPEN_VISIBLE_STRING CANOPEN_OCTET_STRING CANOPEN_UNICODE_STRING CANOPEN_DOMAIN	String

Parameter Paramset

The following parameters can be transferred to the function. Several parameters can be linked together using the Or function.

CANOPEN_ASYNCPDORTRONLY

Send asynchronous PDOs by receiving an RTR frame.

CANOPEN_ASYNCPDO

Send asynchronous PDO.

CANOPEN_PDINVALID

PDO not sent.

CANOPEN_NORTR

PDO cannot be requested by RTR (Remote Request).

CANOPEN_29BIT

Use 29-bit identifier


Default: 11-bit identifier

Using this Function

```
Result := CanOpenAddPDOTx (
    0,
    842,
    0,
    CANOPEN_DWORD,
    sizeof(var_Data_1_of_Node_3),
    var_Data_1_of_Node_3,
    1000,
    100,
    CANOPEN_ASYNCPDO | CANOPEN_NORTR);
```

JetSym STX Program

JVM-407 sends process data to two CANopen® devices with the node ID 74 and 112. After running the program and for changes, the JVM-407 sends cyclic PDO telegrams every 3,000 ms (Event Time). As a maximum, the PDO telegram is sent every 10 ms (Inhibit Time).



```
#Include "CanOpen.stxp"

Const
    // CAN no.
    CAN_CONTROLLER_0 = 0;
    // Node ID Node_1
    NodeID_Node_0 = 10;
    // Node ID Node 4
    NodeID_Node_1 = 74;
    // Node ID Node 5
    NodeID_Node_2 = 112;
    // Event_Time in ms
    Event_Time = 3000;
    // Inhibit time in ms
    Inhibit_Time = 100;
End_Const;

Var
    Data_1_of_Node_1: Int;
    Data_2_of_Node_1: Int;
    Data_1_of_Node_2: Byte;
End_Var;

Task main autorun

Var
    SW_Version: String;
End_Var;

SW_Version := 'v4.3.0.2004';
```

```
// Initialization CAN 0
CanOpenInit(CAN_CONTROLLER_0, NodeID_Node_0, SW_Version);

// Send data per PDO
CanOpenAddPDOTx(CAN_CONTROLLER_0,
CANOPEN_PDO2_TX(NodeID_Node_1), 0, CANOPEN_DWORD,
sizeof(Data_1_of_Node_1), Data_1_of_Node_1, Event_Time,
Inhibit_Time, CANOPEN_ASYNC_PDORTRONLY | CANOPEN_NORTR);
CanOpenAddPDOTx(CAN_CONTROLLER_0,
CANOPEN_PDO2_TX(NodeID_Node_1), 4, CANOPEN_DWORD,
sizeof(Data_2_of_Node_1), Data_2_of_Node_1, Event_Time,
Inhibit_Time, CANOPEN_ASYNC_PDORTRONLY | CANOPEN_NORTR);
CanOpenAddPDOTx(CAN_CONTROLLER_0,
CANOPEN_PDO3_TX(NodeID_Node_2), 0, CANOPEN_BYTE,
sizeof(Data_1_of_Node_2), Data_1_of_Node_2, Event_Time,
Inhibit_Time, CANOPEN_ASYNC_PDO | CANOPEN_NORTR);

// All devices on the CAN bus have the status of PREOPERATIONAL
// Set all devices on the CAN bus to OPERATIONAL status
CanOpenSetCommand(CAN_CONTROLLER_0,
CAN_CMD_NMT_Value(CAN_CMD_NMT_ALLNODES, CAN_CMD_NMT),
CAN_NMT_START);

//As from now, PDO telegrams will be transmitted.
//      ...
//      ...
//      ...

End_Task;
```

CANopen® Object Directory for JVM-407

Supported Objects

The following objects are supported by the operating system for JVM-407:

Index (hex)	Object (code)	Object name	Type	Attribute
1000	VAR	Device Type	Unsigned32	ro
1001	VAR	Error Register	Unsigned8	ro
1002	VAR	Manufacturer Status	Unsigned32	ro
1003	ARRAY	Pre-defined Error Field	Unsigned32	ro
1008	VAR	Manufacturer Device Name	String	const
1009	VAR	Manufacturer Hardware Version	String	const
100A	VAR	Manufacturer Software Version	String	const
100B	VAR	Node ID	Unsigned32	ro
1017	VAR	Producer Heartbeat Time	Unsigned16	rw
1018	RECORD	Identity	Identity	ro
1200	RECORD	Server 1 - SDO Parameter	SDO Parameter	ro
1201	RECORD	Server 2 - SDO Parameter	SDO Parameter	rw
1203	RECORD	Server 3 - SDO Parameter	SDO Parameter	rw
1203	RECORD	Server 4 - SDO Parameter	SDO Parameter	rw

Device Type Object (Index 0x1000)

The structure of the "Device Type Object" is shown in the following table.

Index	Sub-Index	Default	Description
0x1000	0	0x0000012D	Device Type (Read-Only)

Error Register Object (Index 0x1001)

The structure of the "Error Register Object" is shown in the following table.

Index	Sub-Index	Default	Description
0x1001	0	0	Error Register (Read-Only)

This object implements the CANopen® Error Register functionality.

Bit 0 – Generic Errors

None of the other bits are currently in use.

Pre-defined Error Field Object (Index 0x1003)

The structure of the "Pre-defined Error Field Object" is shown in the following table.

Index	Sub-Index	Default	Description
0x1003	0	0	Number of errors entered in the Array's Standard Error Field
	1	0	Most recent error 0 indicates no error
	2 ... 254	-	Earlier Errors

This object shows a history list of errors that have been detected by the JVM-407. The maximum length of the list is 254 errors. The list content is deleted on restart.

Composition of the Standard Error Field

2-byte LSB: Error Code

2-byte MSB: Additional information

Manufacturer Device Name Object (Index 0x1008)

The structure of the "Manufacturer Device Name Object" is shown in the following table.

Index	Sub-Index	Default	Description
0x1008	0	JVM-407	Hardware name

Manufacturer Hardware Version Object (Index 0x1009)

The structure of the "Manufacturer Hardware Version Object" is shown in the following table.

Index	Sub-Index	Default	Description
0x1009	0		OS version of the device

Manufacturer Software Version Object (Index 0x100A)

The structure of the "Manufacturer Software Version Object" is shown in the following table.

Index	Sub-Index	Default	Description
0x100A	0		Software version of the application program that runs on the JVM-407

The entry in this index is made via the parameter "SWVersion" of the STX function CanOpenInit ().

Node ID Object (Index 0x100B)

The structure of the "Node ID Object" is shown in the following table.

Index	Sub-Index	Default	Description
0x100B	0		Own Node ID

Producer Heartbeat Time Object (Index 0x1017)

The structure of the "Producer Heartbeat Time Object" is shown in the following table.

Index	Sub-Index	Default	Description
0x1017	0	1,000 [ms]	Heartbeat time

7 SAE J1939 STX API

Introduction	This chapter describes the STX functions of the SAE J1939 STX API.
The SAE J1939 Standard	SAE J1939 is an open standard for networking and communication in the commercial vehicle sector. The focal point of the application is the networking of the power train and chassis. The J1939 protocol originates from the international Society of Automotive Engineers (SAE) and works on the physical layer with CAN high-speed according to ISO 11898.
Application	These STX functions are used in communication between the controller JVM-407 and other ECUs in the vehicle. As a rule, engine data e.g. rpm, speed or coolant temperature are read and displayed.
Documentation	<p>The key SAE J1939 specifications are:</p> <ul style="list-style-type: none"> ▪ J1939-11 - Information on the physical layer ▪ J1939-21 - Information on the data link layer ▪ J1939-71 - Information on the application layer vehicles ▪ J1939-73 - Information on the application layer range analysis ▪ J1939-81 - Network management


Contents

Topic	Page
Content of a J1939 Message.....	124
STX Function SAEJ1939Init.....	126
STX Function SAEJ1939SetSA.....	128
STX Function SAEJ1939GetSA.....	129
STX Function SAEJ1939AddRx.....	130
STX Function SAEJ1939AddTx.....	134
STX Function SAEJ1939RequestPGN.....	138
STX Function SAEJ1939GetDM1.....	141
STX Function SAEJ1939GetDM2.....	144
STX Function SAEJ1939SetSPNConversion.....	147
STX Function SAEJ1939GetSPNConversion.....	149

Content of a J1939 Message

Content of a J1939 Message

The following diagram shows the content of a J1939 message:



Abbreviation	Description
DA	Destination Address
GE	Group Extensions
PDU	Protocol Data Unit
PGN	Parameter Group Number
SA	Source Address

Meaning of the Parameter Group Number (PGN)

The PGN is a number defined in the SAE J1939 standard that groups together several SPNs into a meaningful group. The PGN is part of the CAN identifier. The 8-byte data (PDU) contain the values of individual SPNs.

The example below shows a PGN 65262 (0xFEEE):

PGN 65262	Engine Temperature 1	- ET1
Part of the PGN	Value	Remarks
Transmission Repetition Rate	1 s	
Data Length	8	
Extended Data Page	0	
Data Page	0	
PDU Format	254	
PDU Specific	238	PGN Supporting Information
Default Priority	6	
Parameter Group Number	65262	in hex: 0xFEEE

Start position	Length	Parameter name	SPN
1	1 byte	Engine Coolant Temperature	110
2	1 byte	Engine Fuel Temperature 1	174
3 - 4	2 bytes	Engine Oil Temperature 1	175
5 - 6	2 bytes	Engine Turbocharger Oil Temperature	176
7	1 byte	Engine Intercooler Temperature	52
8	1 byte	Engine Intercooler Thermostat Opening	1134

STX Function SAEJ1939Init

Introduction

Calling up the SAEJ1939Init () function initializes one of the CAN busses (not CAN 0 as this is reserved for CANopen®) available for the J1939 protocol. From then on, the JVM-407 has the SA (Source Address) assigned by the function parameter mySA. It thus has its own device address on the bus.

Function Declaration

```
Function SAEJ1939Init (
    CANNo: Int,
    mySA: Byte,
) : Int;
```

Function Parameters

The function SAEJ1939Init () has the following parameters.

Parameter	Description	Value
CANNo	CAN channel number	1 ... CANMAX
mySA	Own source address	0 ... 253

Return Value

This function transfers the following return values to the higher-level program.

Return Value

0	OK
-1	Error when checking parameters
-3	Insufficient memory for SAE J1939

Parameter CANNo

The value of the CANMAX parameter depends on the device. The following table provides information on this point.

Device	CANMAX
JVM-407	2
BTM 07	2
BTM 012	1 - 2
BTM 011	n/a
JCM-350	4
JCM-620	2

Using this Function

Initializing the CAN-Bus 1. The JVM-407 has Node-SA 20 (0x14).

The JVM-407 can now send messages with the set SA (and only these messages).

```
Result := SAEJ1939Init(1, 20);
```

Address Claiming

Address Claiming has not been implemented.

STX Function SAEJ1939SetSA

Introduction Calling up the function SAEJ1939SetSA changes the own SA (Source Address) during runtime.

Function Declaration

```
Function SAEJ1939SetSA (
    CANNo: Int,
    mySA: Byte,
) : Int;
```

Function Parameters The function SAEJ1939SetSA () has the following parameters.

Parameter	Description	Value
CANNo	CAN channel number	1 ... CANMAX
mySA	New SA	0 ... 253

Return Value The function transfers the following return values to the higher-level program.

Return Value

0	ok
-1	Error when checking parameters

Parameter CANNo The value of the CANMAX parameter depends on the device. The following table provides information on this point.

Device	CANMAX
JVM-407	2
BTM 07	2
BTM 012	1 - 2
BTM 011	n/a
JCM-350	4
JCM-620	2

Using this Function The SA is changed during runtime.

```
Result := SAEJ1939SetSA(1, 20);
```

Important Note Messages are immediately sent/received with the new SA.

STX Function SAEJ1939GetSA

Introduction

By calling up the function SAEJ1939GetSA, you can determine the own SA (Source Address).

Function Declaration

```
Function SAEJ1939GetSA (
    CANNNo:Int,
    ref mySA:Byte,
) :Int;
```

Function Parameters

The function SAEJ1939GetSA () has the following parameters.

Parameter	Description	Value
CANNNo	CAN channel number	1 ... CANMAX
mySA	SA currently set	0 ... 253

Return Value

The function transfers the following return values to the higher-level program.

Return Value

0	ok
-1	Error when checking parameters

Parameter CANNNo

The value of the CANMAX parameter depends on the device. The following table provides information on this point.

Device	CANMAX
JVM-407	2
BTM 07	2
BTM 012	1 - 2
BTM 011	n/a
JCM-350	4
JCM-620	2

Using this Function

This function returns the currently set SA.

```
Result := SAEJ1939SetSA(1, actual_SA);
```

STX Function SAEJ1939AddRx

Introduction

Calling up the function SAEJ1939AddRx () prompts the JVM-407 to receive a specific message. This message is sent from another bus node. The address of this bus node is transferred to this function as a bySA parameter. If the message is not sent, the value received last remains valid. Cyclical reading continues until the function SAEJ1939Init () is called up again.

Function Declaration

```
Function SAEJ1939AddRx (
    CANNNo: Int,
    IPGN: Long,
    bySA: Byte,
    BytePos: Int,
    BitPos: Int,
    DataType: Int,
    DataLength: Int,
    const ref VarAddr,
    ref stJ1939: TJ1939Rx
    EventTime: Int,
    InhibitTime: Int,
) : Int;
```

Function Parameters

The function SAEJ1939AddRx () has the following parameters.

Parameter	Description	Value
CANNNo	CAN channel number	1 ... CANMAX
IPGN	PGN Parameter Group Number	0 ... 0x3FFFF
bySA	Source Address of message sender	0 ... 253
BytePos	Starting position of bytes of data to be received	1 ... n
BitPos	Starting position of bits of data to be received	1 ... 8
DataType	Data type of data to be received	1 ... 3, 10 ... 16
DataLength	Volume of data for the global variable VarAddr	
VarAddr	Global variable into which the received value is entered	
TJ1939Rx	Control structure	
EventTime	Time lag between two telegrams (> Inhibit Time)	Default Value: 1,000 ms
InhibitTime	Minimum time lag between two telegrams received (< EventTime)	Default Value: 100 ms

Return Value

The function transfers the following return values to the higher-level program.

Return Value

0	ok
-1	Error when checking parameters

Parameter CANNo

The value of the CANMAX parameter depends on the device. The following table provides information on this point.

Device	CANMAX
JVM-407	2
BTM 07	2
BTM 012	1 - 2
BTM 011	n/a
JCM-350	4
JCM-620	2

Parameter DataType

Data types can include the following.

Byte types	Bit types	SAEJ1939
1	-	SAEJ1939_UNSIGNED8 SAEJ1939_BYTE
2	-	SAEJ1939_UNSIGNED16 SAEJ1939_WORD
4	-	SAEJ1939_UNSIGNED32 SAEJ1939_DWORD
n	-	SAEJ1939_STRING
-	1	SAEJ1939_1BIT
-	2	SAEJ1939_2BIT
-	3	SAEJ1939_3BIT
-	4	SAEJ1939_4BIT
-	5	SAEJ1939_5BIT
-	6	SAEJ1939_6BIT
-	7	SAEJ1939_7BIT

**Control Structure
TJ1939Rx**

```
TJ1939Rx: Struct
// Status of received message
    byStatus      : Byte;
// Priority of received message
    byPriority     : Byte;
End_Struct;
```

Using this Function

```
Result := SAEJ1939AddrRx (  
    1,  
    0xFEEE,  
    0x00,  
    2  
    0  
    SAEJ1939_BYTE,  
    sizeof(var_Fueltemp),  
    var_Fueltemp,  
    struct_TJ1939Rx_EngineTemperatureTbl,  
    1500,  
    120);
```

JetSym STX Program

The device JVM-407 with the own SA of 20 wants to receive and display the current fuel temperature. The parameters InhibitTime and EventTime are not explicitly specified when calling up the function. In this case, the default values are used. The controller that measures the fuel temperature has the SA of 0. In practice, the address of the controller can be found in the engine manufacturer's documentation.

The fuel temperature has the SPN 174 and is a component (byte 2) of the PGN 65262 Engine Temperature 1.

```
#Include "SAEJ1939.stxp"  
  
Var  
    bySAEJ1939Channel : Byte;  
    own_Source_Address : Byte;  
  
// PGN 65262 Engine Temperature 1  
    Fueltemp : Byte;  
    EngineTemperatureTbl : TJ1939Rx;  
End_Var;  
  
Task main autorun  
  
// Initializing CAN 1  
bySAEJ1939Channel := 1;  
own_Source_Address := 20;  
SAEJ1939Init (bySAEJ1939Channel, own_Source_Address);  
  
// Receive fuel temperature  
SAEJ1939AddrRx (bySAEJ1939Channel, 65262, 0x00, 2, 1, SAEJ1939_BYTE,  
    sizeof(Fueltemp), Fueltemp, EngineTemperatureTbl);  
  
End_Task;
```

**Engine Manufacturer's
Manual**

For information on the data (priority, PGN, SA and data byte structure) refer to the manual provided by the engine manufacturer.

STX Function SAEJ1939AddTx

Introduction

Calling up the function SAEJ1939AddTx () prompts the device JVM-407 to cyclically send a specific message via the bus.

Cyclical sending continues until the function SAEJ1939Init () is called up again.

Data are sent once the Event Time has elapsed or the given variables have changed and Inhibit Time has elapsed.

Function Declaration

```
Function SAEJ1939AddTx (
    CANNo: Int,
    IPGN: Long,
    BytePos: Int,
    BitPos: Int,
    dataType: Int,
    DataLength: Int,
    const ref VarAddr,
    ref stJ1939: TJ1939Tx
    EventTime: Int,
    InhibitTime: Int,
) : Int;
```

Function Parameters

The function SAEJ1939AddTx () has the following parameters.

Parameter	Description	Value
CANNo	CAN channel number	1 ... CANMAX
IPGN	PGN Parameter Group Number	0 ... 0x3FFFF
BytePos	Starting position of the byte of data to be sent	1 ... n
BitPos	Starting position of the bit of data to be sent	1 ... 8
DataType	Data type of data to be sent	1 ... 3, 10 ... 16
DataLength	Volume of data for the global variable VarAddr	
VarAddr	Global variable into which the value to be sent is entered	
TJ1939Tx	Control structure	
EventTime	Time lag between two telegrams (> Inhibit Time)	Default Value: 1,000 ms
InhibitTime	Minimum time lag between two telegrams received (< EventTime)	Default Value: 100 ms

Return Value

The function transfers the following return values to the higher-level program.

Return Value	
0	ok
-1	Error when checking parameters

Parameter CANN0

The value of the CANMAX parameter depends on the device. The following table provides information on this point.

Device	CANMAX
JVM-407	2
BTM 07	2
BTM 012	1 - 2
BTM 011	n/a
JCM-350	4
JCM-620	2

Parameter DataType

Data types can include the following.

Byte types	Bit types	SAEJ1939
1	-	SAEJ1939_UNSIGNED8 SAEJ1939_BYTE
2	-	SAEJ1939_UNSIGNED16 SAEJ1939_WORD
4	-	SAEJ1939_UNSIGNED32 SAEJ1939_DWORD
n	-	SAEJ1939_STRING
-	1	SAEJ1939_1BIT
-	2	SAEJ1939_2BIT
-	3	SAEJ1939_3BIT
-	4	SAEJ1939_4BIT
-	5	SAEJ1939_5BIT
-	6	SAEJ1939_6BIT
-	7	SAEJ1939_7BIT

Control Structure TJ1939Tx

```
TJ1939Tx : Struct
// Status of sent message
    byStatus      : Byte;
// Priority of sent message
    byPriority     : Byte;
End_Struct;
```

Using this Function

```
Result := SAEJ1939AddTx (
    1,
    0xFEEE,
    0x00,
    2
    0
    SAEJ1939_BYTE,
    sizeof(var_Fueltemp),
    var_Fueltemp,
    struct_TJ1939Tx_EngineTemperatureTbl,
    1500,
    120);
```

JetSym STX Program

Redefining the priority: Priority value 0 has the highest priority, priority value 7 has the lowest priority. A message with priority 6 can be superseded by a message with priority 4 (if the messages are sent at the same time). The parameters InhibitTime and EventTime are not explicitly specified when calling up the function. In this case, the default values are used.

```
#Include "SAEJ1939.stxp"

Var
    bySAEJ1939Channel : Byte;
    own_Source_Address : Byte;

// PGN 65262 Engine Temperature 1
    Fueltemp : Byte;
    EngineTemperatureTbl : TJ1939Tx;
End_Var;

Task main autorun

// Initializing CAN 1
bySAEJ1939Channel := 1;
own_Source_Address := 20;
SAEJ1939Init (bySAEJ1939Channel, own_Source_Address);

// PGN 65262 Engine Temperature
// Set a new priority
EngineTemperatureTbl.byPriority := 6;
SAEJ1939AddTx (bySAEJ1939Channel, 65262, 0x00, 2, 1, SAEJ1939_BYTE,
sizeof(Fueltemp), Fueltemp, EngineTemperatureTbl);

End_Task;
```


**Engine Manufacturer's
Manual**

For information on the data (priority, PGN, SA and data byte structure) refer to the manual provided by the engine manufacturer.

STX Function SAEJ1939RequestPGN

Introduction

Calling up the function SAEJ1939RequestPGN () sends a request to the DA (Destination Address) following a PGN.

This function is not terminated until a valid value has been received or the timeout of 1,250 ms has elapsed.

To obtain the value of the requested message its receipt must be scheduled using the function SAEJ1939AddRx ().

This function must be constantly recalled in cycles.

Function Declaration

```
Function SAEJ1939RequestPGN (
    CANNNo: Int,
    byDA: Byte,
    ulPGN: Long,
    byPriority: Byte,
) : Int;
```

Function Parameters

The function SAEJ1939RequestPGN () has the following parameters.

Parameter	Description	Value
CANNNo	CAN channel number	1 ... CANMAX
byDA	Destination Address Address from which the message is requested	0 ... 253 The own SA cannot be used
ulPGN	PGN Parameter Group Number	0 ... 0x3FFFF
byPriority	Priority	0 ... 7 Default Value: 6

Return Value

This function transfers the following return values to the higher-level program.

Return Value

0	Message has been received
-1	Timeout, as no reply has been received

Parameter CANNNo

The value of the CANMAX parameter depends on the device. The following table provides information on this point.

Device	CANMAX
JVM-407	2
BTM 07	2
BTM 012	1 - 2
BTM 011	n/a
JCM-350	4
JCM-620	2

Parameter DataType

Data types can include the following.

Byte types	Bit types	SAEJ1939
1	-	SAEJ1939_UNSIGNED8 SAEJ1939_BYTE
2	-	SAEJ1939_UNSIGNED16 SAEJ1939_WORD
4	-	SAEJ1939_UNSIGNED32 SAEJ1939_DWORD
n	-	SAEJ1939_STRING
-	1	SAEJ1939_1BIT
-	2	SAEJ1939_2BIT
-	3	SAEJ1939_3BIT
-	4	SAEJ1939_4BIT
-	5	SAEJ1939_5BIT
-	6	SAEJ1939_6BIT
-	7	SAEJ1939_7BIT

Using this Function

```
Result := SAEJ1939RequestPGN (
    1,
    0x00,
    0xFEE5,
    5);
```

JetSym STX Program

JVM-407 with own SA of 20 wants to request the PGN 65253 "Engine Hours" from an engine control unit with the SA 0. The SPN 247 "Engine Total Hours of Operation" should be read from this PGN. It is therefore necessary to register receipt of the SPN 247 by calling up the function SAEJ1939AddRx ().

The parameter "byPriority" is not explicitly specified when calling up the function. In this case, the default value is used.

```
#Include "SAEJ1939.stxp"

Var
    bySAEJ1939Channel : Byte;
    own_Source_Address : Byte;

// PGN 65253 Engine Hours, Revolutions
    EngineTotalHours : Int;
    EngineHoursTbl : TJ1939Rx;
End_Var;

Task main autorun

// Initializing CAN 1
```

```
bySAEJ1939Channel := 1;
own_Source_Address := 20;
SAEJ1939Init (bySAEJ1939Channel, own_Source_Address);

// Engine Hours, Revolutions -- on Request
SAEJ1939AddrX (bySAEJ1939Channel, 65253, 0x00, 1, 0,
SAEJ1939_DWORD, sizeof(EngineTotalHours), EngineTotalHours,
EngineHoursTbl, 5000, 150);

// Required for a cyclical task
TaskAllEnableCycle ();
EnableEvents;

End_Task;

Task t_RequestPGN_5000 cycle 5000

Var
    Return_value : Int;
End_Var;

// Request total machine operating hours
Return_value := SAEJ1939RequestPGN (bySAEJ1939Channel, 0x00,
65253);

If Return_value Then
    Trace ('PGN Request failed');
End_If;

End_Task;
```

STX Function SAEJ1939GetDM1

Introduction

Calling up the function SAEJ1939GetDM1 () requests the current diagnostics error codes (also see SAE J1939-73 No. 5.7.1). The corresponding PGN number is 65226. This function must be constantly recalled in cycles.

Function Declaration

```
Function SAEJ1939GetDM1 (
    CANNo: Int,
    bySA: Byte,
    ref stJ1939DM1stat: TJ1939DM1STAT
    ref stJ1939DM1msg: TJ1939DM1MSG
) : Int;
```

Function Parameters

The function SAEJ1939GetDM1 () has the following parameters.

Parameter	Description	Value
CANNo	CAN channel number	1 ... CANMAX
bySA	Source Address of message sender	0 ... 253 The own SA cannot be used
stJ1939DM1stat	IStatus IMsgCnt IBuffer	Lamp Status Number of received messages Size of variable stJ1939DM1msg
stJ1939DM1msg	ISPN byOC byFMI	Error Code Error counter Error Type

Return Value

The function transfers the following return values to the higher-level program.

Return Value

0	ok
-1	Error when checking parameters

Parameter CANNo

The value of the CANMAX parameter depends on the device. The following table provides information on this point.

Device	CANMAX
JVM-407	2
BTM 07	2
BTM 012	1 - 2
BTM 011	n/a
JCM-350	4

Device	CANMAX
JCM-620	2

stJ1939DM1stat.IStatus**Default:** 0xFF00

Type	Byte	Bit group	Description
Status	1	8 - 7	Malfunction Indicator Lamp Status
		6 - 5	Red Stop Lamp Status
		4 - 3	Amber Warning Lamp Status
		2 - 1	Protect Lamp Status
Flash	2	8 - 7	Flash Malfunction Indicator Lamp
		6 - 5	Flash Red Stop Lamp
		4 - 3	Flash Amber Warning Lamp
		2 - 1	Flash Protect Lamp

Type	Byte	Bit group Value	Description
Status	1	00	Lamps off
		01	Lamps on
Flash	2	00	Slow Flash (1 Hz, 50 % duty cycle)
		01	Fast Flash (2 Hz or faster, 50 % duty cycle)
		10	Reserved
		11	Unavailable / Do Not Flash

stJ1939DM1msg**Default Value:**

ISPN = 0

byOC = 0

byFMI = 0

For older controllers (grandfathered setting):

ISPN = 524287 (0x7FFFF)

byOC = 31 (0x1F)

byFMI = 127 (0x7F)

Using this Function

```
Result := SAEJ1939GetDM1 (
    1,
    0x00,
    stdmlstat_pow,
    stdmlmsg_pow,);
```

JetSym STX Program

By calling up the function SAEJ1939GetDM1 (), the JVM-407 requests the current diagnostics error code (PGN 65226).

```
#Include "SAEJ1939.stxp"

Var
    bySAEJ1939Channel : Byte;
    own_Source_Address : Byte;
    stdmlstat_pow : TJ1939DM1STAT;
    stdmlmsg_pow : Array[10] of STJ1939DM1MSG;
    MyTimer : TTimer;
End_Var;

Task main autorun

// Initializing CAN 1
bySAEJ1939Channel := 1;
own_Source_Address := 20;
SAEJ1939Init (bySAEJ1939Channel, own_Source_Address);

TimerStart (MyTimer, T#2s);

Loop

When (TimerEnd (MyTimer)) Continue;

// Request the diagnostics error codes DM1 POW
stdmlstat_pow.lBuffer := sizeof (stdmlmsg_pow);
SAEJ1939GetDM1 (bySAEJ1939Channel, 0x00, stdmlstat_pow,
stdmlmsg_pow);

TimerStart (MyTimer, T#2s);

End_Loop;

End_Task;
```

STX Function SAEJ1939GetDM2

Introduction

Calling up the function SAEJ1939GetDM2 () requests the diagnostics error codes that preceded the current one (also see SAE J1939-73 No. 5.7.2). The corresponding PGN number is 65227.

Function Declaration

```
Function SAEJ1939GetDM2 (
    CANNNo: Int,
    bySA: Byte,
    ref stJ1939DM2stat: TJ1939DM2STAT
    ref stJ1939DM2msg: TJ1939DM2MSG
) : Int;
```

Function Parameters

The function SAEJ1939GetDM2 () has the following parameters.

Parameter	Description	Value
CANNNo	CAN channel number	1 ... CANMAX
bySA	Source Address of message sender	0 ... 253 The own SA cannot be used
stJ1939DM2stat	IStatus IMsgCnt IBuffer	Lamp Status Number of received messages Size of variable stJ1939DM2msg
stJ1939DM2msg	ISPN byOC byFMI	Error Code Error counter Error Type

Return Value

The function transfers the following return values to the higher-level program.

Return Value

0	ok
-1	Error when checking parameters

Parameter CANNNo

The value of the CANMAX parameter depends on the device. The following table provides information on this point.

Device	CANMAX
JVM-407	2
BTM 07	2
BTM 012	1 - 2
BTM 011	n/a
JCM-350	4

Device	CANMAX
JCM-620	2

stJ1939DM2stat.IStatus**Default:** 0xFF00

Type	Byte	Bit group	Description
Status	1	8 - 7	Malfunction Indicator Lamp Status
		6 - 5	Red Stop Lamp Status
		4 - 3	Amber Warning Lamp Status
		2 - 1	Protect Lamp Status
Flash	2	8 - 7	Flash Malfunction Indicator Lamp
		6 - 5	Flash Red Stop Lamp
		4 - 3	Flash Amber Warning Lamp
		2 - 1	Flash Protect Lamp

Type	Byte	Bit group Value	Description
Status	1	00	Lamps off
		01	Lamps on
Flash	2	00	Slow Flash (1 Hz, 50 % duty cycle)
		01	Fast Flash (2 Hz or faster, 50 % duty cycle)
		10	Reserved
		11	Unavailable / Do Not Flash

stJ1939DM2msg**Default Value:**

ISPN = 0

byOC = 0

byFMI = 0

For older controllers (grandfathered setting):

ISPN = 524287 (0x7FFFF)

byOC = 31 (0x1F)

byFMI = 127 (0x7F)

Using this Function

```
Result := SAEJ1939GetDM2 (
    1,
    0x00,
    stdm2stat_pow,
    stdm2msg_pow,);
```

JetSym STX Program

By calling up the function SAEJ1939GetDM2 (), the JVM-407 requests the current diagnostics error code (PGN 65227).

```
#Include "SAEJ1939.stxp"

Var
    bySAEJ1939Channel : Byte;
    own_Source_Address : Byte;
    stdm2stat_pow : TJ1939DM2STAT;
    stdm2msg_pow : Array[10] of STJ1939DM2MSG;
End_Var;

// Initializing CAN 1
bySAEJ1939Channel := 1;
own_Source_Address := 20;
SAEJ1939Init (bySAEJ1939Channel, own_Source_Address);

// Required for a cyclical task
TaskAllEnableCycle ();
EnableEvents;

End_Task;

Task t_RequestPGN_5000 cycle 5000

Var
    Return_value : Int;
End_Var;

// Request the diagnostics error codes DM2 POW
stdm2stat_pow.lBuffer := sizeof (stdm2msg_pow);
Return_value := SAEJ1939GetDM2 (bySAEJ1939Channel, 0x00,
stdm2stat_pow, stdm2msg_pow);

If Return_value Then
    Trace ('DM2 Request failed');
End_If;

End_Task;
```

STX Function SAEJ1939SetSPNConversion

Introduction

Calling up the function SAEJ1939SetSPNConversion () determines the configuration of bytes in the message, which is requested using function SAEJ1939GetDM1 () or SAEJ1939GetDM2 (). In other words, it specifies the conversion method.

Function Declaration

```
Function SAEJ1939SetSPNConversion (
    CANNo: Int,
    bySA: Byte,
    iConversionMethod: Int,
) : Int;
```

Function Parameters

The function SAEJ1939SetSPNConversion () has the following parameters.

Parameter	Description	Value
CANNo	CAN channel number	1 ... CANMAX
bySA	Source Address of message sender	0 ... 253
iConversionMethod	Conversion method	1 ... 4 4: Automatic detection 2: Default

Return Value

The function transfers the following return values to the higher-level program.

Return Value

0	ok
-1	Error when checking parameters

Parameter CANNo

The value of the CANMAX parameter depends on the device. The following table provides information on this point.

Device	CANMAX
JVM-407	2
BTM 07	2
BTM 012	1 - 2
BTM 011	n/a
JCM-350	4
JCM-620	2

7 SAE J1939 STX API

Using this Function

```
Result := SAEJ1939SetSPNConversion (  
    1,  
    0xAE,  
    4);
```

STX Function SAEJ1939GetSPNConversion

Introduction

Calling up the function SAEJ1939GetSPNConversion () ascertains the current conversion method set.

Function Declaration

```
Function SAEJ1939SetSPNConversion (
    CANNo: Int,
    bySA: Byte,
    iConversionMethod: Int,
) : Int;
```

Function Parameters

The function SAEJ1939GetSPNConversion () has the following parameters.

Parameter	Description	Value
CANNo	CAN channel number	1 ... CANMAX
bySA	Source Address of message sender	0 ... 253
iConversionMethod	Conversion method	1 ... 4 4: Automatic detection 2: Default

Return Value

The function transfers the following return values to the higher-level program.

Return Value

0	ok
-1	Error when checking parameters

Parameter CANNo

The value of the CANMAX parameter depends on the device. The following table provides information on this point.

Device	CANMAX
JVM-407	2
BTM 07	2
BTM 012	1 - 2
BTM 011	n/a
JCM-350	4
JCM-620	2

Using this Function

```
Result := SAEJ1939GetSPNConversion (
    1,
    0xAE,
    actual_conversion_method);
```


8 File System

Introduction

This chapter covers the file system of the HMI JVM-407. The file system enables access to files located on the internal flash disk, SD card or USB stick.

Categories

The file system distinguishes between system area with directories/files used by the operating system (OS), and application area which is available to the user.

System Directories

It is not possible to delete system directories. They will even survive formatting.

Directory	Description
/System	<ul style="list-style-type: none"> ▪ System configuration ▪ System information
/SD	<ul style="list-style-type: none"> ▪ Root directory of the SD card
/USB	<ul style="list-style-type: none"> ▪ Root directory of the USB stick

Contents

Topic	Page
Properties	152
User Administration	156
Reviewing the Flash Disk Capacity Used.....	165
Operating System Update and Application Program.....	169
Formatting and Checking	170

8.1 Properties

Introduction

This chapter covers the properties of the file system. The file system distinguishes between internal flash disk, SD card, and USB stick.

General Properties

The following properties apply to the internal flash disk, SD card, and USB stick:

- Maximum number of simultaneously opened files: 8
 - Directory names are separated by a slash "/", not by a backslash "\".
 - When a file is saved, date and time of the realtime clock of the HMI is assigned to it.
 - Date, time, and/or file size are not available for all system files.
-

Contents

Topic	Page
Flash Disk - Properties.....	153
SD Card - Properties.....	154
USB Stick - Properties	155

Flash Disk - Properties

Available Capacity

The following disk space is available to the user:

Parameter	Value
Flash disk size	13184 KByte

Properties

The internal flash disk has the following properties:

- Up to 7 directory levels and 1 file level is allowed.
 - Directory and file names with a length of up to 63 characters
 - Differentiation between upper and lower case.
 - All characters except "/" and "." are permitted for directory and file names
 - User/access administration for a maximum number of 31 locks and 33 users.
-

SD Card - Properties

Available Capacity

The available capacity depends on the SD card used:

Parameter	Value
Tested size	8 MBytes ... 4 GBytes

Properties

The SD card has the following properties:

- FAT-16 and FAT-32 compatible.
 - The maximum path length is 260 characters.
 - No case sensitivity.
 - The following characters are not allowed in directory and file names: "/", "\", ":", "*", "?", ":", "<", ">" and "|"
 - No user/access administration.
-

USB Stick - Properties

Available Capacity

The available capacity depends on the USB stick used:

Parameter	Value
Tested size	1 GByte ... 8 GBytes

Properties

The USB stick has the following properties:

- FAT-16 and FAT-32 compatible.
 - The maximum path length is 260 characters.
 - No case sensitivity.
 - The following characters are not allowed in directory and file names: "/", "\", ":", "*", "?", ":", "<", ">" and "|"
 - No user/access administration.
-

8.2 User Administration

Introduction

The file system for the internal flash disk offers the possibility to define authorization for access (locks) to directories, as well as to set up users with specific permissions (keys).

Users are not allowed to access directories and files for which they do not have the required key. In case of a FTP/IP connection, these directories and files are not displayed.

Prerequisites

Administrator rights are required for user administration.

Properties

The properties of user administration are as follows:

Property	Maximum value
Number of users	33
Number of predefined users	2
Length of a user name	31 alphanumeric characters
Password length	31 alphanumeric characters
Number of keys for read access	31
Number of keys for write access	31
Number of predefined keys	2

Files

Settings for user administration can be made in 3 files located in the directory "/System".

File	Description
flashdisklock.ini	Assignment of locks to directories
keys.ini	Assignment of names to locks/keys
users.ini	Administration of users

These files are always existing. They cannot be deleted, but only modified or overwritten.

Restrictions

Please take the following restrictions into account:

- User administration can only be applied to the internal flash disk. It cannot be applied to SD cards.
- Once a file user administration has been transferred, its content can be read immediately. The settings only become active when the system is rebooted.

Contents

Topic	Page
User Administration	158
As-Delivered Condition / Predefined Users and Keys.....	160
Assigning a Lock.....	161
Assigning Names to Locks/Keys	163

User Administration

Introduction

The user administration for the file system of the JVM-407 is managed in the configuration file "/System/users.ini".

Prerequisites

If you want to use names for the keys, you must make them known to the JVM-407 beforehand. Therefore, set up the names first (*Setting up names for keys/locks* on page 163).

User Administration

Carry out the following steps for administering users:

Step	Action
1	Establish an FTP connection to the JVM-407; when doing so, log in with administrator rights.
2	Open the file "/System/users.ini".
3	Make your changes to this file.
4	Save the changed file to the JVM-407.
5	Reboot the JVM-407.

Result: The changed user administration settings are now enabled.

Structure of the file "/System/users.ini"

This configuration file is a text file the entries of which are grouped into several sections.

- For each user a separate section is used.
- In these sections values can be set which are then used by the file system.
- Blank lines can be inserted at will.
- The following characters precede a comment line: "!", "#" or ";".

Sections

The sections are named "[USER1]" through "[USER33]". Here, the user name and the related password, as well as read and write permissions are specified.

Example:

```
[USER4]
NAME=TestUser3
PW=testpass
READKEYS=5,openLock2,10,11
WRITEKEYS=openLock2,10,11
SYSKEYS=
```

NAME	
In the given example	TestUser3
Description	User's login name
Allowed values	A maximum of 31 alphanumeric characters
In case of invalid or missing entry	no user account is created
PW	
In the given example	testpass
Description	User's login password
Allowed values	A maximum of 31 alphanumeric characters
In case of missing entry	the user is allowed to log in without password
READKEYS	
In the given example	5,openLock2,10,11
Description	Key for read accesses
Allowed values	1 ... 31 (or corresponding names)
In case of missing entry	the user will not receive read keys
WRITEKEYS	
In the given example	openLock2,10,11
Description	Key for write accesses
Allowed values	1 ... 31 (or corresponding names)
In case of missing entry	the user will not receive write keys
SYSKEYS	
Description	no function assigned; reserved for future extensions

As-Delivered Condition / Predefined Users and Keys

Introduction Two predefined users with set rights are included in the file system. It is not possible to delete these two users. In the user administration only the password can be changed for these two users.

As-Delivered Condition In as-delivered condition the content of the configuration file included in the HMI is as follows.

```
[USER1]
NAME=admin
PW=admin
READKEYS=1,2,3,4,5,6,7,8,9,10,11,12,13,14,15,16,17,18,19,20,21,22,23,24,25,26,27,28,29,30,31
WRITEKEYS=1,2,3,4,5,6,7,8,9,10,11,12,13,14,15,16,17,18,19,20,21,22,23,24,25,26,27,28,29,30,31
SYSKEYS=

[USER33]
NAME=system
PW=system
READKEYS=2,3,4,5,6,7,8,9,10,11,12,13,14,15,16,17,18,19,20,21,22,23,24,25,26,27,28,29,30,31
WRITEKEYS=2,3,4,5,6,7,8,9,10,11,12,13,14,15,16,17,18,19,20,21,22,23,24,25,26,27,28,29,30,31
SYSKEYS=
```

User "admin" All keys are available to this user and he/she is, therefore, able to read all directories and files and to write to them.

User "system" All keys except for key "1" are available to this user, too.

Predefined Keys Two out of the 31 keys have a predefined function:

Lock / Key	Function
1	<ul style="list-style-type: none"> ▪ IP configuration ▪ User administration
2	<ul style="list-style-type: none"> ▪ Operating system update of CPU

Assigning a Lock

Introduction

The configuration file "/System/flashdisklock.ini" is used to assign locks to directories located on the flash disk. Only users with the corresponding key are allowed to read or write (delete) files and subdirectories located in these directories.

Prerequisites

If you want to use names for the locks, you must make them known to the JVM-407 beforehand. Therefore, set up the names first (*Setting up names for keys/locks* on page 163).

Assigning a Lock

Carry out the following steps to assign a lock to a directory:

Step	Action
1	Establish an FTP connection to the JVM-407; when doing so, log in with administrator rights.
2	Open the file "/System/flashdisklock.ini".
3	Make your changes to this file.
4	Save the changed file to the JVM-407.
5	Reboot the JVM-407.

Result: A lock is assigned to this directory.

Structure of the File "/System/flashdisklock.ini"

This configuration file is a text file containing one section.

- In this section values can be set which are then used by the file system.
- Each directory is specified with its lock number in an individual line.
- Blank lines can be inserted at will.
- The following characters precede a comment line: "!", "#" or ";".

Section

The section is named "[LOCKS]". Here, locks are assigned to directories in accordance with the following rule:

Directory=Lock

Example:

```
[LOCKS]
test1=0
test1/sub1=2
test1/sub2=5
test2=userlock2
```

Lock Numbers

Use the following lock numbers:

- Allowed lock numbers: 0 ... 31.
 - Lock number 0: No lock is assigned to this directory. This directory can be accessed without any restrictions.
 - Numbers or previously defined names can be used.
-

Assigning Names to Locks/Keys

Introduction

Locks/keys are consecutively numbered from 1 through 31. To provide ease of handling, a name can be assigned to each lock/key combination. These names are assigned in the configuration file "/System/keys.ini".

Assigning Names

Carry out the following steps to assign names to keys/locks:

Step	Action
1	Establish an FTP connection to the JVM-407; when doing so, log in with administrator rights.
2	Open the file "/System/keys.ini".
3	Make your changes to this file.
4	Save the changed file to the JVM-407.
5	Reboot the JVM-407.

Result: The names are now available and can be used when assigning locks and managing user accounts.

Structure of the File "/System/keys.ini"

This configuration file is a text file containing one section.

- In this section values can be set which are then used by the file system.
- Each key is specified with its name in an individual line.
- Blank lines can be inserted at will.
- The following characters precede a comment line: "!", "#" or ";".

Section

The section is named "[KEYS]". Here, names are assigned to keys/locks in accordance with the following rule:

KEYxx=Name

xx: Number of the key (01 ... 31)

Example:

```
[KEYS]
KEY01=Admin
KEY02=System
KEY03=
KEY04=
KEY05=service
...
KEY31=
```

8 File System

Names for Locks/Keys

For names the following definitions are true:

- A maximum of 15 alphanumeric characters.
 - For a lock and its key the same name is used.
-

8.3 Reviewing the Flash Disk Capacity Used

Introduction

This chapter covers how you can review the used capacity of the user area located on the flash disk.

Contents

Topic	Page
Flash Disk Capacity Used	166

Flash Disk Capacity Used

Info File

The capacity used of the user area located on the internal flash disk can be seen from the file "/System/flashdiskinfo.txt".

Example

In this example, the fictive capacity used of a flash disk in a JetControl 340 (4 MB) is shown:

```
Name : flash disk
Date : 25.11.2008
Time : 15:04
Tracks: 64

Track 0: sectors: 128 (used: 81 / blocked: 47 / free: 0)
Track 1: sectors: 128 (used: 128 / blocked: 0 / free: 0)
Track 2: sectors: 128 (used: 128 / blocked: 0 / free: 0)
Track 3: sectors: 128 (used: 128 / blocked: 0 / free: 0)
Track 4: sectors: 128 (used: 128 / blocked: 0 / free: 0)
Track 5: sectors: 128 (used: 128 / blocked: 0 / free: 0)
Track 6: sectors: 128 (used: 128 / blocked: 0 / free: 0)
Track 7: sectors: 128 (used: 128 / blocked: 0 / free: 0)
Track 8: sectors: 128 (used: 128 / blocked: 0 / free: 0)
Track 9: sectors: 128 (used: 128 / blocked: 0 / free: 0)
Track 10: sectors: 128 (used: 128 / blocked: 0 / free: 0)
Track 11: sectors: 128 (used: 128 / blocked: 0 / free: 0)
Track 12: sectors: 128 (used: 128 / blocked: 0 / free: 0)
Track 13: sectors: 128 (used: 128 / blocked: 0 / free: 0)
Track 14: sectors: 128 (used: 128 / blocked: 0 / free: 0)
Track 15: sectors: 128 (used: 128 / blocked: 0 / free: 0)
Track 16: sectors: 128 (used: 128 / blocked: 0 / free: 0)
Track 17: sectors: 128 (used: 128 / blocked: 0 / free: 0)
Track 18: sectors: 128 (used: 128 / blocked: 0 / free: 0)
Track 19: sectors: 128 (used: 128 / blocked: 0 / free: 0)
Track 20: sectors: 128 (used: 64 / blocked: 64 / free: 0)
Track 21: sectors: 128 (used: 85 / blocked: 43 / free: 0)
Track 22: sectors: 128 (used: 128 / blocked: 0 / free: 0)
Track 23: sectors: 128 (used: 128 / blocked: 0 / free: 0)
Track 24: sectors: 128 (used: 128 / blocked: 0 / free: 0)
Track 25: sectors: 128 (used: 128 / blocked: 0 / free: 0)
Track 26: sectors: 128 (used: 128 / blocked: 0 / free: 0)
Track 27: sectors: 128 (used: 128 / blocked: 0 / free: 0)
Track 28: sectors: 128 (used: 128 / blocked: 0 / free: 0)
Track 29: sectors: 128 (used: 128 / blocked: 0 / free: 0)
Track 30: sectors: 128 (used: 128 / blocked: 0 / free: 0)
Track 31: sectors: 128 (used: 128 / blocked: 0 / free: 0)
Track 32: sectors: 128 (used: 128 / blocked: 0 / free: 0)
Track 33: sectors: 128 (used: 105 / blocked: 0 / free: 23)
Track 34: sectors: 128 (used: 0 / blocked: 0 / free: 128)
```

```

Track 35: sectors: 128 (used: 0 / blocked: 0 / free: 128)
Track 36: sectors: 128 (used: 0 / blocked: 0 / free: 128)
Track 37: sectors: 128 (used: 0 / blocked: 0 / free: 128)
Track 38: sectors: 128 (used: 0 / blocked: 0 / free: 128)
Track 39: sectors: 128 (used: 0 / blocked: 0 / free: 128)
Track 40: sectors: 128 (used: 0 / blocked: 0 / free: 128)
Track 41: sectors: 128 (used: 0 / blocked: 0 / free: 128)
Track 42: sectors: 128 (used: 0 / blocked: 0 / free: 128)
Track 43: sectors: 128 (used: 0 / blocked: 0 / free: 128)
Track 44: sectors: 128 (used: 0 / blocked: 0 / free: 128)
Track 45: sectors: 128 (used: 0 / blocked: 0 / free: 128)
Track 46: sectors: 128 (used: 0 / blocked: 0 / free: 128)
Track 47: sectors: 128 (used: 0 / blocked: 0 / free: 128)
Track 48: sectors: 128 (used: 0 / blocked: 0 / free: 128)
Track 49: sectors: 128 (used: 0 / blocked: 0 / free: 128)
Track 50: sectors: 128 (used: 0 / blocked: 0 / free: 128)
Track 51: sectors: 128 (used: 0 / blocked: 0 / free: 128)
Track 52: sectors: 128 (used: 0 / blocked: 0 / free: 128)
Track 53: sectors: 128 (used: 0 / blocked: 0 / free: 128)
Track 54: sectors: 128 (used: 0 / blocked: 0 / free: 128)
Track 55: sectors: 128 (used: 0 / blocked: 0 / free: 128)
Track 56: sectors: 128 (used: 0 / blocked: 0 / free: 128)
Track 57: sectors: 128 (used: 0 / blocked: 0 / free: 128)
Track 58: sectors: 128 (used: 0 / blocked: 0 / free: 128)
Track 59: sectors: 128 (used: 0 / blocked: 0 / free: 128)
Track 60: sectors: 128 (used: 0 / blocked: 0 / free: 128)
Track 61: sectors: 128 (used: 0 / blocked: 0 / free: 128)
Track 62: sectors: 128 (used: 0 / blocked: 0 / free: 128)
Track 63: sectors: 128 (used: 0 / blocked: 0 / free: 128)

```

```
Total: sectors: 8192 (used: 4175 / blocked: 154 / free: 3863)
```

```

Used   : 2120900 byte
Blocked: 78232 byte
Free   : 1962404 byte
Total  : 4161536 byte

```

Elements of Info File

Tracks and sectors represent the administration units of the flash disk. The info file is structured accordingly and consists of the following elements:

Element	Description
Name	Dedicated name of the flash disk
Date / Time	Point in time when the flash disk has been formatted last
Tracks	Total number of tracks
Track xx: sectors: 128	Assignment of sectors of a track
Total: sectors:	Overall statistical data of sectors

Element	Description
Used	Total number of used bytes
Blocked	Total number of blocked bytes
Free	Total number of available bytes
Total	Total size of the flash disk

States of Sectors

The smallest administrative unit of the flash disk, i.e. the sector, may enter the following states:

State	Meaning
used	The sector is occupied by data.
blocked	The sector is no longer occupied, but can not yet be used due to administrative reasons.
free	The sector is not occupied and can be used.

8.4 Operating System Update and Application Program

Introduction

An OS update for a controller an HMI or an I/O module, as well as access to the application program can be carried out via file system. For a detailed description on this topic refer to the following chapters:

- *Operating System Update* on page 335
 - *Application Program* on page 343
-

8.5 Formatting and Checking

Introduction

This chapter covers formatting and checking of the internal flash disk, SD card, and USB stick.

The internal flash disk needs not be checked using a separate function, since it provides maximum safety of its administrative structures by design.

Operating Principle

When the JVM-407 is booting, the OS checks the contents of the control register belonging to the file system. Depending on the value contained in this register the following functions are carried out:

- Formatting the flash disk
- Formatting the SD card
- Formatting the USB stick
- Checking the SD card
- Checking the USB stick

Register Number

The control register number of the file system is dependent on the controller:

Controller	Register Number
JC-24x	2936
JM-D203-JC24x	2936
JC-340, JC-350, JC-360	202936
JVM-407	202936

Contents

Topic	Page
Formatting the Flash Disk	171
Formatting the SD Card	172
Formatting the USB Stick.....	173
Checking the SD Card	174
Checking the USB Stick	175

Formatting the Flash Disk

Introduction

Sometimes it might be necessary to reformat the flash disk. This may be the case if an OS release has been transferred which has a different flash disk format. Or when information for flash disk administration has been destroyed.

Consequences

- All files and directories located in the user area will be deleted!
- Formatting will not affect system files and directories.

Formatting the Flash Disk

In order to cause the JVM-407 to format the internal flash disk proceed as follows:

Step	Action
1	Switch the JVM-407 on.
2	Enter value -999720373 (0xc4697a4b) into the control register of the file system.
3	Switch the JVM-407 off.
4	Switch the JVM-407 on.

Result: During the boot process of the JVM-407 the flash disk is formatted and the control register is set to 0.

Formatting the SD Card

Introduction

Sometimes it might be necessary to reformat the SD card. This might be the case when information for flash disk administration has been destroyed.

Consequences

All files and directories on the SD card will be deleted!

Formatting the SD Card

In order to cause the JVM-407 to format the SD card proceed as follows:

Step	Action
1	Switch the JVM-407 on.
2	Enter value -748362163 (0xd364e64d) into the JVM-407 register of the file system.
3	Switch the JVM-407 off.
4	Switch the JVM-407 on.

Result: During the boot process of the JVM-407 the SD card is formatted and the control register is set to 0.

Formatting the USB Stick

Introduction

Sometimes it might be necessary to reformat the USB stick. This might be the case when information for USB stick administration has been destroyed.

Consequences

All files and directories on the USB stick will be deleted!

Formatting

To format the USB stick proceed as follows:

Step	Action
1	Power up the HMI.
2	Enter value (0x8f3d5185) into the control register of the file system.
3	De-energize the HMI.
4	Power up the HMI.

Result: During the boot process of the HMI the USB card is formatted and the control register is set to 0.

Checking the SD Card

Introduction

Sometimes it might be necessary to check the SD card for errors. This might be the case when the JVM-407 was switched off while accessing the SD card.

Consequences

- All files and directories on the SD card will be checked and errors, if any, will be fixed.
Following such a check, the administrative structures on the SD card in consistent condition.
 - Depending on the SD card size and the number of files and directories the boot process duration of the JVM-407 may extend to several minutes.
-

Checking the SD Card

In order to cause the JVM-407 to check the SD card proceed as follows:

Step	Action
1	Switch the JVM-407 on.
2	Enter value 748371092 (0x2c9b3c94) into the JVM-407 register of the file system.
3	Switch the JVM-407 off.
4	Switch the JVM-407 on.

Result: During the boot process of the JVM-407 the SD card is checked. The value in the control register remains unchanged so that the card is checked whenever the JVM-407 is rebooted.

Restrictions

This function only "repairs" the administrative structures on the SD card in order that it can be used further. However, it may happen that data of a file which has been written incompletely can't be restored in all cases.

Checking the USB Stick

Introduction

Sometimes it might be necessary to check the USB stick for errors. This might be the case if the HMI was de-energized while it was accessing the USB stick.

Consequences

- All files and directories on the USB stick will be checked and errors, if any, will be fixed.
Following such a check, the administrative structures on the USB stick are in consistent condition.
- Depending on the USB stick capacity and the number of files and directories to be checked the boot process of the HMI may take several minutes.

Check

To check the USB stick for errors proceed as follows:

Step	Action
1	Power up the HMI.
2	Enter value (0x17dbd42a) into the control register of the file system.
3	De-energize the HMI.
4	Power up the HMI.

Result: During the boot process of the JVM-407 the USB stick is checked. The value in the control register remains unchanged so that the stick is checked whenever the HMI is rebooted.

Restrictions

This function only "repairs" the administrative structures on the USB stick so that it can be used further. However, it may happen that data of a file, which has been written incompletely, can't be restored in all cases.

9 FTP Server

Introduction

The FTP server allows access to directories and files located either on an SD card, or on a flash disk integrated into the JVM-407 using an FTP client. This chapter covers the login process and describes the commands supported by the FTP server.

FTP Clients

Apart from the command line FTP client, which comes with many PC operating systems, graphic FTP tools can be used, as well.

Number of Possible Connections

The FTP server on the JVM-407 is able to manage 4 FTP connections simultaneously. That is, up to 4 FTP client programs can be connected with the JVM-407 at the same time.

Any additional client, which tries to connect with the FTP server, will get no response to its request for establishing a connection.

Required Programmer's Skills

To perform the functions described in this chapter, the following skills are required:

- The user must be familiar with the file system of the controller.
 - The user must be familiar with IP networks.
-

Contents

Topic	Page
Login	178
Supported Commands.....	179
Example: Windows FTP Client	180

Login

Login

To have access to the file system via FTP, the FTP client must log in and provide its user name and password when starting the communication.

As Delivered Condition

In its original configuration the controller is delivered with two user accounts:

[USER1]
NAME=admin
PW=admin

[USER33]
NAME=system
PW=system

Administration of Users

Via user administration of the file system, the password can be modified and new users can be added.

Related Topics

- **User administration** on page 156
-

Supported Commands

Supported Commands

The following table lists the commands known to the FTP server, as well as their purpose.

Command	Purpose
USER	Sends the user name; is used at the beginning of the login process
PASS	Sends the password; is sent after USER to complete the login process
QUIT	Terminates the connection
PORT	Specifies the IP address and port number to which the FTP server is to connect for the next file transfer.
TYPE	Sets the transfer type; the following types are possible: <ul style="list-style-type: none"> ▪ Type A with interpretation N ▪ Type I ▪ Type L with 8 bits per character
MODE	Sets the transfer mode; here, only "S" (stream) is possible
STRU	Sets the file structure when transferring data; here, only "F" (file) is possible
NLST	Returns a list containing the file names of a directory
LIST	Returns a list containing the file names and file information of a directory
PWD	Returns the name of the current directory
CWD	Switches to another directory
CDUP	Moves up by one directory level
MKD	Creates a new directory
RMD	This instruction is for removing a directory
STOR	Stores a file
RETR	Reads a file
DELE	Deletes a file
RNFR	Indicates the file name to be changed; must be followed by the command "RNTO"
RNTO	Indicates the new name of the file which has been specified by the command "RNFR" before.
PASV	The FTP server changes into "passive mode"


Example: Windows FTP Client

Task

The following tasks are to be carried out using an FTP client, for example, the one which comes with Windows XP:

- Invoking the FTP client by opening a connection
- Logging in as user "admin" with password "admin"
- Displaying the content of the current directory using "dir"
- Transferring the file "jetter1.jpg" to the JetControl using the command "put"
- Re-displaying the content of the current directory using "dir"
- Terminating the session and the FTP client using "bye"

Action



```
C:\>ftp 192.168.10.208
Verbindung mit 192.168.10.208 wurde hergestellt.
220 JETTER FTP Server 01.5 (22.10.2007).
Benutzer (192.168.10.208:(none>): admin
331 password required for admin.
Kennwort:
230 User admin logged in.
ftp> dir
200 PORT command successful.
150 Opening ASCII mode data connection for "LIST".
09-10-00 10:37PM <DIR> SD
09-10-00 10:37PM <DIR> System
07-24-00 06:28PM <DIR> app
06-11-00 07:48PM <DIR> SysConfig
09-10-00 10:36PM 651 index.htm
09-10-00 10:37PM 1229 ssi1000001.htm
09-10-00 10:37PM 471 pfeil.gif
226 Transfer complete.
FTP: 64d Bytes empfangen in 0,00Sekunden 339000,00KB/s
ftp> put jetter1.jpg
200 PORT command successful.
150 Opening ASCII mode data connection for "STOR".
226 Wait for file system...
226 Transfer complete.
FTP: 64d Bytes gesendet in 0,00Sekunden 5332000,00KB/s
ftp> dir
200 PORT command successful.
150 Opening ASCII mode data connection for "LIST".
09-10-00 10:38PM <DIR> SD
09-10-00 10:38PM <DIR> System
07-24-00 06:28PM <DIR> app
06-11-00 07:48PM <DIR> SysConfig
09-10-00 10:36PM 651 index.htm
09-10-00 10:37PM 1229 ssi1000001.htm
09-10-00 10:37PM 471 pfeil.gif
09-10-00 10:38PM 5332 jetter1.jpg
226 Transfer complete.
FTP: 64d Bytes empfangen in 0,00Sekunden 391000,00KB/s
ftp> bye
211 Goodbye.
C:\>
```

10 HTTP Server

Introduction

The HTTP server can be accessed via standard browser. The browser is for reading and displaying files which have been downloaded to the controller via FTP.

Here, it may be necessary to enter the user name and password to have access to certain pages (depending on the file system configuration).

This chapter covers the "Server Side Includes" (SSI) function included in the HTTP server.

Default File Names

The default file names are *index.htm* and *index.html*.

Supported File Types

The following file types are supported:

- *.htm, *.html, *.shtml
 - *.txt, *.ini
 - *.gif, *.tif, *.tiff, *.bmp, *.wbmp
 - *.jpg, *.jpe, *.jpeg, *.png
 - *.xml
 - *.js, *.jar, *.java, *.class, *.cab
 - *.ocx
 - *.pdf, *.zip, *.doc, *.rtf
 - *.css
 - *.wml, *.wmlc, *.wmls, *.wmlsc
-

Enabling the HTTP Server Feature

To enable the HTTP server feature in the controller the following requirements have to be met:

- When ordering the controller option -W has been selected.

If both requirements have been met, the corresponding bit in status register "Web" is set.

Required Programmer's Skills

To perform the functions described in this chapter, the following skills are required:

- The user must be familiar with the file system of the controller.
 - The user must be familiar with IP networks.
-

Contents

Topic	Page
Server Side Includes	182

10.1 Server Side Includes

Introduction	Current realtime controller values can be displayed in an HTML page using the Server Side Includes (SSI) feature in the HTTP server.
Rules	A name space tag has to be specified at the beginning of the HTML page that is to contain the realtime controller values. This name space tag is for defining the name space used in the HTML page. In the body section of the HTML page the Data Tags are specified.
Updating Realtime Controller Values	When the page is loaded into the browser, the HTTP server once replaces the data tags by current controller values. To refresh the controller values, the HTML page must be reloaded.

Contents

Topic	Page
Name Space Tag.....	183
Inserting Realtime Controller Values	184
Example of an HTML page	189

Name Space Tag

Name Space Tag - Structure

The **Name Space Tag** must be the first entry in the HTML file. Its structure is as follows:

```
<NS:DTAG xmlns:NS=http://jetter.de/ssi/jetcontrol/
```

with **NS** representing the **name space**. A character string with a maximum length of 63 characters can be chosen for the name space.

The **Name Space** introduced here will be re-used for the subsequent Data Tags. The remaining parts of the line are preassigned and have to be specified in exactly the same way.

In the following examples, JW is used for Name Space.

Inserting Realtime Controller Values

Introduction

Actual realtime controller values can be integrated into the parameters of the sections via tag functions. This way, the contents respectively states of registers, text registers, inputs, outputs and flags can be displayed.

Tag Delimiters

All tags start and end with defined strings. Between these tag delimiters variables can be defined:

Delimiter	String
Tag start	<JW:DTAG
Tag end	/>

Variable Definition

The variable definition in a tag contains attributes which are used to set, for example, how the variable value is displayed:

name

Description	Variable Name
Comments	Code letter followed by the variable number
Example	name="R1000023"

type

Description	Variable type of notation
Example	type="REAL"

format

Description	Representation format
Comments	Refer to format definition
Example	format="+0####.###"

factor

Description	Factor by which the realtime controller value is multiplied
Comments	This operation is executed prior to adding the offset
Example	factor="1.5"

offset

Description	Value which is added to the realtime controller value
Comments	This operation is executed after multiplication by the factor
Example	offset="1000"

Format Definition

The representation of variables can be defined by means of their attribute.

- The number of digits/characters used for representing a variable can be defined by the character "#".
- Prefix "0" allows to output leading zeroes. This option applies to the following register types: INT, INTX and REAL.
- Prefix "+" allows to output a sign. This option applies to the following register types: INT, and REAL.
- Prefixing a blank allows to output a space character for positive values. This option applies to the following register types: INT, and REAL.

Registers / Text Registers

The variable name begins with a capital "R" followed by the register number. The following types are possible:

Type	Notation
INT	Integer decimal
INTX	Integer hexadecimal
INTB	Integer binary
BOOL	Register content = 0 --> Display: 0 Register content != 0 --> Display: 1
REAL	Floating point decimal
STRING	Text register

Standard type: INT

Example:

```
<JW:DTAG name="R1000250" type="REAL" format="+0#####.###"
factor="3.25" offset="500" />
```

Result:

The content of register 1000250 is multiplied by 3.25, then, 500 is added to the product, and the result is displayed with sign and at least five integer positions. Leading zeros are added if necessary. Furthermore, three decimal positions are inserted.

Flags

The variable name begins with a capital "F" followed by the flag number.

The following types are possible:

Type	Notation
BOOL	Flag = 0 --> Display: 0 Flag = 1 --> Display: 1
STRING	Flag = 0 --> Display: FALSE Flag = 1 --> Display: TRUE

Standard type: BOOL

Example:

```
<JW:DTAG name="F100" type="STRING" format="#" />
```

Result:

The state of flag 100 is inserted as string "T" or "F".

Inputs

The variable name begins with a capital "I" followed by the input number.
The following types are possible:

Type	Notation
BOOL	Input = 0 --> Display: 0 Input = 1 --> Display: 1
STRING	Input = 0 --> Display: OFF Input = 1 --> Display: ON

Standard type: BOOL

Example:

```
<JW:DTAG name="I100000308" type="STRING" />
```

Result:

The state of input 100000308 on the CPU is inserted as string "ON" or "OFF".

Outputs

The variable name begins with a capital "O" followed by the output number.
The following types are possible:

Type	Notation
BOOL	Output = 0 --> Display: 0 Output = 1 --> Display: 1
STRING	Output = 0 --> Display: OFF Output = 1 --> Display: ON

Standard type: BOOL

Example:

```
<JW:DTAG name="O100000308" />
```

Result:

The state of output 100000308 is inserted as "1" or "0".

Access via Pointer Register

Access via pointer register is realized by inserting the capital letter "P" in front of the variable name. In each case the value of the variable is displayed the number of which corresponds to the content of the register specified in the variable name.

Examples:

```
<JW:DTAG name="PR1000300" />
```

Result: The content of the register is displayed whose number is contained in register 1000300.

```
<JW:DTAG name="PF1000300" />
```

Result: The state of the flag is displayed whose number is contained in register 1000300.

```
<JW:DTAG name="PI1000300" />
```

Result: The state of the input is displayed whose number is contained in register 1000300.

```
<JW:DTAG name="PO1000300" />
```

Result: The state of the output is displayed whose number is contained in register 1000300.

Access via Pointer Register and Offset

To specify the number of the variable to be displayed it is also possible to add a constant value or another register content to the pointer register value.

Examples:

```
<JW:DTAG name="PR1000300 + 100" />
```

Result: The content of the register is displayed whose number results from the addition of the content of register 1000300 and the value 100.

```
<JW:DTAG name="PR1000300 + R1000100" />
```

Result: The content of the register is displayed whose number results from the addition of the content of register 1000300 and the content of register 1000100.

```
<JW:DTAG name="PF1000300 + 100" />
```

Result: The state of the flag is displayed whose number results from the addition of the content of register 1000300 and the value 100.

```
<JW:DTAG name="PF1000300 + R1000100" />
```

Result: The state of the flag is displayed whose number results from the addition of the content of register 1000300 and the content of register 1000100.

```
<JW:DTAG name="PI1000300 + 100" />
```

Result: The state of the input is displayed whose number results from the addition of the content of register 1000300 and the value 100.

```
<JW:DTAG name="PI1000300 + R1000100" />
```

Result: The state of the input is displayed whose number results from the addition of the content of register 1000300 and the content of register 1000100.

```
<JW:DTAG name="PO1000300 + 100" />
```

Result: The state of the output is displayed whose number results from the addition of the content of register 1000300 and the value 100.

```
<JW:DTAG name="PO1000300 + R1000100" />
```

Result: The state of the output is displayed whose number results from the addition of the content of register 1000300 and the content of register 1000100.

Example of an HTML page

Task	Current realtime controller values are to be inserted into an HTML page. The HTML page is then to be displayed in a browser using the Server Side Includes feature of the HTTP server.
Action	<pre> <JC:DTAG xmlns:JC="http://jetter.de/ssi/jetcontrol" /> <html> <head> <meta http-equiv="Content-Type" content="text/html; charset=windows-1252"> <meta name="GENERATOR" content="Microsoft FrontPage 4.0"> <meta name="ProgID" content="FrontPage.Editor.Document"> <title>Index</title> </head> <body> Hello World, &nbsp; <p>Actual controller values can be inserted into an html page like this:&nbsp;</p> <p>Register 201000 = <JC:DTAG name="R201000" type = INT format="+####" />, or Hex: 0x<JC:DTAG name="PR201000+10" type="INTX" format="0###" />, or maybe that way <JC:DTAG name="R201000" type="BOOL" />, if only boolean queries are used. But binary is also possible: <JC:DTAG name="R201000" type="INTB" format="#####" />b.&nbsp;</p> <p>Strings could also be defined "<JC:DTAG name="R201000" type="STRING" />".&nbsp;</p> <p>A real number looks as follows: <JC:DTAG name="R1001500" type="REAL" /> or this way <JC:DTAG name="R1001500" type="REAL" factor="1.3" format="###.###" />.&nbsp;</p> <p>The value of a flag is represented as follows: <JC:DTAG name="F10" /> or <JC:DTAG name="PF1000000" type="STRING" />.&nbsp;</p> <p>For inputs and outputs by analogy: <JC:DTAG name="PI1000130" type="BOOL" /> or <JC:DTAG name="100000205" type="STRING" />.&nbsp;</p> <p>R201000 = <JC:DTAG name="R201000" type="INT" format="+0#####" />&nbsp;</p> <p>Regards&nbsp;</p> <p>Your JetControl</p> </body> </html> </pre>

11 Programming

Purpose of this Chapter This chapter is for supporting you in programming the HMI JVM-407 in the following fields of activity:

- Programming additional functions

Prerequisites

To be able to program the HMI JVM-407 the following prerequisites must be fulfilled:

- The HMI is connected to a PC.
 - The programming tool JetSym is installed on the PC.
-

Contents

Topic	Page
Abbreviations, Module Register Properties and Formats.....	192
Memory Overview.....	193
Inputs and Outputs	205
Realtime Clock (RTC).....	211
Runtime Registers	215
Monitoring the Interface Activity.....	219
E-Mail.....	224
Modbus/TCP.....	249
User-programmable IP Interface	268
User-Programmable CAN-PRIM Interface	296

Abbreviations, Module Register Properties and Formats

Abbreviations

The abbreviations used in this document are listed in the following table:

Abbreviation	Meaning
R 100	Register 100
MR 150	Module register 150

Module Register Properties

Each module register is characterized by certain properties. For many module registers most properties are identical. For example, their value after reset is 0. In the following description, module register properties are mentioned only if a property deviates from the following default properties.

Module Register Properties	Default property for most module registers
Access	Read / write
Value following a reset	0 or undefined (e.g. release number)
Takes effect	Immediately
Write access	Always
Data type	Integer

Number Formats

The number formats used in this document are listed in the following table:

Notation	Number Format
100	Decimal
0x100	Hexadecimal
0b100	Binary

JetSym Sample Programs

The notation for sample programs used in this document is listed in the following table:

Notation	Meaning
<code>Var, When, Task</code>	Key words
<code>BitClear();</code>	Instructions
<code>100 0x100 0b100</code>	Constant numerical value
<code>// This is a comment</code>	Comments
<code>// ...</code>	Further program processing

11.1 Memory Overview

Introduction

The JVM-407 features several types of program and data memories. There is volatile memory that requires power to maintain the stored information, and non-volatile memory which does not require power to maintain the stored information. The memory is located directly in the CPU or in separate memory or I/O modules.

This chapter gives an overview of the available memory.

Contents

Topic	Page
Operating System Memory.....	194
File System Memory.....	195
Application Program Memory	196
Memory for Volatile Application Program Variables.....	197
Memory for Non-Volatile Application Program Registers	198
Memory for Non-Volatile Application Program Variables.....	199
Special Registers.....	201
Inputs and Outputs	202
Flag.....	203

Operating System Memory

Introduction

The OS is stored to a non-volatile flash memory in the CPU. Therefore, the OS can be executed immediately after the JVM-407 is powered up.

Features

- Internal flash memory for storing the OS
 - Internal volatile RAM for storing OS data
-

Memory Access

- The user is not allowed to directly access the OS memory.
 - Changes to the OS can be made by means of an OS update.
-

Related Topics

- **Updating the Operating System** on page 336
-

File System Memory

Introduction

The file system memory is for storing data and program files.

Features

- Internal flash disk and SD memory card
 - Non-volatile
 - Slow access: milliseconds up to seconds
 - Limited number of write/delete cycles: approx. 1 million
 - Internal flash disk size: 12.875 MBytes
 - SD card size: 32 MByte to 4 GByte
-

Memory Access

- by operating system
 - by JetSym
 - via FTP connection
 - by e-mail client
 - by browser (via HTTP server)
 - by means of file commands from within the application program
-

Application Program Memory

Introduction

By default, the application program is uploaded from JetSym to the HMI and is stored to it.

Features

- Stored as file within the file system
 - Default directory: "/app"
 - files may also be stored to other directories (or on SD card)
 - Size: 256 KByte max.
-

Memory Access

- by operating system
 - by JetSym
 - via FTP connection
 - by means of file commands from within the application program
-

Related Topics

- **Application Program** on page 343
-

Memory for Volatile Application Program Variables

Introduction

Volatile variables are used to store data which may be discarded when the JVM-407 is de-energized.

Properties

- Global variables which are not assigned to permanent addresses (not %VL or %RL)
- Local variables
- Variables are stored in a compact way
- Variables are initialized with value 0 when they are created

Memory Access

- by JetSym
- from within the application program

JetSym STX Program

In the following program a global variable is incremented by 1 every 2 seconds:


```
#Include "Platforms.stxp"

Var
    Count:    Int;
End_Var;

Task Increment Autorun
    Loop
        Inc (Count);
        Delay (T#2s);
    End_Loop;
End_Task;
```

Setup Pane

The JetSym setup pane displays the content of the variable.



Number	Description	Function
1	Present content of the variable	The content of the variable is incremented by 1 every 2 seconds.

Memory for Non-Volatile Application Program Registers

Introduction

Non-volatile registers are used to store data which must be maintained when the JVM-407 is de-energized.

Properties

- Global variables which are assigned to permanent addresses (%VL)
- Register variables always occupy 4 bytes
- Register variables are not initialized by the operating system
- Number of register variables: 6.000
- Register numbers: 1,000,000 through 1,005,999

Memory Access

- by JetSym
- by e-mail client
- by browser (via HTTP server)
- from HMIs
- from within the application program
- from other controllers/HMIs

JetSym STX Program

In the following program a register variable is incremented by 1 every time the application program is launched. Thus, it is used to count the number of program launches.


```

Var
    ProgramStartCounter:    Int At %VL 1000000;
End_Var;

Task Work Autorun
    ProgramStartCounter := ProgramStartCounter + 1;
    Loop
        // ...
    End_Loop;
End_Task;
    
```

Setup Pane

The JetSym setup pane displays the content of the register variable.



Number	Content	Description
1	Present content of the register variable	The content of the register variable is incremented by 1 every time the program is launched.

Memory for Non-Volatile Application Program Variables

Introduction

Non-volatile variables are used to store data which must be maintained when the JVM-407 is de-energized.

Properties

- Global variables which are assigned to permanent registers (%RL)
- Variables are stored in a compact way
- Size: 24,000 bytes
- Register numbers: 1,000,000 through 1,005,999

Memory Access

- by JetSym
- from HMIs
- from within the application program

JetSym STX Program

In the following program 4 non-volatile variables are incremented every second. The working range of the counters is between 0 and 255 (variable type: byte). For these 4 variables the 4 bytes of register 1000010 are used.


```

Var
    Cnt1, Cnt2, Cnt3, Cnt4:    Byte At %RL 1000010;
End_Var;

Task Count4 Autorun
    Loop
        Inc (Cnt1);
        Inc (Cnt2, 2);
        Inc (Cnt3, 5);
        Inc (Cnt4, 10);
        Delay (T#1s);
    End_Loop;
End_Task;
    
```

Setup Pane

The JetSym setup pane displays the content of the variable. As the type of the 4 counters is byte, this will result in counter overflow after a relatively short time:



Number	Content	Description
1	Present content of the variable Cnt1	The content of the variable is incremented by 1 every second.

Number	Content	Description
2	Present content of the variable Cnt2	The content of the variable is incremented by 2 every second.
3	Present content of the variable Cnt3	The content of the variable is incremented by 5 every second.
4	Present content of the variable Cnt4	The content of the variable is incremented by 10 every second.

Special Registers

Introduction

Special registers are used to control OS functions and to retrieve status information.

Properties

- Global variables which are assigned to permanent addresses (%VL)
- When the operating system is launched, special registers are initialized using default values.
- Register numbers: 100,000 through 999,999

Memory Access

- by JetSym
- via e-mail client
- by browser (via HTTP server)
- from HMIs
- from within the application program
- from other controllers

JetSym STX Program

In the following program 2 special registers are used. The first is the special register for status LEDs, the second is the special register for digipot values. In this task, the value is just copied from the special register containing digipot values to the special registers assigned to the status LEDs. If the application program is running on the HMI and the user turns the digipot, the value contained in the digipot special register is displayed by the status LEDs.

```
Var
    Digipot:    Int at %VL 363000;
    Status_LEDs: Int at %VL 362100;
End_Var;

Task Main Autorun

    Loop
        Status_LEDs:= Digipot;
    End_Loop;

End_Task;
```

Inputs and Outputs

Introduction

Inputs and outputs are 1-bit variables. This means they can either have the value TRUE or FALSE.

Properties of Virtual Inputs/Outputs

- Global variables assigned to permanent addresses (%IX, %QX)
 - Used for RemoteScan via Modbus/TCP
 - Quantity: 16,000
 - I/O numbers: 20001 through 36000
-

Memory Access

- by JetSym
 - via e-mail client
 - by browser (via HTTP server)
 - from HMIs
 - from within the application program
-

JetSym STX Program

The following program is for dimming the background lighting of the HMI if input In11 is set.

```
Var
    In11          :Bool at %XL 362100.10;
    //Background lighting
    BackgroundLighting :Int at %VL 364000;
End_Var;

Task Main Autorun
    Loop
        // If In11 is set, then
        If In11 Then
            //dim background lighting
            Inc(BackgroundLighting);
            Delay(T#30ms);
        End_If;
    End_Loop;
End_Task;
```

Flag

Introduction	Flags are 1-bit operands. This means they can either have the value TRUE or FALSE.
Properties of User Flags	<ul style="list-style-type: none"> ▪ Global variables assigned to permanent addresses (%MX) ▪ Non-volatile ▪ Quantity: 256 ▪ Flag numbers: 0 through 255
Properties of Overlaid User Flags	<ul style="list-style-type: none"> ▪ Global variables assigned to permanent addresses (%MX) ▪ Non-volatile ▪ Overlaid by registers 1000000 through 1000055 ▪ Quantity: 1,792 ▪ Flag numbers: 256 through 2047
Properties of Special Flags	<ul style="list-style-type: none"> ▪ Global variables assigned to permanent addresses (%MX) ▪ When the operating system is launched, special flags are initialized using default values. ▪ Quantity: 256 ▪ Flag numbers: 2048 through 2303
Memory Access	<ul style="list-style-type: none"> ▪ by JetSym ▪ by e-mail client ▪ by browser (via HTTP server) ▪ from HMIs ▪ from within the application program
JetSym STX Program	<p>In the following program, a flag is set when the user presses key F1. If on an HMI key F2 is pressed, the flag is reset. As long as this flag is set, special register 361000 (Status LED) is incremented. Incrementing of the special register continues until the flag is reset.</p>

```

Var
    Flag1:          Bool at %MX 1;
    Input_Button_1: Bool at %XL 361000.0;
    Input_Button_2: Bool at %XL 361000.1;
    Status_LEDs:    Int  at %VL 362100;
End_Var;

Task Main Autorun
    Flag1:= False;
    Loop
        If Input_Button_1 Then
            Flag1 := True;
        ElseIf Input_Button_2 Then
            Flag1:= False;

```

```
        End_IF;  
  
        If Flag1 Then  
            Inc(Status_LEDs);  
            Delay(T#100ms);  
        End_If;  
    End_Loop;  
End_Task;
```

11.2 Inputs and Outputs

Introduction

This chapter covers the programming of inputs and outputs, controls and ignition and switching off delay for the JVM-407.

Contents

Topic	Page
Function Keys	206
Digipot.....	207
Digital Inputs and Outputs	208
Ignition and Switching Off Delay.....	209

Function Keys

Introduction

The HMI JVM-407 has four function keys F1 to F4. The function keys are freely programmable.

Special Registers

In register 361000 of the JVM-407, there is a bit-coded mapping of the function keys which can be used for programming.

JetSym STX Program**Prerequisites:**

So that the status LEDs are not also controlled via the JVM-407 inputs, the inputs IN1 to IN10 should not be set whilst running the sample program.

In the following sample program, the function keys are continuously interrogated in one task. Pressing one or more keys controls the status LEDs assigned in the program.

```

Var
    F_Button_Register: Int At %VL 361000;

    Status_Led_1: Bool At %XL 362100.0;
    Status_Led_2: Bool At %XL 362100.1;
    Status_Led_3: Bool At %XL 362100.2;
    Status_Led_4: Bool At %XL 362100.3;
End_Var;

Task Main Autorun
    F_Button_Register := 0;
    Loop
        If F_Button_Register.0 Then
            Status_Led_1 := True;
        Else Status_Led_1 := False;
        End_If;
        If F_Button_Register.1 Then
            Status_Led_2 := True;
        Else Status_Led_2 := False;
        End_If;
        If F_Button_Register.2 Then
            Status_Led_3 := True;
        Else Status_Led_3 := False;
        End_If;
        If F_Button_Register.3 Then
            Status_Led_4 := True;
        Else Status_Led_4 := False;
        End_If;
    End_Loop;
End_Task;

```

Digipot

Introduction

The JVM-407 has a digipot with pushbutton feature, which offers a convenient input option. The following provides details of the digipot's special registers with a corresponding sample program.

Digipot Registers

The following special registers exist for the digipot:

Registers	Description
363000	This register counts up and down when the digipot is rotated and contains the current reading. Here, the following applies: <ul style="list-style-type: none"> ▪ Rotate digipot clockwise = register incremented ▪ Rotate digipot counter-clockwise = register decremented
363001	Bit 0: 0 = Digipot not pressed Bit 0: 1 = Digipot pressed
363002	The lower limit for the digipot reading is specified here. If the digipot is further rotated counter-clockwise, the register 363000 remains at this minimum value.
363003	The upper limit for the digipot reading is specified here. If the digipot is further rotated clockwise, the register 363000 remains at this maximum value.

JetSym STX Program

In the following sample program, the background lighting for the JVM-407 is dimmed using the digipot. An upper and lower limit for the digipot is specified for this purpose. Pressing the digipot sets full background lighting.

```

Var
    Digipot_Count      : Int At %VL 363000;
    Digipot_Limit_min: Int At %VL 363002;
    Digipot_Limit_max: Int At %VL 363003;
    Digipot_Button     : Int At %VL 363001;
    BackgroundLighting: Int At %VL 364000;
End_Var;

Task Main Autorun
    Digipot_Count := 0;
    Digipot_Limit_max := 17;
    Digipot_Limit_min := 0;
    Loop
        If Digipot_Button Then
            BackgroundLighting := 255;
        Else BackgroundLighting := Digipot_Count*15;
        End_If
    End_Loop
End_Task;

```

Digital Inputs and Outputs

Introduction

The HMI JVM-407 has the following inputs and outputs:

- 15 digital inputs. Ten of these have a fixed connection with status LEDs and five are freely programmable.
- 1 digital output, e.g. to control a bypass relay. However, outputs are always set simultaneously to enable provision of a higher current.

Special Registers

The following registers are available for the digital inputs and outputs:

Register	Description
362100	Bit-coded mapping of digital inputs IN1 - IN15 . IN1 - IN10 are linked to the JVM-407 status LEDs. Example: Bit 0 = 1: IN1 in and status LED 1 on.
362200	Bit 0 of the register is responsible for setting the digital output. Bit 0 = 1: Digital output is set.

JetSym STX-Program

In this sample program, the freely programmable input IN11 is continuously interrogated. If this input is set, then the 2 digital outputs are set, which serve to control e.g. a bypass relay.

```

Var
  IN11:   Bool At %XL 362100.10;
  // Digital outputs
  Output: Bool At %XL 362200.0;
End_Var;

Task Main Autorun
  Loop
    // If In11 is set, then
    If IN11 Then
      // Set the digital outputs
      Output := True;
      Delay(T#100ms);
    End_If;
  End_Loop;
End_Task;

```


Ignition and Switching Off Delay

Introduction

The ignition and shutdown function are detailed here.

Special Registers

The special register 361100 of the JVM-407 is responsible for prompting ignition. Here, the following applies:

If Then ...
Bit 0 = 0	Ignition is switched on and voltage is applied to KL 15 ignition (+).
Bit 0 = 1	Ignition is switched off and no voltage is applied to KL 15 ignition (+).

Default Ignition Function

The HMI has the following default settings in connection with ignition:

Ifand...	... Then ...
the power supply is connected to the HMI	the ignition is off	the HMI does not boot up.
the power supply is connected to the HMI	the ignition is on	the HMI boots up.
the HMI is running	the ignition is switched off (not the power supply)	then the HMI remains switched on.

Shutdown Function - Options

Notwithstanding the default ignition function, the Shutdown function provides the following options:

- The HMI can be individually shut down.
- The HMI can be restarted.

Function Declaration

Function **Shutdown (Reboot:Bool) :Bool;**

Function Parameters

The Shutdown () function has the following parameters.

Parameter	Description	Value
Reboot	System restart: System shutdown:	True False

Return Value

The function transfers the following return values to the higher-level program.

Return Value

0	ok
-1	Ignition is still switched on

Note

If the ignition is still switched on, the device will not be switched off. However, a restart will always be performed and is not dependent on the ignition.

JetSym STX Program

In the sample program, the **Shutdown ()** function is executed after 3 seconds, if the ignition of the vehicle is switched off. The **Reboot** parameter for the **Shutdown ()** function has the value **false**. This means that the device is switched off.

```
Var

    Ignition: Int At %VL 361100;
End_Var;

Task Ign Autorun
    Loop
        When Ignition Continue;
            Delay(3000);
            Shutdown(False);
        End_Loop;
    End_Task;
```

11.3 Realtime Clock (RTC)

Introduction The JVM-407 is equipped with a timing circuit (realtime clock for date and time). This clock continues to work even when the JVM-407 is deenergized.

Usage by OS The realtime clock is used by the OS for the following functions:

- File date and time when creating a file

Restrictions When using the realtime clock the following restrictions have to be taken into account:

- When the JVM-407 is deenergized the power reserve is limited.
- The RTC has no automatic daylight savings time function

Contents

Topic	Page
Technical Data	212
Sample Program for Real-Time Clock.....	213

Technical Data

Technical Data - Real-Time Clock

Parameter	Description
Power reserve	4 years
Deviation	Max. 1 minute per month

Behavior when the Power Reserve has Elapsed

If the HMI has been de-energized for a longer period of time and the RTC power reserve has elapsed, it takes the following actions when re-booting:

Stage	Description
1	During the boot process the HMI detects that the power reserve has elapsed.
2	Date and time are set to their default values: Date: Saturday, January 01, 2000 Time: 0:00 a.m.

As-Delivered Condition

In as-delivered condition the date is Saturday, 01 January, 2000.

Sample Program for Real-Time Clock

Task	Actual date and time from the JVM-407 are to be displayed in JetSym.
Solution	An application program task reads out the realtime clock at regular intervals and outputs the readings properly formatted as trace message. These readings can be displayed in JetSym when trace mode has been activated.

```

JetSym STX Program
#include "Platforms.stxp"

Type
// structure of RTC buffer
TimeAndDate: Struct
    Second:      Int;
    Minute:      Int;
    Hour:        Int;
    DayOfWeek:   Int;
    Day:         Int;
    Month:       Int;
    Year:        Int;
    Trigger:     Int;
End_Struct;
End_Type;

Var
    RTCregs:    TimeAndDate At %VL 102921;
End_Var;

Task ShowTimeAndDate Autorun
    Var
        Dummy:    Int;
    End_Var;

    Loop
        // wait one second
        Delay(T#1s);
        // copy actual time and date to buffer
        Dummy := RTCregs.Trigger;

        // show day of week
        Case RTCregs.DayOfWeek Of
            0: Trace('Sunday');
               Break;
            1: Trace('Monday');
               Break;
            2: Trace('Tuesday');
               Break;
            3: Trace('Wednesday');
               Break;
        End_Case;
    End_Loop;
End_Task;

```

```
        4: Trace('Thursday');
           Break;
        5: Trace('Friday');
           Break;
        6: Trace('Saturday');
           Break;
End_Case;
// show date
Trace(StrFormat(' , %2d.%02d.%4d , ',
                RTCregs.Day,
                RTCregs.Month,
                RTCregs.Year + 2000));
// show time (plus cr/lf)
Trace(StrFormat('%2d:%02d:%02d$n',
                RTCregs.Hour,
                RTCregs.Minute,
                RTCregs.Second));

End_Loop;
End_Task;
```

11.4 Runtime Registers

Introduction The JVM-407 provides several registers which are incremented by the operating system at regular intervals.

Application These registers can be used to easily carry out time measurements in the application program.

Contents

Topic	Page
Description of Runtime Registers	216
Sample Program - Runtime Registers	218

Description of Runtime Registers

Overview of Registers

The following registers are used in this manual:

Registers	Description
R 201000	Application time base in milliseconds
R 201001	Application time base in seconds
R 201002	Application time base in R 201003 * 10 milliseconds
R 201003	Application time base unit for R 201002
R 201004	System time base in milliseconds

R 201000

Application time base in milliseconds

Every millisecond this register is incremented by 1.

Register properties

Values -2,147,483,648 ... 2,147,483,647 (with overflow function)

R 201001

Application time base in seconds

Every second this register is incremented by 1.

Register properties

Values -2,147,483,648 ... 2,147,483,647 (with overflow function)

R 201002

Application time base in application time base units

Every [201003] * 10 milliseconds this register is incremented by 1. Using the reset value in register 201003 of 10, this register is incremented every 100 milliseconds.

Register properties

Values -2,147,483,648 ... 2,147,483,647 (with overflow function)

R 201003**Application time base unit for R 201002**

This register contains the multiplier for runtime register R 201002.

Register properties

Values	1 ... 2,147,483,647 (* 10 ms)
--------	-------------------------------

Value following reset	10 (--> 100 ms)
-----------------------	-----------------

Enabling Conditions	after at least 10 ms
---------------------	----------------------

R 201004**System time base in milliseconds**

Every millisecond this register is incremented by 1.

Register properties

Values	-2,147,483,648 ... 2,147,483,647 (with overflow function)
--------	---

Access	Read access
--------	-------------

Sample Program - Runtime Registers

Task	Measure how much time it takes to store variable values to a file.
Solution	Before storing the values register 201000 is set to 0. Once the values have been stored, from this register can be seen how much time it took to store the values [in milliseconds].

JetSym STX Program

```
Var
    dataArray:    Array[2000] Of Int;
    File1:       File;
    WriteTime:   Int;
    WriteIt:     Bool;

    MilliSec:    Int At %VL 201000;
End_Var;

Task WriteToFile Autorun
    Loop
        // clear start flag
        WriteIt := False;
        // wait until start flag set by user
        When WriteIt Continue;
        // open file in write mode
        If FileOpen(File1, '/Test.dat', fWrite) Then
            // restart timer register
            MilliSec := 0;
            // write array data to file
            FileWrite(File1, dataArray,
                SizeOf(dataArray));
            // capture time
            WriteTime := MilliSec;
            FileClose(File1);
            // show measured time
            Trace(StrFormat('Time : %d [ms]$n',
                WriteTime));
        Else
            // show error message
            Trace('Unable to open file!$n');
        End_If;
    End_Loop;
End_Task;
```

11.5 Monitoring the Interface Activity

Introduction

Several servers for variables have been integrated into the HMI to make variables used within the HMI accessible from outside. These servers support several protocols on different interfaces. The servers do not require any programming in the application program, but process requests from external clients on their own.

This chapter explains one possibility for detecting from within the application program whether communication with the servers takes places through these interfaces.

Monitored Interface Activities

The following interface activities can be monitored:

- JetIP server via Ethernet interface
- STX debug server via Ethernet interface

Application

The monitoring function for interface activities can be used, amongst others, for the following scenarios:

- Plants requiring process visualization to ensure safe operation can be transferred into a safe condition if communications fails.
- When the service technician connects an HMI, the application program automatically displays additional status information.

Contents

Topic	Page
Operating Principle	220
Programming	222


Operating Principle

Introduction

The activity of a client communicating with a server in the JVM-407 can be monitored from the application program by means of two special flags and one special register per interface.

Overview

The diagram below shows the interdependence between interface activity and the two special flags, as well as the special register:



Number	Element	Function
1	Telegrams	Requests from client to server
2	OS flag	OS flag set by the JVM-407 once a request has been received.
3	User flag	The user flag should be set in the application program once the OS flag has been set. This indicates that the connection has temporarily been disrupted even if the OS flag is reset very quickly.
4	Timeout	Time of inactivity after which both special flags are reset by the OS. This time can be set in a special register.

Description

Interface activities are monitored as follows:

Stage	Description
1	To activate monitoring mode the desired value is entered into the timeout register from within the application program.
2	When the JVM-407 receives the next telegram, it sets the corresponding OS flag.
3	Once the OS flag has been set, the corresponding user flag is set in the application program.
4	Each new telegram causes the timeout to restart.
5	If telegrams cease to arrive, both special flags are reset by the JVM-407 upon expiry of the timeout interval.

6	The application program detects that the special flags have been reset and takes appropriate action.
7	When further telegrams start to arrive, the JVM-407 sets the corresponding OS flag. The user flag, however, remains reset.

Programming

Registers/Flags - Overview

The following registers and flags are used in this manual:

Timeout Registers

Register	Interface	Application
R 203000	JetIP via Ethernet	<ul style="list-style-type: none"> ▪ Visualization ▪ Networking
R 203005	STX debug via Ethernet	<ul style="list-style-type: none"> ▪ JetSym via Ethernet

Special Flags

Flag	Interface	Application
F 2088	JetIP via Ethernet	OS flag
F 2089		User-defined flag
F 2098	STX debug via Ethernet	OS flag
F 2099		User-defined flag

R 203000

Timeout in the case of JetIP via Ethernet

This register contains the timeout for the JetIP server via Ethernet in milliseconds.

Register properties

Values	0 ... 2,147,483,647 [ms]
Value after reset	0 (monitoring disabled)

R 203005

Timeout in the case of STX debug via Ethernet

This register specifies the timeout for STX debug server via Ethernet in milliseconds.

Register properties

Values	0 ... 2,147,483,647 [ms]
Value after reset	0 (monitoring disabled)

Enabling the Monitoring Function

To enable monitoring of interface activities, proceed as follows:

Step	Action
1	Enter the desired value into the timeout register of this interface.
2	Wait until the OS flag of this interface is set by the HMI.
3	Set the corresponding user flag.

Timeout Detection

To detect a timeout, proceed as follows:

Step	Action						
1	Enable monitoring of interface activities (see above).						
2	Wait until the user flag of this interface is reset by the HMI. Result: A timeout has occurred.						
3	Check the corresponding OS flag <table border="1" data-bbox="667 880 1452 1043"> <thead> <tr> <th>If ...</th> <th>... Then ...</th> </tr> </thead> <tbody> <tr> <td>the OS flag is set</td> <td>the connection was temporarily disrupted</td> </tr> <tr> <td>the OS flag is reset</td> <td>the connection is still disrupted</td> </tr> </tbody> </table>	If Then ...	the OS flag is set	the connection was temporarily disrupted	the OS flag is reset	the connection is still disrupted
If Then ...						
the OS flag is set	the connection was temporarily disrupted						
the OS flag is reset	the connection is still disrupted						

11.6 E-Mail

Introduction

E-mails are created using template files into which variable values are inserted as required when the e-mail is sent. E-mails are sent from the HMI to an e-mail server which will then forward the message.

This chapter gives a description on how to configure the e-mail feature in the HMI JVM-407, and on how to create and send e-mails.

Required Programmer's Skills

To perform the functions described in this chapter, the following skills are required:

- Since files are used to configure the e-mail feature, and e-mails as such are based on these files, the user must be familiar with the file system of the HMI.
 - The user must be familiar with IP networks.
-

Contents

Topic	Page
Configuring the E-Mail Feature	225
Creating E-Mails	233
Sending an E-Mail.....	240
Registers.....	244

11.6.1 Configuring the E-Mail Feature

Introduction

This chapter gives a description on how to configure the e-mail feature so as to allow sending of e-mails from within the application program.

During the boot process, the JVM-407 reads out configuration data from the file "/EMAIL/email.ini".

Prerequisites

When creating the configuration file, the following requirements have to be met:

- The IP address of the e-mail server must be known.
- If the IP address of the e-mail server is not known, name resolution through a DNS server must be possible (refer to *Using Names for IP Addresses* on page 79).
- The log-on and authentication parameters at the e-mail server must be known.

To obtain this information contact your network administrator.

Contents

Topic	Page
Configuration File "/EMAIL/email.ini"	226
Section [SMTP].....	227
Section [POP3]	229
Section [DEFAULT].....	231
Configuration File - Examples	232

Configuration File "/EMAIL/email.ini"

Introduction

The configuration of the e-mail client in the JVM-407 is based on the contents of the file "/EMAIL/email.ini". This file is read out only when the controller is booting.

File Structure

This configuration file is a text file the entries of which are grouped into several sections.

- These sections are for setting values which are then used by the e-mail client.
- Blank lines can be inserted as required.
- The following characters precede a comment line: "!", "#" or ";".

Sections

The configuration file contains up to 3 sections. Section [SMTP] is mandatory. The other sections have to be created only in case they are actually required.

Section	Configuration Values
[SMTP]	<ul style="list-style-type: none">▪ IP address and port number of SMTP server▪ Log-on parameters
[POP3]	<ul style="list-style-type: none">▪ IP address and port number of POP3 server▪ Log-on parameters
[DEFAULT]	<ul style="list-style-type: none">▪ Name of an e-mail template file containing default values

Section [SMTP]

Introduction

In this section the parameters are specified which are used to connect to the SMTP server.

Example:

```
[SMTP]
IP      = 192.168.40.1
PORT    = 25000
HELO    = JetControl_2
USER    = JetControl0815
PASSWORD = MyPassWord
```

Authentication

This type of authentication requires the JVM-407 to log on at the SMTP server before an e-mail can be sent. During the logon process USER and PASSWORD have to be entered. JetControl supports the following authentication methods:

- LOG-ON
- PLAIN
- CRAM-MD5

Configuration Values

IP

In the given example	192.168.40.1
Description	IP address of the SMTP server; can also be specified as name.
Allowed values	<ul style="list-style-type: none"> ▪ > 1.0.0.0 ▪ < 223.255.255.255
Illegal values	<ul style="list-style-type: none"> ▪ Network address ▪ Broadcast address
In case of illegal value or missing entry	E-mail feature will not be available

PORT

In the given example	25.000
Description	Port number of SMTP server
Allowed values	<ul style="list-style-type: none"> ▪ > 0 ▪ < 65.536
Illegal values	<ul style="list-style-type: none"> ▪ > 65.335
In case of missing entry	25

HELO

In the given example	JetControl_2
Description	Name for logging on at the e-mail server
Allowed values	String of 63 characters max.

In case of missing entry	When sending the e-mail, the JVM-407 uses the entry contained in [FROM]
--------------------------	---

USER

In the given example	JetControl0815
Description	Log-on name for SMTP authentication. If this entry exists, a PASSWORD must be specified, too.
Allowed values	String of 63 characters max.
In case of missing entry	SMTP authentication will not be carried out

PASSWORD

In the given example	MyPassWord
Description	Log-on password for SMTP authentication. If this entry exists, a USER must be specified, too.
Allowed values	String of 63 characters max.
In case of missing entry	SMTP authentication will not be carried out

Section [POP3]

Introduction

In this section the parameters are specified which are used to connect to the POP3 server.

This section is only needed if the e-mail server, to which the e-mails are to be sent, requires authentication through POP3-before-SMTP.

Example:

```
[POP3]
IP      = 192.168.40.1
PORT    = 25100
USER    = JetControl4711
PASSWORD = Pop3PassWord
```

Authentication

This type of authentication requires the JVM-407 to establish a connection to the POP3 server first. During this process USER and PASSWORD have to be entered. After that, the SMTP server allows to send e-mails for a given period of time (mostly 10 to 30 minutes).

Configuration Values

IP

In the given example	192.168.40.1
Description	IP address of POP3 server; can also be specified as name.
Allowed values	<ul style="list-style-type: none"> ▪ > 1.0.0.0 ▪ < 223.255.255.255
Illegal values	<ul style="list-style-type: none"> ▪ Network address ▪ Broadcast address
In case of illegal value or missing entry	POP3 log-in will not be carried out

PORT

In the given example	25.100
Description	Port number of POP3 server
Allowed values	<ul style="list-style-type: none"> ▪ > 0 ▪ < 65.536
Illegal values	<ul style="list-style-type: none"> ▪ > 65.335
In case of missing entry	110

USER

In the given example	JetControl4711
Description	Log-on name for POP3 authentication. If this entry exists, a PASSWORD must be specified, too.
Allowed values	String of 63 characters max.
In case of missing entry	POP3 log-in will not be carried out

PASSWORD

In the given example	Pop3PassWord
Description	Log-on password for POP3 authentication. If this entry exists, a USER must be specified, too.
Allowed values	String of 63 characters max.
In case of missing entry	POP3 log-in will not be carried out

Section [DEFAULT]

Introduction

In this section the name of an e-mail template file is specified which contains default settings for e-mails. The settings made here will be used when sending an e-mail if the corresponding section in an e-mail template is missing.

Example

```
[DEFAULT]
MAILCFG = EmailDefaults.cfg
```

Related Topics

- [Structure of Template File](#) on page 235
-

Configuration File - Examples

Introduction

This section contains several examples of the e-mail configuration file "/EMAIL/email.ini".

Minimum Configuration

If no authentication is required and the default value is assigned to the IP port of the SMTP server, the configuration file must contain only the IP address of the SMTP server.

```
[SMTP]
IP      = 192.168.40.1
```

Authentication through POP3 Log-on

In case the e-mail server requires previous log-on through POP3 and an e-mail template containing default setting has been defined:

```
[SMTP]
IP      = 192.168.40.1

[POP3]
IP      = 192.168.40.1
USER    = JetControl4711
PASSWORD = Pop3PassWord

[DEFAULT]
MAILCFG = EmailDefaults.cfg
```

Authentication through SMTP

In case the e-mail server requires an encrypted authentication:

```
[SMTP]
IP      = 192.168.40.1
USER    = JetControl0815
PASSWORD = MyPassWord
```

11.6.2 Creating E-Mails

Introduction

This chapter gives a description on how to create e-mails so as to allow sending them from within the application program.

For each e-mail the user has to create an e-mail template file.

Contents

Topic	Page
Name of the E-Mail Template File	234
Structure of the E-Mail Template File.....	235
Inserting Realtime Controller Values	237

Name of the E-Mail Template File

Introduction

The name of an e-mail template file consists of a constant part of the name and a variable part. The variable part of the name allows the application program to choose an e-mail for sending.

File Name

email_#.cfg

Part of the name	Description
email_	Constant prefix
#	Number of e-mail; value between 0 and 255
.cfg	Constant file extension

Storage Location

E-mail template files and the configuration file have to be stored to the same directory on the internal flash disk:

/EMAIL

Examples

email_0.cfg
email_37.cfg
email_255.cfg

Structure of the E-Mail Template File

Introduction

An e-mail template file is a text file which is divided into sections. When sending an e-mail, it is compiled based on the information contained in these sections.

E-Mail Template File

- Sections [FROM] and [TO] are mandatory. This information may be specified either in the e-mail to be sent or in the e-mail template file containing the default settings.
- All parameters in this section can be tagged with realtime controller values (refer to *Inserting Realtime Controller Values* on page 184).

[FROM]

Sender

[TO]

Addressee

[CC]

Additional addressee(s)

[SUBJECT]

Subject

[ATTACHMENT]

Complete path and file name

[MESSAGE]

E-mail message text

Sections

[FROM]

Description	E-Mail sender
Comments	Please check with your IT administrator which information has to be entered here.
Length	63 characters
Example	[FROM] JetControl@jetter.de

[TO]

Description	E-mail addressee
Comments	Several addressees are separated by ";".
Length	255 characters
Example	[TO] service@mydomain.com

[CC]

Description	Additional e-mail addressee(s)
Comments	Several addressees are separated by ";".
Length	255 characters
Example	[CC] service@mydomain.com;hotline@mydomain.com

[SUBJECT]

Description	Subject
Length	255 characters
Example	[SUBJECT] Fatal Error

[ATTACHMENT]

Description	Complete name of the file to be attached
Comments	This file must be a text file.
Length	511 characters
Example	[ATTACHMENT] /logfiles/error_report.log

[MESSAGE]

Description	E-mail message text
Comments	Text only message
Length	65,535 characters
Example	[MESSAGE] Have a nice day ! JetControl.

Inserting Realtime Controller Values

Introduction

Actual realtime controller values can be integrated into parameter entries within the sections via tag functions. This way, the contents respectively states of registers, text registers, and flags can be displayed.

Tag Delimiters

All tags start and end with defined strings. Between these tag delimiters variables can be defined:

Delimiter	String
Tag start	<JW:DTAG
Tag end	/>

Defining Variables

The variable definition in a tag contains attributes which are used to set, for example, how the value of a variable is to be displayed:

name

Function	Variable Name
Comments	Code letter followed by the variable number
Example	name="R1000023"

type

Function	Variable type of notation
Example	type="REAL"

format

Function	Representation format
Comments	Refer to format definition
Example	format="+0####.###"

factor

Function	Factor by which the realtime controller value is multiplied
Comments	This operation is executed prior to adding the offset
Example	factor="1.5"

offset

Function	Value which is added to the realtime controller value
Comments	This operation is executed after multiplication by the factor
Example	offset="1000"

Format Definition

The representation of variables can be defined by means of their attribute.

- The number of digits/characters used for representing a variable can be defined by the character "#".
- Prefix "0" allows to output leading zeroes. This option applies to the following register types: INT, INTX and REAL.
- Prefix "+" allows to output a sign. This option applies to the following register types: INT, and REAL.
- Prefixing a blank allows to output a space character for positive values. This option applies to the following register types: INT, and REAL.

Registers / Text Registers

The variable name begins with a capital "R" followed by the register number. The following types are possible:

Type	Notation
INT	Integer, decimal
INTX	Integer, hexadecimal
INTB	Integer, binary
BOOL	Register content = 0 --> Display: 0 Register content != 0 --> Display: 1
REAL	Floating point, decimal
STRING	Text register

Standard type: INT

Example:

```
<JW:DTAG name="R1000250" type="REAL" format="+0#####.###"
factor="3.25" offset="500" />
```

Result:

The content of register 1000250 is multiplied by 3.25. Then, 500 is added to the product, and the result is displayed with sign and at least five integer positions. Leading zeros are added if necessary. Furthermore, three decimal positions are inserted.

Flags

The variable name begins with a capital "F" followed by the flag number.

The following types are possible:

Type	Notation
BOOL	Flag = 0 --> Display: 0 Flag = 1 --> Display: 1
STRING	Flag = 0 --> Display: FALSE Flag = 1 --> Display: TRUE

Standard type: BOOL

Example:

```
<JW:DTAG name="F100" type="STRING" format="#" />
```

Result:

The state of flag 100 is inserted as string "T" or "F".

Access via Pointer Register

Access via pointer register is realized by inserting the capital letter "P" in front of the variable name. In each case the value of the variable is displayed whose number corresponds to the content of the register specified in the variable name.

Examples:

```
<JW:DTAG name="PR1000300" />
```

Result: The content of the register is displayed whose number is contained in register 1000300.

```
<JW:DTAG name="PF1000300" />
```

Result: The state of the flag is displayed whose number is contained in register 1000300.

Access via Pointer Register and Offset

To specify the number of the variable to be displayed, it is also possible to add a constant value or another register content to the pointer register value

Examples:

```
<JW:DTAG name="PR1000300 + 100" />
```

Result: The content of the register is displayed whose number results from the addition of the content of register 1000300 and value 100.

```
<JW:DTAG name="PR1000300 + R1000100" />
```

Result: The content of the register is displayed whose number results from the addition of the content of register 1000300 and the content of register 1000100.

```
<JW:DTAG name="PF1000300 + 100" />
```

Result: The state of the flag is displayed whose number results from the addition of the content of register 1000300 and value 100.

```
<JW:DTAG name="PF1000300 + R1000100" />
```

Result: The state of the flag is displayed whose number results from the addition of the content of register 1000300 and the content of register 1000100.

11.6.3 Sending an E-Mail

Introduction

This chapter gives a description on how to send previously created e-mails from within the application program.

When sending an e-mail from the application program, the JVM-407 creates the e-mail based on the e-mail template file and inserts variable values if required.

Processing by the Application Program

Sending an e-mail may take considerable time. Therefore, other tasks of the application program are processed while an e-mail is being sent. However, only one e-mail function call can be carried out at a time. While an e-mail of a task is being sent, all other tasks which invoke the e-mail function are therefore blocked until this operation is completed.

Contents

Topic	Page
Sending E-Mails Using the System Function.....	241
Sample Program	242

Sending E-Mails Using the System Function

Introduction

A system function is used for sending e-mails.

JetSym STX

```
Systemfunction(110, &RegEmailNo, &RegResult);
```

Parameter	Description
RegEmailNo	Number of the register that contains the number of the e-mail to be sent. This number is part of the file name of the e-mail template file.
RegResult	Number of the register to which the result of this function will be stored.

Return Value

This function will produce one of the following return values:

Result	Description	Possible error cause
0	No error	
-1	Insufficient memory	Operating system error
-2	FROM not defined	The e-mail template file is faulty or could not be located.
-3	TO not defined	Error in e-mail template file
-4	No connection to the e-mail server or error during data transfer to the e-mail server.	<ul style="list-style-type: none"> ▪ No e-mail server available ▪ An error occurred during configuration using file "/EMAIL/email.ini" ▪ Data transfer error
-10	E-mail function not available. Bit 2 in register "Web status" not reset	Initialization error. For example, configuration file "/EMAIL/email.ini" does not exist or is faulty.
-12	Internal error	Operating system error

Sample Program

E-Mail Template File

The e-mail template file is stored to the JVM-407 under the name "/EMAIL/email_0.cfg".

```
[FROM]
JVM-407

[TO]
test1@test.mail

[CC]
test2@test.mail

[SUBJECT]
Test <JW:DTAG name="R1000000" />

[ATTACHMENT]
/System/config.ini

[MESSAGE]
Register 1000001 (int) = <JW:DTAG name="R1000001"
                        format="+0#####" />
Register 1000001 (hex) = <JW:DTAG name="R1000001"
                        type="INTX" />
Text register: <JW:DTAG name="R1001000"
                type="STRING" />
Float register: <JW:DTAG name="R1001900" type="REAL"
                factor="2.35" offset="100" />
Flag 10: <JW:DTAG name="F10" type = "STRING" />
Output R[1000113] = <JW:DTAG name="PO1000113"
                    type="BOOL" />

Have a nice day...
JVM-407
```

JetSym STX Program

Set "bSend" to cause an e-mail to be sent.

```
Var
Counter:    Int    At %VL 1000000;
TestReg:    Int    At %VL 1000001;
TextReg:    String At %VL 1001000;
FloatReg:   Float  At %VL 1001900;

RegEmail:   Int    At %VL 1000200;
RegResult:  Int    At %VL 1000201;
Send:       Bool;
End_Var;
```

```
Task SendMail Autorun
  Counter := 0;
  TestReg := 1234;
  TextReg := 'Hello World !';
  FloatReg := 20.5;
  RegEmail := 0;
  Loop
    Send := False;
    When Send Continue;
    Inc(Counter);
    SystemFunction(110, &RegEmail, &RegResult);
  End_Loop;
End_Task;
```

11.6.4 Registers

Introduction

This chapter gives a description of those registers from which the status of e-mail processing can be seen.

Contents

Topic	Page
Overview of Registers	245
Register Description	246

Overview of Registers

Introduction

The JVM-407 provides several registers from which the status of e-mail processing can be seen.

Overview of Registers

Register(s)	Description
202930	Web status
292932	IP address of SMTP server
292933	IP address of POP3 server
292934	Port number of SMTP server
292935	Port number of POP3 server
292937	Status of e-mail processing
292938	ID of the task that is just sending an e-mail

Register Description

R 202930

Web Status

In register "Web status" all available functions are displayed (bit-coded).

Meaning of the Individual Bits

Bit 0 FTP Server

1 = available

Bit 1 HTTP Server

1 = available

Bit 2 E-Mail

1 = available

Bit 3 Data File Function

1 = available

Bit 4 Modbus/TCP

1 = existing

Bit 5 Modbus/TCP

1 = available

Module Register Properties

Access Read access

Value following a reset Depending on options purchased

R 292932

IP Address of SMTP Server

From this register the IP address of the SMTP server can be seen as it has been specified in the file "/EMAIL/email.ini".

Module Register Properties

Access Read access

Value following a reset Depending on configuration

Takes effect once R 202930.2 = 1

R 292933

IP Address of POP3 Server

From this register the IP address of the POP3 server can be seen as it has been specified in the file "/EMAIL/email.ini".

Module Register Properties

Access	Read access
Value following a reset	Depending on configuration
Takes effect	once R 202930.2 = 1

R 292934**Port Number of SMTP Server**

From this register the port number of the SMTP server can be seen as it has been specified in the file "/EMAIL/email.ini".

Module Register Properties

Access	Read access
Value following a reset	Depending on configuration
Takes effect	once R 202930.2 = 1

R 292935**Port Number of POP3 Server**

From this register the port number of the POP3 server can be seen as it has been specified in the file "/EMAIL/email.ini".

Module Register Properties

Access	Read access
Value following a reset	Depending on configuration
Takes effect	once R 202930.2 = 1

R 292937**Status of E-Mail Processing**

With the help of this registers the user can track the e-mail status.

Module Register Properties

Values	0	No e-mail is being sent
	1	Parameters are being handed over to the e-mail client of the JVM-407
	2	E-mail is being compiled and connection with the server is being established.
	3	E-mail was sent to the server
Access	Read access	

R 292938

Task ID (E-Mail)

The ID of the task that is just sending an e-mail can be seen from this register

Module Register Properties

Values	0 ... 99	Task ID
	255	None of the tasks is sending an e-mail
Value following a reset	255	
Access	Read access	

11.7 Modbus/TCP

Introduction

This chapter describes the functions of the Modbus/TCP server and client integrated into JVM-407.

Required Programmer's Skills

To be able to use the functions described in this chapter, the following skills are required:

- The user must be familiar with Modbus/TCP and the supported commands.
- The user must be familiar with IP networks.

Contents

Topic	Page
Modbus/TCP Server	250
Modbus/TCP Client.....	255

11.7.1 Modbus/TCP Server

Introduction	<p>In the case of a valid license (Modbus/TCP feature is enabled) and after successful launch of the Modbus/TCP server, an external client can access registers, inputs and outputs.</p> <p>This chapter covers the addressing process and describes the commands supported by the Modbus/TCP server.</p>
Number of Possible Connections	<p>4 connections may be opened at the same time.</p>
Restriction	<p>Modbus/TCP only supports transmission of registers with a width of 16 bits. From this follows, that only the lower-order 16 bits are transmitted when 32-bit registers are sent.</p> <p>When assigning incoming register values to the internal 32-bit registers no sign extension will be carried out.</p>

Contents

Topic	Page
Addressing	251
Supported Commands - Class 0.....	252
Supported Commands - Class 1.....	253
Supported Commands - Class 2.....	254

Addressing

Introduction

The addresses which have been received via Modbus/TCP can be modified locally in the server. For this purpose, three registers have been provided. The respective basic address for accessing registers, inputs and outputs can be entered into these registers. Then, the address contained in the Modbus/TCP frame specifies the address with reference to the basic address.

R 272702

Register offset

The basic address for accessing registers via Modbus/TCP is entered into R 272702.

Module register properties

Value after reset	1000000
-------------------	---------

R 272704

Input offset

The basic address for accessing inputs via Modbus/TCP is entered into R 272704.

Module register properties

Value after reset	100000000
-------------------	-----------

R 272705

Output offset

The basic address for accessing outputs via Modbus/TCP is entered into R 272705.

Module register properties

Value after reset	100000000
-------------------	-----------

Example 1

The Modbus/TCP server on the JVM-407 receives from a Modbus/TCP client the command **read multiple registers** starting from register number 100. The number of registers to be read is 5. Register 272702 *Register Offset* contains value 1000000.

Hence, registers 1000100 through 1000104 are read.

Supported Commands - Class 0

fc 3

read multiple registers

Reading register blocks:

The starting register number within JVM-407 is calculated as follows: Register number specified in the command plus the content of register 272702 *Register Offset*.

fc 16

write multiple registers

Writing register blocks

The starting register number within JVM-407 is calculated as follows: Register number specified in the command plus the content of register 272702 *Register Offset*.

Supported Commands - Class 1

fc 1	read coils
	Reading outputs.
	The output number within the JVM-407 is calculated as follows: Output number specified in the command plus the content of register 272705 <i>Output Offset</i> .
fc 2	read input discretes
	Reading inputs.
	The input number within JVM-407 is calculated as follows: Input number specified in the command plus the content of register 272704 <i>Input Offset</i> .
fc 4	read input registers
	Reading inputs blockwise in 16-bit words.
	The starting register number within JVM-407 is calculated as follows: Register number specified in the command plus the content of register 272702 <i>Register Offset</i> .
fc 5	write coil
	Enabling/disabling an individual output.
	The output number within the JVM-407 is calculated as follows: Output number specified in the command plus the content of register 272705 <i>Output Offset</i> .
fc 6	write single register
	Entering values into the lower-order 16 bits of a register.
	The starting register number within JVM-407 is calculated as follows: Register number specified in the command plus the content of register 272702 <i>Register Offset</i> .

Supported Commands - Class 2

fc 15

force multiple coils

Enabling/disabling several outputs

The output number within the JVM-407 is calculated as follows: Output number specified in the command plus the content of register 272705 *Output Offset*.

fc 23

read / write registers

Reading/writing registers simultaneously

The starting register number within JVM-407 is calculated as follows: Register number specified in the command plus the content of register 272702 *Register Offset*.

11.7.2 Modbus/TCP Client

Introduction

The Modbus/TCP client included in JVM-407 supports only Class 0 Conformance. This means that commands for reading and writing multiple registers are used. Up to 125 registers with a width of 16 bits can be transmitted in one frame.

As protocol ID "0" is used. Assignment of sent and received frames is carried out using the transaction ID.

This chapter describes how to carry out acyclical or cyclical transmission to a Modbus/TCP server using system functions.

Number of Possible Connections

Connections to 11 different Modbus/TCP servers may be opened at the same time.

Acyclical Data Transmission

System functions 65 and 67 (reading registers), as well as 66 and 68 (writing registers) can be used to establish a acyclical transmission channel to a Modbus/TCP server.

These system functions establish a connection to the specified Modbus/TCP server, transmit the desired data and clear down the connection.

If RemoteScan has already established a connection (cyclical data transmission), this connection will be used. Setting-up and clearing-down the connection is, therefore, not required.

Cyclical Data Transmission

The configurable function **RemoteScan** is for cyclically transferring the inputs and outputs 20001 through 36000 that are combined in the 16-bit registers 278000 through 278999 from and to the configured Modbus/TCP servers.

Only one connection is established to each Modbus/TCP server (IP address and port) irrespective of the number of communication units which have been configured on this server.

If several communication units are configured on one Modbus/TCP server, accesses are serialized since servers often do not support "command pipelining". If several servers have been configured, communication is carried out in parallel.

Combined Inputs / Outputs

Registers	Inputs and Outputs
278000	20001 ... 20016
278001	20017 ... 20032
278002	20033 ... 20048
...	...
278999	35985 ... 36000

These registers and inputs/outputs mapped to them are merely storage cells within the RAM. The registers are not directly mapped to the hardware. Therefore, it is not defined whether inputs or outputs are mapped to a register. Assignment is made not until configuration in the communication units takes place.

Unit ID

The instruction header of a Modbus/TCP telegram contains a *Unit ID*. This "Unit ID" is not evaluated by Modbus/TCP devices, as they can be addressed without ambiguity by their IP address. Therefore, in the case of system functions 65, 66 and 80 always value "1" is sent.

Converters from Modbus/TCP to Modbus RTU use the *Unit ID* for addressing the Modbus RTU servers. Therefore, the corresponding special functions for reading and writing registers (system functions 67 and 68), as well as for initializing RemoteScan (system function 85) have been provided. These special functions can be used to set the "Unit ID".

Restriction

Modbus/TCP only supports transmission of registers with a width of 16 bits. From this follows, that only the lower-order 16 bits are transmitted when 32-bit registers are sent.

When assigning incoming register values to the internal 32-bit registers no sign extension will be carried out.

Contents

Topic	Page
System Function 65: Acyclical Reading of Registers	257
System Function 67: Acyclical Reading of Registers	259
System Function 66: Acyclical Writing of Registers	261
System Function 68: Acyclical Writing of Registers	263
Example of an Application.....	265

System Function 65: Acyclical Reading of Registers

Introduction

Using system function 65, a register block from a Modbus/TCP server is copied to the registers of the local memory.

Important Notes

- While this system function is being carried out, simultaneous calls of this function in other tasks are blocked until this function will be completed.
- While this system function is being executed, it is not advisable to carry out TaskBreak or TaskRestart for this task or to restart the program via JetSym. In the a.m. cases the connection remains open and it might happen that further communication is blocked.
- The IP address is always to be specified directly. It cannot be specified using names.

Function Declaration

```
Systemfunction(65, &StructModbusTCP, &RegResult);
```

Parameter	Function
StructModbusTCP	Structure of the type MODBUS_TCP
RegResult	Number of the register to which the result of this function will be stored.

Type Declaration MODBUS_TCP

Type

```
MODBUS_TCP:
Struct
  IPaddress    : Int;
  Port         : Int;
  Timeout: Int;
  Source       : Int;
  Destination  : Int;
  Values       : Int;
End_Struct;
End_Type;
```

Function Parameters

Parameter	Value	Comment
IPaddress	IP-Address of Modbus/TCP Server	direct input
Port	502	
Timeout	in ms	
Source	remote	Register number of source
Destination	local	Register number of destination
Values	1 ... 125	Quantity of registers

Return Value

This function will produce one of the following return values:

Return Value	
0	No error
-1 or -2	Error during connection set-up
-4	Error during data transfer
-5	Error message from Modbus/TCP Server
-8	Timeout
-10	No Modbus/TCP license

Related Topics

- **Example of an Application** on page 265
-

System Function 67: Acyclical Reading of Registers

Introduction

Using system function 67, a register block from a Modbus/TCP server is copied to the registers of the local memory.

Unlike system function 65, the Unit ID can be set here.

Important Notes

- While this system function is being carried out, simultaneous calls of this function in other tasks are blocked until this function will be completed.
- While this system function is being executed, it is not advisable to carry out TaskBreak or TaskRestart for this task or to restart the program via JetSym. In the a.m. cases the connection remains open and it might happen that further communication is blocked.
- The IP address is always to be specified directly. It cannot be specified using names.

Function Declaration

```
Systemfunction(67, &StructModbusTCP, &RegResult);
```

Parameter	Function
StructModbusTCP	Structure of the type MODBUS_TCP
RegResult	Number of the register to which the result of this function will be stored.

Type Declaration MODBUS_TCP

```
Type
MODBUS_TCP:
Struct
  IPaddress      : Int;
  Port           : Int;
  Timeout: Int;
  Source         : Int;
  Destination   : Int;
  Values         : Int;
  UnitID        : Int;
  Internal_1    : Int;
  Internal_2    : Int;
End_Struct;
End_Type;
```

Function Parameters

Parameter	Value	Comment
IPaddress	IP-Address of Modbus/TCP Server	direct input
Port	502	
Timeout	in ms	
Source	remote	Register number of source
Destination	local	Register number of destination
Values	1 ... 125	Quantity of registers
UnitID	0 ... 255	Unit ID
Internal_1	0	Internal usage
Internal_2	0	Internal usage

Return Value

This function will produce one of the following return values:

Return Value

0	No error
-1 or -2	Error during connection set-up
-4	Error during data transfer
-5	Error message from Modbus/TCP Server
-8	Timeout
-10	No Modbus/TCP license

System Function 66: Acyclical Writing of Registers

Introduction

Using system function 66, the content of registers contained in the local memory is copied to the Modbus/TCP server as a register block.

Important Notes

- While this system function is being carried out, simultaneous calls of this function in other tasks are blocked until this function will be completed.
- While this system function is being executed, it is not advisable to carry out TaskBreak or TaskRestart for this task or to restart the program via JetSym. In the a.m. cases the connection remains open and it might happen that further communication is blocked.
- The IP address is always to be specified directly. It cannot be specified using names.

Function Declaration

```
Systemfunction(66, &StructModbusTCP, &RegResult);
```

Parameter	Function
StructModbusTCP	Structure of the type MODBUS_TCP
RegResult	Number of the register to which the result of this function will be stored.

Type Declaration MODBUS_TCP

Type

```
MODBUS_TCP:
Struct
  IPaddress    : Int;
  Port         : Int;
  Timeout: Int;
  Source       : Int;
  Destination  : Int;
  Values       : Int;
End_Struct;
End_Type;
```

Function Parameters

Parameter	Value	Comment
IPaddress	IP-Address of Modbus/TCP Server	direct input
Port	502	
Timeout	in ms	
Source	local	Register number of source
Destination	remote	Register number of destination
Values	1 ... 125	Quantity of registers

Return Value

This function will produce one of the following return values:

Return Value	
0	No error
-1 or -2	Error during connection set-up
-4	Error during data transfer
-5	Error message from Modbus/TCP Server
-8	Timeout
-10	No Modbus/TCP license

Related Topics

- **Example of an Application** on page 265
-

System Function 68: Acyclical Writing of Registers

Introduction

Using system function 68, the content of registers contained in the local memory is copied to the Modbus/TCP server as a register block.

Unlike system function 66, the Unit ID can be set here.

Important Notes

- While this system function is being carried out, simultaneous calls of this function in other tasks are blocked until this function will be completed.
- While this system function is being executed, it is not advisable to carry out TaskBreak or TaskRestart for this task or to restart the program via JetSym. In the a.m. cases the connection remains open and it might happen that further communication is blocked.
- The IP address is always to be specified directly. It cannot be specified using names.

Function Declaration

```
Systemfunction(68, &StructModbusTCP, &RegResult);
```

Parameter	Function
StructModbusTCP	Structure of the type MODBUS_TCP
RegResult	Number of the register to which the result of this function will be stored.

Type Declaration MODBUS_TCP

```
Type
MODBUS_TCP:
  Struct
    IPaddress      : Int;
    Port           : Int;
    Timeout        : Int;
    Source         : Int;
    Destination    : Int;
    Values         : Int;
    UnitID         : Int;
    Internal_1     : Int;
    Internal_2     : Int;
  End_Struct;
End_Type;
```

Function Parameters

Parameter	Value	Comment
IPaddress	IP-Address of Modbus/TCP Server	direct input
Port	502	
Timeout	in ms	
Source	local	Register number of source
Destination	remote	Register number of destination
Values	1 ... 125	Quantity of registers
UnitID	0 ... 255	Unit ID
Internal_1	0	Internal usage
Internal_2	0	Internal usage

Return Value

This function will produce one of the following return values:

Return Value

0	No error
-1 or -2	Error during connection set-up
-4	Error during data transfer
-5	Error message from Modbus/TCP Server
-8	Timeout
-10	No Modbus/TCP license

Example of an Application

Task	<p>JetControl is to cyclically exchange I/O data with two Modbus/TCP servers on the network.</p> <p>On external request, the content of a single register is to be sent to one of the two communication partners.</p>
Solution	<p>For cyclic data transmission the function "RemoteScan" is used. System functions 80 and 81 are executed one after the other.</p> <p>The value contained in a single register is sent to the second communication partner in acyclical mode using system function 66.</p>
Action	<p>First, the configuration data are entered into the structures required for configuring the RemoteScan function. The starting address of these structures is transferred along with other data when system function 80 (InitRscan) is invoked. If initialization was successful, RemoteScan function is started via system function 81 (StartRscan) and cyclic communication sets in.</p> <p>Then, the parameter structure for acyclic data transmission is prepared. Setting flag "Send" triggers a register block to be sent to a second communication partner one time.</p>

JetSym STX Program

Type

```

RSCAN_HEADER:
Struct
    Protocol      :   Int;
    Units         :   Int;
End_Struct;

RSCAN_ELEMENT:
Struct
    Ipadress      :   Int;
    Port          :   Int;
    UpdateRate    :   Int;
    OutRegs       :   Int;
    OutSource     :   Int;
    OutDestination : Int;
    InRegs        :   Int;
    InSource      :   Int;
    InDestination : Int;
    Status        :   Int;
    Timeout       :   Int;
End_Struct;

RSCAN_STATUS:
Struct
    Status        :   Int;
    Error         :   Int;
    ErrCnt        :   Int;

```

```
End_Struct;

MODBUS_TCP:
Struct
    Ipadress      : Int;
    Port          : Int;
    Timeout       : Int;
    Source        : Int;
    Destination   : Int;
    Values        : Int;
End_Struct;
End_Type;

Const
    RscanRegs      = 1000100;
    RscanStatRegs  = 1001000;
    Elements       = 2;

    InitRscan      = 80;
    StartRscan     = 81;

    ProtModbusTCP  = 5;
    ModbusTCP      = 502;

    Rscan          = 0;
End_Const;

Var
    RemoteScan     : RSCAN_HEADER At %VL RscanRegs;

    RscanElements  : Array[Elements] Of RSCAN_ELEMENT At
                    %VL RscanRegs + Regsizeof(RSCAN_HEADER);

    RscanStatus    : Array[Elements] Of RSCAN_STATUS At
                    %VL RscanStatRegs;

    ModbusTCP      : MODBUS_TCP At %VL 1000500;

    Result         : Int          At %VL 1000099;
    Send           : Bool         At %MX 1;
End_Var;

Task tRscan Autorun
    RemoteScan.Protocol := ProtModbusTCP;
    RemoteScan.Units    := Elements;

    // first communication unit
    RscanElements[0].Ipadress := IP#192.168.10.211;
```

```
RscanElements[0].Port           := ModbusTCPPort;
RscanElements[0].UpdateRate     := 50;
RscanElements[0].OutRegs        := 3;
RscanElements[0].OutSource      := 278000;
RscanElements[0].OutDestination := 20000;
RscanElements[0].InRegs         := 3;
RscanElements[0].InSource       := 21000;
RscanElements[0].InDestination := 278100;
RscanElements[0].Status         := &RscanStatus[0];
RscanElements[0].Timeout        := 20;

// second communication unit
RscanElements[1].Ipaddress      := IP#192.168.10.150;
RscanElements[1].Port           := ModbusTCPPort;
RscanElements[1].UpdateRate     := 20;
RscanElements[1].OutRegs        := 5;
RscanElements[1].OutSource      := 278300;
RscanElements[1].OutDestination := 20000;
RscanElements[1].InRegs         := 10;
RscanElements[1].InSource       := 25000;
RscanElements[1].InDestination := 278400;
RscanElements[1].Status         := &RscanStatus[1];
RscanElements[1].Timeout        := 200;

Systemfunction(InitRscan, &RemoteScan, &Result);
If Result > 0 Then
    Systemfunction(StartRscan, 0, &Result);
End_If;

ModbusTCP.Ipaddress      := IP#192.168.10.212;
ModbusTCP.Port           := ModbusTCPPort;
ModbusTCP.Values         := 1;
ModbusTCP.Source         := 1040000;
ModbusTCP.Destination    := 1050000;
ModbusTCP.Timeout        := 100;
Send                     := False;

Loop
    When Send Continue;
    Systemfunction(66, &ModbusTCP, &Result);
    Send := False;
End_Loop;

End_Task;
```

11.8 User-programmable IP Interface

The user-programmable IP interface

The user-programmable IP interface allows to send or receive data via Ethernet interface on the JVM-407 using TCP/IP or UDP/IP. When using this feature, data processing is completely carried out by the application program.

Applications

The user-programmable IP interface allows the programmer to exchange data via Ethernet connections which do not use standard protocols, such as FTP, HTTP, JetIP or Modbus/TCP. The following applications are possible:

- Server
- Client
- TCP/IP
- UDP/IP

Required Programmer's Skills

To be able to program user-programmable IP interfaces the following knowledge of data exchange via IP networks is required:

- IP addressing (e.g. IP address, port number, subnet masks etc.)
- TCP (e.g. connection establishment/termination, data stream, data backup etc.)
- UDP (e.g. datagram, etc.)

Restrictions

For communication via user-programmable IP interface, ports which are already used by the operating system of the controller must NOT be used. Therefore, do not use the following ports:

Protocol	Port number	Default value	User
TCP	depending on the FTP client	20	FTP server (data)
TCP	21		FTP server (controller)
TCP	23		System logger
TCP	80		HTTP server
TCP	from file /EMAIL/email.ini	25, 110	e-mail client
TCP	502		Modbus/TCP Server
TCP, UDP	1024 - 2047		various users
TCP, UDP	IP configuration	50000, 50001	JetIP
TCP	IP configuration	52000	Debug server

Contents

Topic	Page
Programming	270
Registers.....	282
Sample Programs	287

11.8.1 Programming

Introduction

The user-programmable IP interface is used to exchange data between application program and network clients via TCP/IP or UDP/IP connections. For this purpose, function calls are used. These function calls are included in the programming language of the JVM-407. Carry out the following steps to program this feature:

Step	Action
1	Initializing the user-programmable IP interface
2	Establishing the connection(s)
3	Transferring data
4	Terminating the connection(s)

Technical Data

Technical data of the user-programmable IP interface:

Feature	Description
Number of connections	20
Maximum data size	4,000 bytes

Restrictions

In the application program, tasks serving the user-programmable IP interface should not be stopped through `TaskBreak` or restarted through `TaskRestart` while the JVM-407 is processing one of these functions. Failure to do so could result in the following errors:

- Connections are not opened
- Data loss during sending or receiving
- Connections, which should be terminated, remain established
- Connections, which should be used, are terminated

Contents

Topic	Page
Initializing the User-Programmable IP Interface	271
Establishing a Connection	272
Sending Data	276
Receiving Data.....	278
Terminating a Connection	281

Initializing the User-Programmable IP Interface

Introduction The user-programmable IP interface must be initialized at least each time the application program is launched.

Function Declaration `Function ConnectionInitialize():Int;`

Return Value The following return value is possible:

Result of the function

0	always
---	--------

Using the Function This function can be used and its return value be assigned to a variable for further utilization in the following way:

```
Result := ConnectionInitialize();
```

Operating Principle The JVM-407 processes the function in the following steps:

Stages	Description
1	All established connections of the user-programmable IP interface are terminated
2	All OS-internal data structures of the user-programmable IP interface are initialized

Related Topics:

- **Establishing a connection** on page 272
 - **Terminating a connection** on page 281
 - **Sending data** on page 276
 - **Receiving data** on page 278
-

Establishing a Connection

Introduction

Before data can be sent or received, a connection has to be established. In doing so, it must be decided which transport protocol (TCP or UDP) is to be used and whether a client or a server should be established.

Function Declaration

```
Function ConnectionCreate(ClientServerType: Int,
                        IPType: Int,
                        IPAddr: Int,
                        IPPort: Int,
                        Timeout: Int): Int;
```

Function Parameters

Description of function parameters:

Parameter	Value	Comment
ClientServerType	Client = 1 = CONNTYPE_CLIENT Server = 2 = CONNTYPE_SERVER	
IPType	UDP/IP = 1 = IPTYPE_UDP TCP/IP = 2 = IPTYPE_TCP	
IPAddr	Valid IP address	Required only for TCP/IP client
IPPort	Valid IP port	Will be ignored for UDP/IP client
Timeout	0 .. 1,073,741,824 [ms]	0 = infinitely

Return Value

If the return value is positive, the connection could have been established. If the return value is negative, an error occurred and the connection could not be established.

Return Value

> 0	A positive return value must be stored to a variable, since it has to be passed on as handle with functions for receiving and sending data via this connection, as well as for terminating this connection.
-1	Error during connection set-up
-2	Internal error
-3	Invalid parameter
-8	Timeout

Using this Function with a TCP/IP Client

This function can be used and its return value be assigned to a variable for further utilization in the following way if a client is to establish a TCP/IP connection to a server:

```
Result := ConnectionCreate(CONNTYPE_CLIENT,
```



```

IPTYPE_TCP,
IP#192.168.75.123,
46000,
T#10s);
    
```

Functioning Principle with a TCP/IP Client

The task stops at the program line until the connection is established or the specified timeout has elapsed. The following stages are taken when processing this function:

Stage	Description	
1	The JVM-407 tries to establish a TCP/IP connection via port 46000 to the network client with IP address 192.168.75.123.	
2	If Then ...
	the network client has accepted the connection	the function is terminated and a positive value is returned as handle for further access to the connection
	the connection could not be established and the timeout of 10 seconds has not elapsed	stage 1 is carried out
	an error has occurred or the timeout has elapsed	the function is terminated and a negative value is returned

Using this Function with a TCP/IP Server

This function can be invoked and its return value be assigned to a variable for further utilization in the following way if a server is to establish a TCP/IP connection to a client:

```

Result := ConnectionCreate(CONNTYPE_SERVER,
                            IPTYPE_TCP,
                            0,
                            46000,
                            T#100s);
    
```

Functioning Principle with a TCP/IP Server

The task stops at the program line until the connection is established or the specified timeout has elapsed. The following stages are taken when processing this function:

Stage	Description	
1	The JVM-407 sets up TCP/IP port 46000 for receiving connection requests	
2	If Then ...
	the network client has established an connection	no further connection requests to this port are accepted, the function is terminated and a positive value is returned as handle for further access to the connection
	the connection has not been established and the timeout of 100 seconds has not elapsed	the system waits for a connection being established
	an error has occurred or the timeout has elapsed	the function is terminated and a negative value is returned

Using this Function with a UDP/IP Client

This function can be invoked and its return value be assigned to a variable for further utilization in the following way if a client is to establish a UDP/IP connection:

```
Result := ConnectionCreate(CONNTYPE_CLIENT,
                           IPTYPE_UDP,
                           0,
                           0,
                           0);
```

Functioning Principle with a UDP/IP Client

As UDP is a connectionless type of communication, the controller simply opens a communication channel which is used to send data to a network client. The following stages are taken when processing this function:

Stage	Description	
1	The JVM-407 sets up a UDP/IP communication channel for sending data	
2	If Then ...
	no error has occurred	the function is terminated and a positive value is returned as handle for further access to the connection
	an error has occurred	the function is terminated and a negative value is returned

Using this Function with a UDP/IP Server

This function can be invoked and its return value be assigned to a variable for further utilization in the following way if a server is to establish a UDP/IP connection:

```
Result := ConnectionCreate(CONNTYPE_SERVER,
                           IPTYPE_UDP,
                           0,
                           46000,
                           0);
```

Functioning Principle with a UDP/IP Server

As UDP is a connectionless type of communication, the server simply opens a communication channel over which a network client is able to receive data. The following stages are taken when processing this function:

Stage	Description							
1	The JVM-407 sets up a UDP/IP communication channel at port 46000 for receiving data							
2	<table border="1"> <thead> <tr> <th>If ...</th> <th>... Then ...</th> </tr> </thead> <tbody> <tr> <td>no error has occurred</td> <td>the function is terminated and a positive value is returned as handle for further access to the connection</td> </tr> <tr> <td>an error has occurred</td> <td>the function is terminated and a negative value is returned</td> </tr> </tbody> </table>		If Then ...	no error has occurred	the function is terminated and a positive value is returned as handle for further access to the connection	an error has occurred	the function is terminated and a negative value is returned
If Then ...							
no error has occurred	the function is terminated and a positive value is returned as handle for further access to the connection							
an error has occurred	the function is terminated and a negative value is returned							

Related Topics:

- **Terminating a connection** on page 281
- **Sending data** on page 276
- **Receiving data** on page 278
- **Initializing the user-programmable IP interface** on page 271

Sending Data

Introduction

Data can be sent via a previously established TCP/IP connection or via a UDP/IP connection of a client. Via UDP/IP connection of a server data can not be sent, but only received.

Function Declaration

```
Function ConnectionSendData (IPConnection: Int,
                             IPAddr: Int,
                             IPPort: Int,
                             Const Ref SendData,
                             DataLen: Int): Int;
```

Function Parameters

Description of function parameters:

Parameter	Value	Comment
IPConnection	Handle	Result of the function when establishing the connection
IPAddr	Valid IP address	Required only for UDP/IP client
IPPort	Valid IP port	Required only for UDP/IP client
SendData	Address of the data block to be sent	
DataLen	1 .. 4,000	Data block length in bytes

Return Value

The following return values are possible:

Return Value

0	Data have been sent successfully
-1	Error when sending, e.g. connection interrupted
-3	Invalid handle, e.g. sending via a UDP/IP server

Using this Function with a TCP/IP connection

This function can be invoked and its return value be assigned to a variable for further utilization in the following way if data are to be sent via TCP/IP connection:

```
Result := ConnectionSendData (hConnection,
                              0,
                              0,
                              SendBuffer,
                              SendLen);
```

Functioning Principle with a TCP/IP Connection

When using TCP/IP, data are sent via a previously established connection. Therefore, it is not required to specify the IP address and IP port and can be ignored in the function. The task stops at the command until data have been sent and acknowledgment has been received or an error has occurred.

Using this Function with a UDP/IP Client

This function can be invoked and its return value be assigned to a variable for further utilization in the following way if data are to be sent from a client via

UDP/IP connection:

```
Result := ConnectionData(hConnection,  
                          IP#192.168.75.123,  
                          46000,  
                          SendBuffer,  
                          SendLen);
```

Functioning Principle with a UDP/IP Client

With UDP/IP there is no connection between 2 given network clients. Therefore, with each function call data can be sent to another client or another port. The task will pause at the command until the data are sent. There will be no acknowledgement that the data have been received by the remote network client.

Related Topics:

- **Initializing the user-programmable IP interface** on page 271
 - **Establishing a Connection** on page 272
 - **Terminating a connection** on page 281
 - **Receiving data** on page 278
-

Receiving Data

Introduction

Data can be sent via a previously established TCP/IP connection or via a UDP/IP connection of a server. Via UDP/IP connection of a client data can not be received, but only sent.

Function Declaration

```
Function ConnectionReceiveData (IPConnection: Int,
                               Ref IPAddr: Int,
                               Ref IPPort: Int,
                               Ref ReceiveData,
                               DataLen: Int,
                               Timeout: Int): Int;
```

Function Parameters

Description of function parameters:

Parameter	Value	Comment
IPConnection	Handle	Return value when establishing the connection
IPAddr	Address of a variable for storing the sender's IP Address	Required only for UDP/IP server
IPPort	Address of a variable for storing the sender's IP port	Required only for UDP/IP server
ReceiveData	Address of the data block to be received	
DataLen	1 .. 4,000	Maximum data block length in bytes
Timeout	0 .. 1,073,741,824 [ms]	0 = infinitely

Return Value

The following return values are possible:

Return Value

> 0	Number of received data bytes
-1	Error when receiving data, e.g. connection interrupted
-3	Invalid handle, e.g. receiving data via a UDP/IP client
-8	Timeout

Using this Function with a TCP/IP Connection

This function can be invoked and its return value be assigned to a variable for further utilization in the following way if data are to be received via TCP/IP connection:

```
Result := ConnectionReceiveData (hConnection,
                                Dummy,
                                Dummy,
                                ReceiveBuffer,
                                sizeof (ReceiveBuffer),
                                T#10s);
```

Functioning Principle with a TCP/IP Connection

When using TCP/IP, data are sent via a previously established connection. Therefore, it is not required to specify the IP address and IP port and can be ignored in the function. The task will pause at the command until the data are received or an error has occurred. In case of a TCP/IP connection, data are transmitted as data stream.

The JVM-407 processes the function in the following stages:

Stage	Description							
1	The JVM-407 waits until data have been received, but no longer than the specified timeout							
2	<table border="1"> <thead> <tr> <th>If ...</th> <th>... Then ...</th> </tr> </thead> <tbody> <tr> <td>the timeout has elapsed or the connection has been terminated</td> <td>the function is exited and an error message is issued</td> </tr> <tr> <td>data have been received</td> <td>they are copied to the receiving buffer given along with the data (but not exceeding the amount given along with the data). Then, the function continues with stage 3</td> </tr> </tbody> </table>		If Then ...	the timeout has elapsed or the connection has been terminated	the function is exited and an error message is issued	data have been received	they are copied to the receiving buffer given along with the data (but not exceeding the amount given along with the data). Then, the function continues with stage 3
If Then ...							
the timeout has elapsed or the connection has been terminated	the function is exited and an error message is issued							
data have been received	they are copied to the receiving buffer given along with the data (but not exceeding the amount given along with the data). Then, the function continues with stage 3							
3	<table border="1"> <thead> <tr> <th>If ...</th> <th>... Then ...</th> </tr> </thead> <tbody> <tr> <td>more data have been received than could have been copied into the receiving buffer</td> <td>these data are buffered by the JVM-407 and can be retrieved from within the application by invoking the function several times</td> </tr> </tbody> </table>		If Then ...	more data have been received than could have been copied into the receiving buffer	these data are buffered by the JVM-407 and can be retrieved from within the application by invoking the function several times		
If Then ...							
more data have been received than could have been copied into the receiving buffer	these data are buffered by the JVM-407 and can be retrieved from within the application by invoking the function several times							
4	The function is exited and the number of data, which have been copied into the receiving buffer, is returned							

Using this Function with a UDP/IP Server

This function can be invoked and its return value be assigned to a variable for further utilization in the following way if data are to be received from a server via UDP/IP connection:

```
Result := ConnectionReceiveData(hConnection,
                                IPAddr,
                                IPPort,
                                ReceiveBuffer,
                                sizeof(ReceiveBuffer),
                                T#10s);
```

Functioning Principle with a UDP/IP Server

The task will pause at the command until all of the data are received or an error has occurred. In case of a UDP/IP connection, data are transmitted as datagram.

The JVM-407 processes the function in the following stages:

Stage	Description	
1	The JVM-407 waits until all data of a datagram have been received, but no longer than the specified timeout	
2	If Then ...
	the timeout has elapsed or the connection has been terminated	the function is exited and an error message is issued
	data have been received	they are copied to the receiving buffer given along with the data (but not exceeding the amount given along with the data). Then, the function continues with stage 3
3	If Then ...
	more data have been received than could have been copied into the receiving buffer (that is, if the sent datagram is too large)	these data are discarded
4	The sender's IP address and IP port are transferred into the variables which are given along with the data	
5	The function is exited and the number of data, which have been copied into the receiving buffer, is returned	

Related Topics:

- **Initializing the user-programmable IP interface** on page 271
- **Establishing a Connection** on page 272
- **Terminating a connection** on page 281
- **Sending Data** on page 276

Terminating a Connection

Introduction

Clear all connections which are no longer required as the number of concurrently opened connections is limited.

Function Declaration

```
Function ConnectionDelete(IPConnection:Int):Int;
```

Function Parameters

Description of function parameters:

Parameter	Value	Comment
IPConnection	Handle	Return value when establishing the connection

Return Value

The following return values are possible:

Return Value

0	Connection terminated and deleted
-1	Invalid handle

Using the Function

This function can be invoked and its return value be assigned to a variable for further utilization in the following way:

```
Result := ConnectionDelete(hConnection);
```

Related Topics:

- **Establishing a Connection** on page 272
 - **Sending Data** on page 276
 - **Receiving Data** on page 278
 - **Initializing the user-programmable IP interface** on page 271
-

11.8.2 Registers

Introduction

This chapter describes the registers of a JVM-407 from which the current connection list of the user-programmable IP interface can be read out. These registers can be used for debugging or diagnostic purposes. However, they can't be used for other functions, such as establishing or terminating a connection.

Contents

Topic	Page
Register Numbers	283
Register Description.....	284

Register Numbers

Introduction

Data of one connection each are displayed within the registers of a coherent register block. The basic register number of this block is dependent on the controller.

Register Numbers

Controller	Basic Register Number	Register Numbers
JC-24x	10290	10290 ... 10297
JM-D203-JC24x	10290	10290 ... 10297
JC-340, JC-350, JC-360, JC-940MC, JVM-407	350000	350000 ... 350007

Determining Register Numbers

In this chapter only the last figure of a register number is specified. To calculate the actually used register number the basic register number of the corresponding device must be added.

Overview of Registers

Register(s)	Description
MR 0	Selection of a connection
MR 1	Type of connection
MR 2	Transport protocol
MR 3	IP address
MR 4	IP port
MR 5	Status
MR 6	Number of sent bytes
MR 7	Number of received bytes

Register Description

Introduction

Established connections are managed by the operating system in a list. Module register MR0 *Selection of a connection* is used to copy connection details into other registers of a register block.

MR 0

Selection of a connection

Write access to this register is used to select connections and to display their details in the following registers. Read access is used to display whether the following registers contain connection details.

Module Register Properties

Reading values	0	Connection exists
	-1	Connection does not exist

Module Register Properties

Writing values	0	Address the first connection in the list
	> 0	Address the next connection in the list
	< 0	Address the previous connection in the list

MR 1

Type of connection

The value in this register shows whether the connection is a client or a server connection.

Module Register Properties

Values	1	Client
	2	Server

MR 2

Transport Protocol

The value in this register shows whether TCP or UDP is used as transport protocol.

Module Register Properties

Values	1	UDP
	2	TCP

MR 3**IP Address**

The value in this register shows the configured IP address.

Module Register Properties

Values	0.0.0.0 ... 255.255.255.255
--------	-----------------------------

MR 4**IP Port**

The value in this register shows the configured IP port.

Module Register Properties

Values	0 ... 65,535
--------	--------------

MR 5**Status**

The value in this register shows status the connection is currently in.

Module Register Properties

Values	0	Connection terminated
	1	Connection is being established
	2	Connection is established
	3	TCP/IP server: Waiting for connection request from client
	4	Internal usage

MR 6**Number of sent bytes**

The value in this register shows the number of data bytes sent via the given connection. Since this is a signed 32-bit register and the sent bytes are added each time, the number range may be exceeded from the positive maximum value to the negative maximum value.

Module Register Properties

Values	-2,147,483,648 ... 2,147,483,647
--------	----------------------------------

MR 7

Number of received bytes

The value in this register shows the number of data bytes received via the given connection. Since this is a signed 32-bit register and the received bytes are added each time, the number range may be exceeded from the positive maximum value to the negative maximum value.

Module Register Properties

Values	-2,147,483,648 ... 2,147,483,647
--------	----------------------------------


11.8.3 Sample Programs

Introduction

This chapter contains sample programs for implementing a server and a corresponding client which will use TCP/IP for communication.

Sample Configuration

The examples in this chapter are based on the following configuration:



Number	Component	Function
1	JC-940MC	Controller
2	JC-350	Controller

Due to the platform-independent implementation of the user-programmable IP interface these sample programs can be used for other configurations without modification.

Contents

Topic	Page
Server	288
Client.....	292

Server

Task A server is to receive a data block with a given number of characters and to return the received data to the client.

Solution Programming a server for the user-programmable IP interface. The server communicates via TCP/IP.

Sample Configuration This example is based on the configuration described under *Sample Configuration* on page 287.

JetSym STX Program

```

Const
    TCP_PORT = 52100;
    MSG_LEN  = 4000;
End_Const;

Var
    // connection handle
    ConnHandle      : Int;

    // send buffer
    SendBuf         : Array[MSG_LEN] Of Char;
    // receive buffer
    RecvBuf         : Array[MSG_LEN] Of Char;

    ResConnInit     : Int;
    ResConnCreate   : Int;
    ResConnReceive  : Int;
    ResConnSend     : Int;

    ConnTimeOut     : Int;
    RecvTimeOut     : Int;

    // receive error count
    RecvErrors      : Int;
    // send error count
    SendErrors      : Int;
    // valid communication counter
    CommCnt         : Int;

    AmountToReceive : Int;

    // dummy
    NotUsed         : Int;
End_Var;

Task TCPserver Autorun

    Var

```



```

    RecvTimer      : Timer;
    ReceiveCnt     : Int;
End_Var;

// connection timeout
ConnTimeOut := T#5s;
// reception timeout
RecvTimeOut := T#5s;

// expected amount of data to receive
AmountToReceive := MSG_LEN;

// close all connections, init. data structures
ResConnInit := ConnectionInitialize();

If ResConnInit >= 0 Then

    Trace('Server running.$n');

    While (True) Do

        // try to connect
        ResConnCreate := ConnectionCreate
            ( CONNTYPE_SERVER,
              IPTYPE_TCP,
              0,
              TCP_PORT,
              ConnTimeOut );

        If ResConnCreate > 0 Then

            Trace('Connection established. ');
            // save connection handle
            ConnHandle := ResConnCreate;

            // loop, as long as connection established
            Loop

                // timeout for the complete data packet
                TimerStart(RecvTimeOut, RecvTimeOut * 5);
                // init. receive data counter
                ReceiveCnt := 0;

                // loop until all expected data received or timeout
                While ReceiveCnt < AmountToReceive
                    And Not TimerEnd(RecvTimer) Do

                    ResConnReceive := ConnectionReceiveData
                        ( ConnHandle,
                          NotUsed,
                          NotUsed,

```

```
        RecvBuf[ReceiveCnt],
        SizeOf(RecvBuf),
        RecvTimeout );

If ResConnReceive > 0 Then
    // something received, increment counter
    ReceiveCnt := ReceiveCnt + ResConnReceive;
Else
    // error on receive
    ResConnReceive := -1;
    // increment error counter
    inc(RecvErrors);
    // leave loop
    Exit;
End_If;
End_While;

// here is the point to implement the server function;
// in this example we simply return the received data
If ReceiveCnt Then
    // copy from receive to send buffer
    MemCopy(SendBuf, RecvBuf, SizeOf(SendBuf));
    ResConnSend := ConnectionSendData
                ( ConnHandle,
                  0,
                  0,
                  SendBuf,
                  ReceiveCnt );
    If ResConnSend < 0 Then
        // increment error counter
        Inc(SendErrors);
    End_If;
End_If;

If ResConnSend >= 0 And ResConnReceive >= 0 Then
    // no error --> increment OK counter
    Inc(CommCnt);
Else
    // leave loop
    Exit;
End_If;

End_Loop;

If ConnHandle > 0 Then
    // close connection
    ConnectionDelete(ConnHandle);
    // no longer valid
    ConnHandle := 0;
    Trace('Connection close.$n');
End_If;
```

```
        End_If;

        // wait a little bit before trying to reconnect
        Delay(T#3s);

        End_While;

    Else
        Trace('ConnectionInitialize() failed, server stopped !$n');
    End_If;

End_Task;
```

Related Topics:

- **Client** on page 292
-

Client

Task A client is to send a data block with a given number of characters and to return the data received from the server.

Solution Programming a client for the user-programmable IP interface. The client communicates via TCP/IP.

Sample Configuration This example is based on the configuration described under *Sample Configuration* on page 287.

JetSym STX Program

Const

```
TCP_ADDR = IP#192.168.10.210;
TCP_PORT = 52100;
MSG_LEN = 4000;
```

End_Const;

Var

```
// connection handle
ConnHandle : Int;

// send buffer
SendBuf : Array[MSG_LEN] Of Char;
// receive buffer
RecvBuf : Array[MSG_LEN] Of Char;
```

```
ResConnInit : Int;
ResConnCreate : Int;
ResConnReceive : Int;
ResConnSend : Int;
```

```
ConnTimeOut : Int;
RecvTimeOut : Int;
```

```
// receive error count
RecvErrors : Int;
// send error count
SendErrors : Int;
// valid communication counter
CommCnt : Int;
```

```
AmountToReceive : Int;
SendDelay : Int;
```

```
// dummy
NotUsed : Int;
```

End_Var;

Task TCPclient Autorun

```

Var
    RecvTimer      : Timer;
    ReceiveCnt     : Int;
End_Var;

// connection timeout
ConnTimeOut := T#5s;
// reception timeout
RecvTimeOut := T#5s;

// expected amount of data to receive
AmountToReceive := MSG_LEN;
SendDelay       := T#500ms;

// close all connections, init. data structures
ResConnInit := ConnectionInitialize();

If ResConnInit >= 0 Then

    Trace('Client running.$n');

    While (True) Do

        // try to connect
        ResConnCreate := ConnectionCreate
            ( CONNTYPE_CLIENT,
              IPTYPE_TCP,
              TCP_ADDR,
              TCP_PORT,
              ConnTimeOut );

        If ResConnCreate > 0 Then

            Trace('Connection established. ');
            // save connection handle
            ConnHandle := ResConnCreate;

            // loop, as long as connection established
            Loop

                ResConnSend := ConnectionSendData
                    ( ConnHandle,
                      0,
                      0,
                      SendBuf,
                      AmountToReceive );

                If ResConnSend < 0 Then
                    // increment error counter
                    Inc(SendErrors);
                End_If;
            End_While;
        End_If;
    End_While;

```

```
// timeout for the complete data packet
TimerStart(RecvTimer, RecvTimeOut * 5);
// init. receive data counter
ReceiveCnt := 0;

// loop until all expected data received or timeout
While ReceiveCnt < AmountToReceive
  And Not TimerEnd(RecvTimer) Do

  ResConnReceive := ConnectionReceiveData
    ( ConnHandle,
      NotUsed,
      NotUsed,
      RecvBuf[ReceiveCnt],
      SizeOf(RecvBuf),
      RecvTimeOut );

  If ResConnReceive > 0 Then
    // something received, increment counter
    ReceiveCnt := ReceiveCnt + ResConnReceive;
  Else
    // error on receive
    ResConnReceive := -1;
    // increment error counter
    Inc(RecvErrors);
    // leave loop
    Exit;
  End_If;
End_While;

If ResConnSend >= 0 And ResConnReceive >= 0 Then
  // no error --> increment OK counter
  Inc(CommCnt);
  Delay(SendDelay);
Else
  // leave loop
  Exit;
End_If;

End_Loop;

If ConnHandle > 0 Then
  // close connection
  ConnectionDelete(ConnHandle);
  // no longer valid
  ConnHandle := 0;
  Trace('Connection close.$n');
End_If;

End_If;
```

```
        // wait a little bit before trying to reconnect
        Delay(T#3s);

        End_While;

    Else
        Trace('ConnectionInitialize() failed, client stopped !$n');
    End_If;

End_Task;
```

Related Topics:

- **Server** on page 288
-

11.9 User-Programmable CAN-PRIM Interface

CAN-PRIM Interface The user-programmable CAN-PRIM interface allows to send and receive CAN messages. When using this feature, the CAN messages are completely processed by the application program.

Applications The user-programmable CAN-PRIM interface can be used for the following applications:

- Connection of modules with CAN interface
-

Required Programmer's Skills To be able to program user-programmable CAN-PRIM interfaces basic knowledge of Controller Area Networks (CAN) is required. This knowledge includes:

- Structure of CAN messages
-

Contents

Topic	Page
User-programmable CAN-PRIM interface - Operating Principle	297
Restrictions Regarding the CAN-PRIM Interface.....	298
Programming the CAN-PRIM Interface	299
Internal Processes of the CAN-PRIM Interface	302
Register Description - CAN-PRIM Interface	303
CAN-PRIM Interface - Sample Program.....	309

User-programmable CAN-PRIM interface - Operating Principle

Operating Principle

The user-programmable CAN-PRIM interface uses message boxes for data exchange between CAN bus and application program. Each message box is able to accommodate a complete CAN message.

32 message boxes are available to the user. Each of these boxes can be configured as inbox or outbox with a specific CAN ID.

Technical Data

Function	Description
CAN ID	11-bit or 29-bit
RTR messages	are not supported
Number of message boxes	32

Restrictions Regarding the CAN-PRIM Interface

Only CAN-0

The CAN-PRIM interface of a JVM-407 is available only with CAN-0.

Time Response

The interval between two CAN messages received via CAN-PRIM interface must be at least 10 ms. If the interval is shorter, the HMI JVM-407 is not able to receive all CAN messages.

Earmarked CAN IDs

The following CAN IDs are earmarked as CANopen® is running in parallel:

Earmarked CAN IDs	Description
0x00	With 11-bit NMT
0x600 + node ID and 0x580 + node ID	SDO
0x80	Sync
0x100	Time Stop
0x80 + node ID	Emergency message
0x700 + node ID	Heartbeat
+ related PDOs	In the application project
+ IDs of other CANopen® nodes	

Programming the CAN-PRIM Interface

Overview of Registers

The following registers are used in this manual:

Register	Description
R 200010500	CAN-PRIM status
R 200010501	CAN-PRIM command register
R 200010502	Box number
R 200010503	FIFO buffer filling level
R 200010510	Box status
R 200010511	Box configuration
R 200010512	CAN ID
R 200010513	Number of data bytes
R 200010514	Data byte 0
...	...
R 200010521	Data byte 7

Initialization

To initialize the CAN-PRIM interface configure the length of the CAN ID for all message boxes as follows:

If CAN ID length...	... Then ...
is 11 bits	R 200010501 = 8;
is 29 bits	R 200010501 = 9;

Configuring a Message Box for Sending

To configure a message box for sending proceed as follows:

Step	Action
1	Select message box R 200010502 := Message box number;
2	Configure the message box as inbox R 200010511 := 1;
3	Configure the CAN ID for receiving messages R 200010512 := CAN ID;
4	Activate the box R 200010501 := 1; Result if configuration was successful: Bit 0 = 1 in R 200010510

Sending a CAN Message

To send a CAN message proceed as follows:

Step	Action
1	Select message box R 200010502 := Message box number;
2	Number of bytes to be sent R 200010513 := Number of bytes;
3	Writing the data bytes R 200010514 := Data byte 0; R 200010515 := Data byte 1; ... R 200010521 := Data byte 7;
4	Send data from the selected message box R 200010501 := 3; Result if sending was successful: Bit 3 = 0 in R 200010510

Configuring a Message Box for Receiving

To configure a message box for receiving proceed as follows:

Step	Action
1	Select message box R 200010502 := Message box number;
2	Configure the message box as inbox R 200010511 := 0;
3	Configure the CAN ID for receiving messages R 200010512 := CAN ID;
4	Activate the box R 200010501 := 1; Result if configuration was successful: Bit 0 = 1 in R 200010510

Receiving a CAN Message

To receive a CAN message proceed as follows:

Step	Action				
1	Check bit 1 NEWDAT in R 200010500 <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>If ...</th> <th>... Then ...</th> </tr> </thead> <tbody> <tr> <td>Bit 1 = 1 in R 200010500</td> <td>a CAN message has been received. Proceed with step 2</td> </tr> </tbody> </table>	If Then ...	Bit 1 = 1 in R 200010500	a CAN message has been received. Proceed with step 2
If Then ...				
Bit 1 = 1 in R 200010500	a CAN message has been received. Proceed with step 2				
2	Select the message box which has received a CAN message. R 200010502 := R 200010504;				
3	Check the message box for overflow. <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>If ...</th> <th>... Then ...</th> </tr> </thead> <tbody> <tr> <td>Bit 2 = 1 in R 200010510</td> <td>an overflow has occurred.</td> </tr> </tbody> </table>	If Then ...	Bit 2 = 1 in R 200010510	an overflow has occurred.
If Then ...				
Bit 2 = 1 in R 200010510	an overflow has occurred.				
4	Read the number of received bytes Number of bytes = R 200010513;				
5	Read the received bytes Data byte 0 = R 200010514; Data byte 1 = R 200010515; ... Data byte 7 = R 200010521;				
6	Acknowledge that the message has been received R 200010501 := 4;				
7	The message box is again ready to receive.				

Internal Processes of the CAN-PRIM Interface

Introduction

The CAN-PRIM interface processes the following tasks independently:

- Reception of CAN messages
- Sending of CAN messages
- Filtering of CAN messages on reception

Internal Reception of CAN Messages

The CAN-PRIM interface receives new messages in the following way:

Stage	Description						
1	The CAN bus receives a valid CAN message.						
2	The CAN ID matches the receiving mask.						
3	The CAN ID matches the CAN ID of a message box which has been configured as inbox.						
4	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">If in R 200010510 of the message box ...</th> <th style="text-align: center;">... Then ...</th> </tr> </thead> <tbody> <tr> <td>the NEW DAT bit = 0</td> <td>the NEW DAT bit switches to 1 proceed with stage 5</td> </tr> <tr> <td>the NEW DAT bit = 1</td> <td>the OVERRUN bit switches to 1; CAN message data are discarded.</td> </tr> </tbody> </table>	If in R 200010510 of the message box Then ...	the NEW DAT bit = 0	the NEW DAT bit switches to 1 proceed with stage 5	the NEW DAT bit = 1	the OVERRUN bit switches to 1; CAN message data are discarded.
If in R 200010510 of the message box Then ...						
the NEW DAT bit = 0	the NEW DAT bit switches to 1 proceed with stage 5						
the NEW DAT bit = 1	the OVERRUN bit switches to 1; CAN message data are discarded.						
5	R 200010503 <i>FIFO filling level</i> is incremented.						
6	The message box number is entered into R 200010504 <i>FIFO data</i> .						
7	In R 200010500 <i>CAN-PRIM Status</i> the NEW DAT bit is set to 1.						

Register Description - CAN-PRIM Interface

R 200010500**CAN-PRIM status**

R 200010500 allows to evaluate the status of the CAN-PRIM interface.

Meaning of the individual bits

Bit 1 NEW-DAT

1 = At least one message box has received a new CAN message.

Bit 2 ID length

0 = The length of sent/received CAN IDs is 11 bits

1 = The length of sent/received CAN IDs is 29 bits

Module register properties

Type of access Read access

Value after reset CAN-PRIM interface is enabled.

R 200010501

CAN-PRIM command register

R 200010501 is used to transfer certain commands to the CAN-PRIM interface.

CAN-PRIM Interface - Commands

- 1 Enabling the message box**

The selected message box in R 200010502 is enabled. When enabling the message box, the system checks whether the CAN ID of the box is reserved or not.

Result: Bit 0 = 1 in R 200010510

- 2 Disabling the message box**

The selected message box in R 200010502 is disabled.

Result: Bit 0 = 0 in R 200010510

- 3 Sending CAN messages**

A CAN message is sent containing the data of the selected message box.

- 4 Clearing the NEW DAT bit**

This command is for clearing the NEW DAT bit in R 200010500 which enables the selected message box to receive CAN messages again.

Result: Bit 1 = 0 in R 200010510

- 5 Clearing the OVERRUN bit**

This command is for clearing the OVERRUN bit in R 200010510 of the selected message box.

Result: Bit 2 = 0 in R 200010510

- 6 Clearing the transmission error bit**

This command is for clearing the transmission error bit in R 200010510 of the selected message box.

Result: Bit 3 = 0 in R 200010510

- 7 Clearing the FIFO buffer**

This command is for clearing all entries in the FIFO buffer.

Result: R 200010503 = 0

- 8 Setting the default ID length to 11 bits**

The ID length for all CAN messages is set to 11 bits.

Result:
Bit 2 = 0 in R 200010500
R 200010506 = 0
R 200010507 = 0

- 9 Setting the default ID length to 29 bits**

The ID length for all CAN messages is set to 29 bits.

Result:
Bit 2 = 1 in R 200010500
R 200010506 = 0
R 200010507 = 0

CAN-PRIM Interface - Commands

10 Checking message boxes for new messages

The CAN-PRIM interface automatically checks the inbox for new messages. Command 10 is for extending the interval between checks.

Module register properties

Type of access	CAN-PRIM interface is enabled.
----------------	--------------------------------

R 200010502

Message box number

R 200010502 is for selecting a message box. The data contained in the message box can then be accessed via module registers R 200010510 through R 200010521.

Module register properties

Values	Message box number:	0 ... 15
Type of access	Read access removes character	
Takes effect	if the CAN-PRIM interface is enabled.	

R 200010503

FIFO buffer filling level

R 200010503 shows whether new CAN messages have been received, as well as the number of messages.

Module register properties

Values	Number of received messages:	0 ... 16
Type of access	Read access	
Takes effect	if the CAN-PRIM interface is enabled.	

R 200010504

FIFO data

R 200010504 shows which of the messages boxes has received a new CAN message. Read access to R 200010504 removes the value which has been read last from the FIFO buffer. This access decrements the value of R 200010503 by one.

Module register properties

Values	No FIFO data available:	-1
	Number of the message box containing new data:	0 ... 15
Type of access	Read access removes characters	
Value after reset	-1	
Takes effect	if the CAN-PRIM interface is enabled.	

R 200010506

Global receiving mask

The global receiving mask is for filtering the bits of the received CAN-ID. If the bit of the global receiving mask is set, the received bit of the CAN-ID is compared with the global receiving ID.

Module register properties

Values	in the case of 11-bit CAN IDs	0 ... 0x7FF
	in the case of 29-bit CAN IDs	0 ... 0x1FFFFFFF
Bit = 0	Bit is not compared with R 200010507.	
Bit = 1	Bit is compared with R 200010507.	
Takes effect	if the CAN-PRIM interface is enabled.	

R 200010507

Global receiving ID

The global receiving ID and R 200010506 *Global receiving mask* are for setting a CAN ID range which is then forwarded to the CAN-PRIM interface.

Module register properties

Values	in the case of 11-bit CAN IDs	0 ... 0x7FF
	in the case of 29-bit CAN IDs	0 ... 0x1FFFFFFF
Takes effect	if the CAN-PRIM interface is enabled.	

R 200010510**Box status**

R 200010510 allows to evaluate the status of a message box.

Meaning of the individual bits**Bit 0 Valid**

1 = The message box is enabled

Bit 1 NEW-DAT

1 = The message box has received a CAN message. Reception of additional CAN messages is blocked.

Bit 2 OVERRUN

1 = The message box has received a new CAN message while NEW-DAT was 1.

Bit 3 Sending error

1 = An error has occurred when sending a CAN message from this message box.

Module register properties

Type of access Read access

Takes effect if the CAN-PRIM interface is enabled.

R 200010511**Box configuration**

R 200010511 is for configuring the message box.

Meaning of the individual bits**Bit 0 Outbox/inbox**

0 = Outbox

1 = Inbox

Module register properties

Takes effect if the CAN-PRIM interface is enabled.

R 200010512

CAN ID

In the case of an outbox, a CAN message is sent using the CAN ID.
In the case of an inbox, only CAN messages with this CAN ID are received.

Module register properties

Values	in the case of 11-bit CAN IDs	0 ... 0x7FF
	in the case of 29-bit CAN IDs	0 ... 0x1FFFFFFF
Takes effect	if the CAN-PRIM interface is enabled and the message box is disabled, i.e. if in MR 10510 bit 0 = 0.	

R 200010513

Number of data bytes

In the case of an outbox, a CAN message is sent with this number of data bytes.
In the case of an inbox, the number of received data bytes is entered.

Module register properties

Values	Number of data bytes:	0 ... 8
Takes effect	if the CAN-PRIM interface is enabled.	

**R 200010514 ...
R 200010521**

Data bytes 0 through 7

In the case of an outbox, a CAN message is sent with these data bytes.
In the case of an inbox, the received data bytes are entered.

Module register properties

Values	Data of data bytes:	0 ... 255
Takes effect	if the CAN-PRIM interface is enabled.	

CAN-PRIM Interface - Sample Program

Task CAN messages with CAN IDs 0x200 are to be sent via CAN-PRIM interface. On receipt, a CAN message with CAN ID 0x277 is to be sent.

Solution The data are sent and received via CAN-PRIM interface. To this end, a message box is configured as inbox for CAN ID 0x200. A second message box is configured as outbox with CAN ID 0x277.

Configuration In this example, the CAN-PRIM interface of a JVM-407 is used.

Configuring the JetSym STX Program

Type

```
TYPE_JC_CAN_PRIM:
```

Struct

```

    State      : Int At 0*SizeOf(Int);
    Command    : Int At 1*SizeOf(Int);
    BoxNumber  : Int At 2*SizeOf(Int);
    FifoNumData : Int At 3*SizeOf(Int);
    FifoData   : Int At 4*SizeOf(Int);
    GlobalMask : Int At 6*SizeOf(Int);
    GlobalID   : Int At 7*SizeOf(Int);
    BoxState   : Int At 10*SizeOf(Int);
    BoxConfig  : Int At 11*SizeOf(Int);
    BoxCanId   : Int At 12*SizeOf(Int);
    BoxDLC     : Int At 13*SizeOf(Int);
    BoxData    : Array[8] of Int At 14*SizeOf(Int);

```

```
End_Struct;
```

```
End_Type;
```

Var

```

    CanPrim    : TYPE_JC_CAN_PRIM At %VL 200010500;
    Data       : Array[8] of Int;

```

```
End_Var;
```

```
Task main Autorun

    // 11-bit CAN ID
    CanPrim.Command := 8;

    // Selecting box 0
    CanPrim.BoxNumber := 0;
    // Configuring the box for ID 0x200
    CanPrim.BoxCanId := 0x200;
    // Configuring box as inbox
    CanPrim.BoxConfig := 0;
    // Enabling the box
    CanPrim.Command := 1;
    If
        BitClear(CanPrim.BoxState, 0)
    Then
        // CAN ID already used by system bus
    End_If;

    // Selecting box 1
    CanPrim.BoxNumber := 1;
    // Configuring the box to ID 0x2FF
    CanPrim.BoxCanId := 0x2FF;
    // Configuring box as outbox
    CanPrim.BoxConfig := 1;
    // Enabling the box
    CanPrim.Command := 1;
    If
        BitClear(CanPrim.BoxState, 0)
    Then
        // CAN ID is already used by CAN system bus
    End_If;
End_Task;
```

**JetSym STX Program -
Receiving Data**

```
// Waiting for new CAN messages
When
    BitSet(CanPrim.State, 1)
Continue;

// Reading box number out of FIFO buffer and selecting box
CanPrim.BoxNumber := CanPrim.FifoData;

// Checking for overrun
If
    BitSet(CanPrim.BoxState, 2)
Then
    // Acknowledging overrun
    CanPrim.Command := 5;
End_If;

// Copying received data
Data[0] := CanPrim.BoxData[0];
Data[1] := CanPrim.BoxData[1];

// Resetting the NEW-DATA bit to be able to receive
// new messages in this box
CanPrim.Command := 4;
```

**JetSym STX Program -
Sending Data**

```
// Selecting box 1
CanPrim.BoxNumber := 1;

// Number of data bytes = 2
CanPrim.BoxDLC := 2;
// Entering the data to be sent
CanPrim.BoxData[0] := 12;
CanPrim.BoxData[1] := 25;

// Starting to send the CAN message
CanPrim.Command := 3;

// Checking for errors
If
    BitSet(CanPrim.BoxState, 3)
Then
    // Acknowledging errors
    CanPrim.Command := 6;
End_If;
```

12 Automatic Copying of Controller Data

Introduction

This chapter describes the AutoCopy feature which allows to copy data within the JVM-407 and/or between the JVM-407 and an FTP server. To this end, a command file has to be created which is then stored along with the data to the SD card or a USB stick. This command file is automatically processed by the controller during the boot process.

Functions Within the Local File System

The following functions can be performed:

- Storing registers and flags to a file
 - Restoring registers and flags from a file
 - Creating directories
 - Deleting directories
 - Copying files
 - Deleting files
-

Functions Within the File System of an FTP Server

The following functions can be performed:

- Copying files from the FTP server
 - Copying files to the FTP server
 - Deleting files
 - Changing directories
 - Creating directories
 - Deleting directories
-

Areas of Application

This function can be used in systems where remote maintenance is not feasible, no PC is available or the operator is not able (or should not be allowed) to make modifications to the plant. This function includes the following:

- Modification to the application program
 - Modification to user data
 - Modification to the controller configuration
 - Operating system update (JVM-407, network nodes)
 - Duplication of a control system
-

Prerequisites

The following requirements must be met:

- the programmer must be familiar with the file system of the JVM-407
 - the programmer must have basic knowledge in the area of FTP application
-

Names

In this description "Complete Name" means the name of the file or directory including its complete path.

Contents

Topic	Page
Operating Principle	314
The File "autocopy.ini"	318
Log File	330
Data Files.....	332

12.1 Operating Principle

Introduction

This chapter describes how the AutoCopy function is started and how it is executed by the JVM-407.

Contents

Topic	Page
Activating the AutoCopy Feature	315
Executing AutoCopy Commands	316
Terminating AutoCopy Mode.....	317

Activating the AutoCopy Feature

Introduction

The AutoCopy function can only be executed while the JVM-407 is booting.

Prerequisites

The command file has been created and stored to the SD card or USB stick.

	Value	Comment
File Name	autocopy.ini	All lower case letters
Directory - SD	/SD/	Root directory on the SD Card
Directory - USB	/USB/	Root directory on USB stick

Activating the AutoCopy Feature

To start AutoCopy proceed as follows:

Step	Action
1	Switch the device OFF.
2	Insert the SD card completely into the SD slot or insert the USB stick into the USB port.
3	Keep the keys F1 and F3 pressed.
4	Switch the device ON.
5	Wait until the following message appears: Start operating system in STOP mode.

Result: The device is booting in AutoCopy mode.

Executing AutoCopy Commands

Introduction

During the boot process in AutoCopy mode the device executes the commands contained in the command file.

Restrictions

In AutoCopy mode, the following restrictions apply as regards the functions of the device JVM-407:

- The application program is not executed
- No communication with the JVM-407 possible

Executing AutoCopy Commands

When executing AutoCopy commands, the OS of the JVM-407 proceeds as follows:

Stage	Description
1	The device loads the file "/SD/autocopy.ini" from the SD card or from the USB stick.
2	It reads the values from section [OPTIONS]
3	The device reads the command and its parameters from the section [COMMAND_1], processes it and writes the results, if any, into the log file
4 .. n	The device processes the other commands in ascending order up to the number given in section [OPTIONS]
n+1	The device calculates the statistic values for all command results and writes them into the log file.

Terminating AutoCopy Mode

Introduction

The AutoCopy mode can only be exited by booting the JVM-407.

Terminating AutoCopy Mode

Once the AutoCopy function is completed, proceed as follows to exit the AutoCopy mode:

Step	Action
1	Remove the SD card or the USB stick.
2	Press any key on the device.

Result: The device reboots.

12.2 The File "autocopy.ini"

Introduction	This chapter covers the structure of the file "autocopy.ini" and the available commands.								
File Structure	<p>This command file of the AutoCopy function is a text file the entries of which are grouped into several sections.</p> <ul style="list-style-type: none">▪ In these sections values can be set which are then used by the AutoCopy function.▪ Blank lines can be inserted as required▪ The following characters precede a comment line: "!", "#" or ";"								
Sections	<p>The command file has two section types:</p> <ul style="list-style-type: none">▪ In section [OPTIONS] the basic settings are made. It exists only once.▪ In the sections [COMMAND_#] the commands to be executed are specified. The number of commands is limited to 128.								
Contents	<table><thead><tr><th>Topic</th><th>Page</th></tr></thead><tbody><tr><td>Section [OPTIONS].....</td><td>319</td></tr><tr><td>Command Sections.....</td><td>320</td></tr><tr><td>Example of a Command File.....</td><td>328</td></tr></tbody></table>	Topic	Page	Section [OPTIONS].....	319	Command Sections.....	320	Example of a Command File.....	328
Topic	Page								
Section [OPTIONS].....	319								
Command Sections.....	320								
Example of a Command File.....	328								

Section [OPTIONS]

Introduction

This section contains the basic settings of the AutoCopy function. It exists only once, preferably at the beginning of the file.

Example

```
[OPTIONS]
CommandCount = 14
LogFile      = /SD/autocopy.log
LogAppend   = 1
```

Elements of this Section

This section consists of the following elements:

CommandCount

In the given example	14
Description	Number of command sections that follow
Allowed values	> = 0
Illegal values	< 0
In case of illegal value or missing entry	0

LogFile

In the given example	/SD/autocopy.log
Description	Complete name of the log file
Allowed values	<ul style="list-style-type: none"> ▪ All allowed file names ▪ Directory exists
Illegal values	<ul style="list-style-type: none"> ▪ Invalid file name ▪ Nonexistent directory
In case of illegal value or missing entry	No log file will be created.

LogAppend

In the given example	1
Description	Defines whether a new log file is to be created or it is to be appended to an existing one.
Allowed values	<ul style="list-style-type: none"> ▪ 0 = Delete file which may exist and create a new one. ▪ 1 = Append file to existing one. If no file exists, a new log file is created.
Illegal values	<ul style="list-style-type: none"> ▪ < 0 ▪ > 1
In case of illegal value or missing entry	A new log file will be created.

Command Sections

Introduction

In these sections commands can be specified which are then executed by the AutoCopy function of the JVM-407.

Example

```
[COMMAND_1]
Command = DirCreate
Path    = /Homepage
ErrorAsWarning = 1

[COMMAND_2]
Command    = FileCopy
Source     = /SD/Index.htm
Destination = /Homepage/index.htm

[COMMAND_3]
Command      = FtpConnect
ServerAddr   = 192.168.123.45
UserName     = admin
Password     = admin
```

Section Names

The section names consist of the string `COMMAND_` followed by a number which indicates the number of the entry `CommandCount` given in section `[OPTIONS]`.

Processing Commands

The AutoCopy function processes the commands in order of their section names.

- Starting with the command under section `[COMMAND_1]`
 - Ending with the command under the section with the value of entry `CommandCount` from section `[OPTIONS]`
 - Each command section may hold only one command. That is, for each command a separate section has to be created.
-

Troubleshooting

When an error occurs while a command is being processed, the corresponding entry in the log file is made. For each command the user can set, whether the error is entered into the log file as `Error` or as `Warning`. This setting is made through the optional parameter `ErrorAsWarning`:

ErrorAsWarning	Entry in log file
Parameter does not exist	Error
ErrorAsWarning = 0	Error
ErrorAsWarning = 1	Warning

File Names

- The function parameter for the local file may contain the path to this file (e.g. `"/Data/TestFiles/LocalTestFile.txt"`).
- The function parameter for the file on the FTP server may contain the path to this file if this feature is supported by the file system. If this feature is not supported, the corresponding directory must be set using the command `FtpDirChange(...)`.
- The file system of a JVM-407 PLC supports both options.

Available Commands in the Local File System

The following commands are available for access to the local file system:

Command = DirCreate

Function	This command is for creating a subdirectory
Parameter name	Path
Parameter value	Complete name of the directory
Allowed values	<ul style="list-style-type: none"> ▪ All valid directory names ▪ Existing higher-level directories
Illegal values	<ul style="list-style-type: none"> ▪ Invalid directory names ▪ Nonexistent higher-level directory ▪ Name of an already existing directory
In case of an illegal value	The directory will not be created and the error message will be entered into the log file
Example	<pre>[COMMAND_1] Command = DirCreate Path = /sub1 [COMMAND_2] Command = DirCreate Path = /sub1/sub2</pre>

Command = DirRemove

Function	This command is for deleting a subdirectory
Parameter name	Path
Parameter value	Complete name of the directory
Allowed values	<ul style="list-style-type: none"> ▪ All valid directory names ▪ An empty directory
Illegal values	<ul style="list-style-type: none"> ▪ Invalid directory names ▪ Directory is not empty
In case of an illegal value	The directory will not be deleted and the error message will be entered into the log file
Example	<pre>[COMMAND_8] Command = DirRemove Path = /sub1/sub2</pre>

Command = FileCopy

Function	This command is for copying a file
Parameter name 1	Source
Parameter value 1	Complete name of the source file

Parameter name 2	Destination
Parameter value 2	Complete name of the destination file
Allowed values	<ul style="list-style-type: none"> ▪ All allowed file names ▪ The destination directory does exist
Illegal values	<ul style="list-style-type: none"> ▪ Invalid file name ▪ Nonexistent source file ▪ Nonexistent destination directory
In case of an illegal value	The file will not be copied and the error message will be entered into the log file
Example	<pre>[COMMAND_1] Command = FileCopy Source = /SD/OS/JC-340_1.04.0.03.os Destination = /System/OS/op_system.os [COMMAND_2] Command = FileCopy Source = /SD/Manual.pdf Destination = /sub1/Manual.pdf</pre>

Command = FileRemove

Function	This command is for deleting a file.
Parameter name	Path
Parameter value	Complete name of the file
Allowed values	All allowed file names
Illegal values	Invalid file name
In case of an illegal value	The file will not be deleted and the error message will be entered into the log file
Example	<pre>[COMMAND_5] Command = FileRemove Path = /sub1/Manual.pdf</pre>

Command = DaFileRead

Function	This command is for transferring register values and flag states from a data file to the JVM-407
Parameter name	DaFile
Parameter value	Complete name of the data file
Allowed values	All allowed file names for data files
Illegal values	<ul style="list-style-type: none"> ▪ Invalid file name ▪ Nonexistent data file
In case of an illegal value	The data will not be transferred to the controller and the error message will be entered into the log file
Example	<pre>[COMMAND_12] Command = DaFileRead DaFile = /SD/Data/MyTestData.da</pre>

Command = DaFileWrite

Function	This command is for storing register values and flag states to a data file
----------	--

Parameter name 1	DaFile
Parameter value 1	Complete name of the file
Allowed values	<ul style="list-style-type: none"> ▪ All allowed file names for data files ▪ The destination directory does exist
Illegal values	<ul style="list-style-type: none"> ▪ Invalid file name ▪ Nonexistent destination directory
In case of an illegal value	The file will not be created and the error message will be entered into the log file
Parameter name 2	Append
Parameter value 2	Defines whether a new data file is to be created or it is to be appended to an existing one.
Allowed values	<ul style="list-style-type: none"> ▪ 0 = Delete file which may exist and create a new one. ▪ 1 = Append file to existing one. If no file exists, create a new data file.
Illegal values	<ul style="list-style-type: none"> ▪ < 0 ▪ > 1
In case of an illegal value	A new data file will be created
Parameter name 3	Type
Parameter value 3	Defines whether registers or flags are to be stored.
Allowed values	<ul style="list-style-type: none"> ▪ Registers ▪ Flag
Illegal values	Values other than "Register" or "Flag"
In case of an illegal value	The file will not be created and the error message will be entered into the log file
Parameter name 4	First
Parameter value 4	Number of the first register or flag
Allowed values	All valid numbers from the memory area of the corresponding JVM-407
Illegal values	Invalid numbers
In case of an illegal value	The file will not be created and the error message will be entered into the log file
Parameter name 5	Last
Parameter value 5	Number of the last register or flag
Allowed values	All valid numbers from the memory area of the corresponding JVM-407 which are equal to or greater than the value for "First".
Illegal values	<ul style="list-style-type: none"> ▪ Invalid numbers ▪ Numbers less than "First"
In case of an illegal value	Only one value (First) is stored

12 Automatic Copying of Controller Data

Example	<pre> [COMMAND_11] Command = DaFileWrite DaFile = /SD/MyTestData2.da Append = 0 Type = Register First = 1000000 Last = 1000000 [COMMAND_12] Command = DaFileWrite DaFile = /SD/MyTestData2.da Append = 1 Type = Flag First = 10 Last = 20 [COMMAND_13] Command = DaFileWrite DaFile = /SD/MyTestData2.da Append = 1 Type = Register First = 1000001 Last = 1000999 </pre>
---------	--

Available Commands for Access via FTP

The following commands are available for access via network using FTP:

Command = FtpConnect

Function	Establishing a connection to an FTP server
Parameter name 1	ServerAddr
Parameter value 1	IP address or name of FTP server
Allowed values	<ul style="list-style-type: none"> ▪ IP address of the FTP server ▪ Name which can be resolved through DNS
Illegal values	<ul style="list-style-type: none"> ▪ IP address other than that of the FTP server ▪ Name which cannot be resolved
Parameter name 2	UserName
Parameter value 2	User name for logging on at the FTP server
Parameter name 3	Password
Parameter value 3	Password for logging on at the FTP server
In the case of a illegal values	Connection will not be established and the error message will be entered into the log file
Example	<pre> [COMMAND_1] Command = FtpConnect ServerAddr = 192.168.123.45 UserName = admin Password = admin </pre>
Comment	Only one connection with an FTP server can be established at a time. If a connection to another FTP server is to be established, the JVM-407 terminates the existing connection beforehand.

Command = FtpFileRead

Function	Copying file from FTP server into the local file system
Parameter name 1	ServerFile
Parameter value 1	Complete name of the source file in the FTP server
Parameter name 2	ClientFile
Parameter value 2	Complete name of the destination file in the local file system
Allowed values	<ul style="list-style-type: none"> ▪ All allowed file names ▪ The destination directory does exist
Illegal values	<ul style="list-style-type: none"> ▪ Invalid file name ▪ Nonexistent source file ▪ Nonexistent destination directory
In case of an illegal value	The file will not be copied and the error message will be entered into the log file
Example	<pre>[COMMAND_8] Command = FtpFileRead ServerFile = /app/cantest/cantest.es3 ClientFile = /SD/cantest3.es</pre>

Command = FtpFileWrite

Function	Copying file from the local file system into the file system of the FTP server
Parameter name 1	ServerFile
Parameter value 1	Complete name of the destination file in the FTP server
Parameter name 2	ClientFile
Parameter value 2	Complete name of the source file in the local file system
Allowed values	<ul style="list-style-type: none"> ▪ All allowed file names ▪ The destination directory does exist
Illegal values	<ul style="list-style-type: none"> ▪ Invalid file name ▪ Nonexistent source file ▪ Nonexistent destination directory
In case of an illegal value	The file will not be copied and the error message will be entered into the log file
Example	<pre>[COMMAND_5] Command = FtpFileWrite ServerFile = /System/OS/op_system.os ClientFile = /SD/OS/JC-340_1.09.0.00.os</pre>

Command = FtpFileRemove

Function	This command is for deleting a file in the FTP server
Parameter name	ServerFile
Parameter value	Complete name of the file
Allowed values	All allowed file names
Illegal values	Invalid file name
In case of an illegal value	The file will not be deleted and the error message will be entered into the log file

Example	[COMMAND_9] Command = FtpFileRemove ServerFile = /sub1/Manual.pdf
---------	---

Command = FtpDirChange

Function	Changing the working directory in FTP server
Parameter name	ServerDir
Parameter value	Complete name of the directory
Allowed values	All valid directory names
Illegal values	Invalid directory names
In case of an illegal value	The directory will not be changed and the error message will be entered into the log file
Example	[COMMAND_12] Command = FtpDirChange ServerDir = /Data/MyTestData

Commando = FtpDirCreate

Function	This command is for creating a subdirectory in FTP server
Parameter name	ServerDir
Parameter value	Complete name of the directory
Allowed values	<ul style="list-style-type: none"> ▪ All valid directory names ▪ Existing higher-level directories
Illegal values	<ul style="list-style-type: none"> ▪ Invalid directory names ▪ Nonexistent higher-level directory ▪ Name of an already existing directory
In case of an illegal value	The directory will not be created and the error message will be entered into the log file
Example	[COMMAND_6] Command = FtpDirCreate ServerDir = /Data/MyTestData
Restriction	If a directory with the corresponding path is specified as function parameter, all directories up to the directory to be created must exist. Recursive creation of several directories is not supported.

Commando = FtpDirRemove

Function	This command is for removing a subdirectory in FTP server
Parameter name	ServerDir
Parameter value	Complete name of the directory
Allowed values	<ul style="list-style-type: none"> ▪ All valid directory names ▪ An empty directory
Illegal values	<ul style="list-style-type: none"> ▪ Invalid directory names ▪ Directory is not empty
In case of an illegal value	The directory will not be removed and the error message will be entered into the log file

Example

```
[COMMAND_8]  
Command      = FtpDirRemove  
ServerDir    = /Data/MyTestData
```

Example of a Command File

Task	<p>New functions are to be added to an installed JVM-407. To this end, the following modifications have to be made to the configuration:</p> <ul style="list-style-type: none">▪ Operating system update▪ New application program▪ New values for some of the registers
Solution	<p>The required files are copied to an SD card and a command file for the AutoCopy function is created. This SD card along with a short instruction sheet is sent to the customer. Once the update is completed, the customer returns the card.</p>
SD Card Contents	<p>The SD card contains the following files:</p> <ul style="list-style-type: none">▪ The file "autocopy.ini"▪ The new OS▪ A .da file containing the new register values▪ A file "start.ini" and a .es3 file containing the new application program <p>Following execution the log file "autocopy.log" has been added.</p>
Command File	<pre>[OPTIONS] CommandCount = 6 LogFile = /SD/autocopy.log LogAppend = 0 # update operating system of JVM-407 [COMMAND_1] Command = FileCopy Source = /SD/OS/JVM4xx_1.15.1.00.os Destination = /System/OS/op_system.os # Creating user program directories # Probably already present - but to be sure ... [COMMAND_2] Command = DirCreate Path = /app ErrorAsWarning = 1 [COMMAND_3] Command = DirCreate Path = /app/userprogtest # Copying user program start file [COMMAND_4] Command = FileCopy Source = /SD/UserProgs/start.ini</pre>


```
Destination = /app/start.ini

# Copying user program
[COMMAND_5]
Command      = FileCopy
Source       = /SD/UserProgs/userprogtest.es3
Destination  = /app/userprogtest/userprogtest.es3

# Setting registers and flags
[COMMAND_6]
Command      = DaFileRead
DaFile       = /SD/UserData/MyTestData.da
```

12.3 Log File

Introduction

This chapter covers the structure and contents of the log file into which the results of each command are entered.

Contents

Topic	Page
File Contents	331

File Contents

Introduction

The log file is a plain text file. The command file defines whether a log file is to be created. And whether it is to be created from scratch or whether the entries are to be appended to an existing log file.

Example

```
JetControl AutoCopy log file 07.11.2008 09:14:09

1: Ok    - FileCopy   /SD/OS/JC-340_1.04.0.00.os
                /System/OS/op_system.os (345740 byte)
2: Warning - DirCreate  /app
3: Ok    - DirCreate  /app/userprogtest
4: Ok    - FileCopy   /SD/UserProgs/start.ini
                /app/start.ini (63 byte)
5: Ok    - FileCopy   /SD/UserProgs/userprogtest.es3
                /app/userprogtest/userprogtest.es3
                (169 byte)
6: Error  - DaFileRead /SD/UserData/MyTestData.da

Command statistics:
Total   : 7
Ok      : 5
Warning: 1
Error   : 1
```

Description

When for each executed AutoCopy function a section is appended to an existing log file, the log file consists of three elements:

- The header contains date and time
- The following block contains information on the executed commands.
- Finally, short statistics on command processing.

In the above example, an error message occurs (which will be entered as warning) when trying to create the directory "/app" as this directory already exists. When reading the DA file an error occurs, too. The corresponding error message is entered into the log file.

12.4 Data Files

Introduction

This chapter covers data files where register and flag values are stored.

Contents

Topic	Page
File Format.....	333

File Format

Format

The file is structured as follows:

- Pure text file
- Each entry must be in a separate line of text
- Each line must be terminated by carriage return / line feed
- Comment lines must be preceded by ";"
- Each data file is to start with the entry "SD1001".

Data Lines

A data line consists of the following elements:

- ID of the variable at the beginning of the line
- Now follows the number of the variable separated by a blank or tab
- Then follows the value of the variable separated by a blank or tab

Variable ID	Variable type
FS	Flags
RS	Integer registers
QS	Floating-point registers

Example

```
SD1001
; Data File - Jetter AG
;
; Register 1000000 ... 1000005
RS 1000000 12345
RS 1000001 2
RS 1000002 -1062729008
RS 1000003 502
RS 1000004 50
RS 1000005 3
QS 1009000 3.14
;
; Flag 10 ... 13
FS 10 0
FS 11 1
FS 12 1
FS 13 0
```

13 Operating System Update

Introduction

Jetter AG are continuously striving to enhance the operating systems for HMIs. Enhancing means adding new features, upgrading existing functions and fixing bugs.
This chapter describes how to update the operating system.

Downloading an Operating System

You can download operating systems from the Jetter AG homepage at www.jetter.de **http://www.jetter.de**. You get to the OS files by clicking on the quick link "Operating System Download" located on the website of the corresponding HMI.

Contents

Topic	Page
Updating the Operating System of the HMI.....	336

13.1 Updating the Operating System of the HMI

Introduction

This chapter describes how an OS update of the JVM-407 is carried out. There are several options to transfer the OS file to the device:

- from within the programming tool JetSym
 - via FTP connection
 - from an SD Card
 - from a USB stick
 - from within the application program
-

Contents

Topic	Page
Operating System Update from within JetSym	337
Operating System Update by Means of FTP	338
Automatic OS Update from SD Card and USB stick	339
Operating System Update from within the Application Program.....	340

Operating System Update from within JetSym

Introduction

The programming tool JetSym offers an easy way to transfer an OS file to the JVM-407.

Prerequisites

- An OS file for the JVM-407 must be available.
- There must be a UDP/IP and a TCP/IP connection between programming tool and IP port of the JVM-407. The number of this port must have been entered into the configuration memory as IP basic port number.
- During booting, the JVM-407 is waiting for the OS update, or the OS is already running.
- Make sure that the JVM-407 is not switched off during OS update.

Updating the Operating System

To update the OS proceed as follows:

Step	Action
1	In JetSym, call up the "Build" menu and select item "Update OS..." there, or click in the configuration window of the hardware manager on "OS Update". Result: The file selection box opens.
2	Select the desired OS file here. Result: In JetSym, a confirmation box opens.
3	Start the OS upload by clicking the button "Yes".
4	Wait until the update process is completed.
5	Reboot the JVM-407 to launch the new operating system.

Operating System Update by Means of FTP

Introduction

Using an FTP client an OS file can be transferred to the controller.

Prerequisites

- An OS file for the controller JVM-407 must be available.
 - An FTP connection to the controller must be possible.
 - The login parameters for a user with administrator or system rights must be at hand.
 - The operating system is running.
 - Make sure that the controller is not switched off during OS update.
-

Updating the Operating System

To update the OS proceed as follows:

Step	Action
1	Establish an FTP connection to the controller.
2	Log in with administrator or system rights.
3	Navigate to the directory "/System/OS".
4	Transfer the OS file.
5	Wait until the update process is completed.
6	Close the FTP connection.
7	Reboot the controller to launch the new operating system.

Automatic OS Update from SD Card and USB stick

Reference: An automatic OS update of the HMI from SD card or USB stick can be carried out using the AutoCopy function. For a detailed description refer to *AutoCopy* on page 312.

Operating System Update from within the Application Program

Introduction

The file functions included in the STX language allow to carry out a program-controlled OS update of a controller from within an OS file.

Prerequisites

- An OS file for the controller JVM-407 must be available in the file system of the controller.
- The operating system of the controller and the application program are running.
- Make sure that the controller is not switched off during OS update.

Updating the Operating System

To update the OS from within the application program proceed as follows:

Step	Action
1	Open the OS file in read-only mode.
2	Open a file with any name and the extension ".os" in the directory "/System/OS" in write mode.
3	Read the data out of the OS file.
4	Write these data to the target file.
5	Close both files.
6	Reboot the controller to launch the uploaded operating system (for example by entering a value into the system command register).

Sample Program

```

Var
  SourceName:          String[100];
  DestinationName:    String[100];
  UpdateIt:           Bool;
End_Var;

//*****
// Name:      FileCopy
// param[in] SrcName      name of source file
// param[in] DstName      name of destination file
// return    >= 0        size of source file
// return    < 0        error
// brief     copies a file
//*****
Function FileCopy(ref SrcName: String,
                 ref DstName: String):Int;

  Var
    SrcFile, DstFile:  File;
    FileBuffer:       Array[1000] of Byte;
    Result:           Int;
    ReadSize:         Int;
    WriteSize:        Int;
    FileSize:         Int;
  End_Var;

```

```

Result := 0;
FileSize := 0;
// open source file for reading
If FileOpen(SrcFile, SrcName, 'r') Then
    // open destination file for writing
    If FileOpen(DstFile, DstName, 'w') Then
        // read first block of data
        ReadSize := FileRead(SrcFile,
                               FileBuffer,
                               SizeOf(FileBuffer));
        While ReadSize <> 0 Do
            // write read data to destination file
            WriteSize := FileWrite(DstFile,
                                    FileBuffer,
                                    ReadSize);
            If WriteSize <> ReadSize Then
                // write error
                Result := -3;
                Exit;
            End_If;
            Inc(FileSize, WriteSize);
            // read next block of data
            ReadSize := FileRead(SrcFile,
                                   FileBuffer,
                                   SizeOf(FileBuffer));
        End_While;
        // close both files
        FileClose(SrcFile);
        FileClose(DstFile);
    Else
        // can't open destination file
        FileClose(SrcFile);
        Result := -2;
    End_If;
Else
    // can't open source file
    Result := -1;
End_If;
If Result < 0 Then
    FileCopy := Result;
Else
    FileCopy := FileSize;
End_If;
End_Function;

//*****
// 1. Enable Tracing in JetSym
// 2. Put source file name into 'SourceName'
// 3. Set flag 'UpdateIt'
//*****

```

13 Operating System Update

```
Task OSupdate Autorun
  Var
    ResCopy:    Int;
  End_Var;

  DestinationName := '/System/OS/OperatingSystem.os';
  Loop
    UpdateIt := False;
    When UpdateIt Continue;
    ResCopy := FileCopy(SourceName,
                        DestinationName);
    Trace('Result : ' + IntToStr(ResCopy) + '$n');
  End_Loop;
End_Task;
```

14 Application Program

Introduction

This chapter explains how the application program is stored to the JVM-407 and how the user selects the program to be executed.

Required Programmer's Skills

This chapter requires knowledge on how to create application programs in JetSym and how to transmit them via the JVM-407 file system.

Contents

Topic	Page
Loading an Application Program.....	344
Application Program - Default Path	345
Storing the Application Program to an SD Card	346

Loading an Application Program

Introduction

The application program is loaded and executed by the file system either on relaunch of the application program through JetSym or on re-boot of the JVM-407.

Loading Process

The application program is loaded by the JVM-407's OS as follows:

Stage	Description
1	The OS reads the file "/app/start.ini" from the internal flash disk.
2	The OS reads out the path to the application program from the entry "Project".
3	The OS reads out the program name from the entry "Program". The path is relative to the directory "/app".
4	The OS loads the application program from the file <Project>/<Program>.

Application Program - Default Path

Introduction

When uploading the application program from JetSym to the JVM-407, it is stored as file to the internal flash disk. Path and file name are entered into the file "/app/start.ini".

Path and File Name

In the directory "/app" JetSym, by default, creates a subdirectory and assigns the project name to it. Then, JetSym stores the application program to this subdirectory assigning the extension "*.es3" to it. Path and file names are always converted into lower case letters.

File "/app/start.ini"

This file is a text file with one section holding two entries:

Element	Description
[Startup]	Section name
Project	Path to the application program. This path is relative to "/app".
Program	Name of the application program file

Example:

```
[Startup]
Project = test_program
Program = test_program.es3
```

Result: The application program is loaded from the file "/app/test_program/test_program.es3".

Related Topics

- **Storing the Application Program to the SD Card** on page 346
-

Storing the Application Program to an SD Card

Introduction

When uploading the application program from JetSym to the JVM-407, the default path for the application program is used. If the application program is to be read from the SD card or an USB stick, the user has to configure this option.

The procedure is the same if you wish to store the application program to a different directory of the internal flash disk.

Prerequisites

Since the JVM-407's file system is case sensitive, make sure that path and file names, as well as file entries are spelled correctly.

Storing the application program to the SD card or the USB stick

This is how the JVM-407 is to be configured if you wish to store the application program to the SD card:

Step	Action
1	Create the desired directory on the SD card or the USB stick.
2	Store the application program created by JetSym to this directory.
3	Enter the path to the application program file and the program name into the file "/app/start.ini" on the controller's internal flash disk.

Result: When the application program is relaunched, it is loaded from SD card or USB stick.

File "/app/start.ini"

This file is a text file with one section holding two entries:

Entry	Description
[Startup]	Section name
Project	Path to the application program. This path is relative to "/app".
Program	Name of the application program file

Example - SD Memory Card

```
[Startup]
Project = /SD/TestProgram
Program = Test1.es3
```

Example - USB Stick

```
[Startup]
Project = /USB/TestProgram
Program = Test1.es3
```

Result: The application program is loaded from the file "Test1.es3" located in the directory "TestProgram" on SD card ("/SD/TestProgram/Test1.es3") and on USB stick ("/USB/TestProgram/Test1.es3").

Related Topics:

- **Application Program - Default Path** on page 345
-

15 Quick Reference JVM-407

OS version

This quick reference gives an overview of registers and flags used in connection with HMLs JVM-407, BTM 07, BTM 09, BTM 09V and BTM 012 with OS version 1.17.1.00.

General Overview - Registers

100000 ... 100999	Electronic Data Sheet (EDS)
101000 ... 101999	Configuration
102000 ... 102999	Real-Time Clock (RTC)
104000 ... 104999	Ethernet
106000 ... 106999	CAN
107000 ... 107999	SD Memory Card
108000 ... 108999	CPU/backplane

200000 ... 209999	General system registers
210000 ... 219999	Application program
230000 ... 239999	Networking via JetIP
260000 ... 269999	Remote scan
270000 ... 279999	Modbus/TCP
290000 ... 299999	E-mail
310000 ... 319999	File system / data files
350000 ... 359999	User-programmable IP Interface
360000 ... 369999	Display

1000000 ... 1059999	JC-360: Application registers (remanent; Int/Float)
---------------------	---

General Overview - I/Os

Entry keys	
361000 ... 361007	Bit-coded mapping of entry keys
LED	
362000 ... 362006	Bit-coded mapping of LEDs
I/Os	
362100	Bit-coded mapping of status LEDs
362200	Bit-coded mapping of relay

General Overview - Flags

0 ... 255	Application flags (remanent)
256 ... 2047	overlaid by registers 1000000 through 1000055
2048 ... 2303	Special Flags

MAC Address

100801	MAC Address (Jetter)
100802	MAC Address (device)

Configuration

From file /system/ config.ini	
101100	IP address
101101	Subnet mask
101102	Default gateway
101103	DNS server
101132	Host name suffix type
101133 ...	Host name (register string)
101151	
101164	JetIP port number
101165	STX debugger port number
Used by the system	
101200	IP address
101201	Subnet mask
101202	Default gateway
101203	DNS server

101232	Host name suffix type
101233 ...	Host name (register string)
101251	
101264	JetIP port number
101265	STX debugger port number

Realtime clock (RTC)

Direct access	
102911	Seconds
102912	Minutes
102913	Hours
102914	Weekday (0 = Sunday)
102915	Day
102916	Month
102917	Year
Buffer access	
102921	Seconds
102922	Minutes
102923	Hours
102924	Weekday (0 = Sunday)
102925	Day
102926	Month
102927	Year
102928	Read/write trigger

Ethernet

IP	
104531	current IP address (rw)
104532	current subnet mask (rw)
104533	current default gateway (rw)

CAN

106000	Baud rate CAN 0
106001	Node ID CAN 0
106100	Baud rate CAN 1
106101	Node ID CAN 1
106200	Baud rate CAN 2
106201	Node ID CAN 2

SD memory card

107000	Bit 0 = 1: Card available Bit 1 = 1: Card ready
107001	1 = card is read-only (only applies if reg. 107000 = 3)
107002	Size in MBytes
107003	Baud rate in MBaud

CPU Hardware

108015	Backup voltage (e.g. of the clock) 0 = Data invalid 1 = Power supply OK You can confirm the register by entering 1, if the power supply has been recovered.
--------	--

USB Data Carrier

109000	Bit 0 = 1: Data carrier exists Bit 1 = 1: Data carrier is ready
107001	1 = data carrier is read-only (only applies if reg. 109000 = 3)
107002	Size in MBytes

CPU

108002	all LED on/off (bit-coded) Bit 1: LED E
108004	LED E 0 = off 3 = on
108015	Application status 2 = RUN 3 = STOP

General System Registers

200000	OS version (Major * 100 + Minor)
200001	Application program running (Bit 0 = 1)
200008	Error register (identical to 210004)
200168	Bootloader version (IP format)
200169	OS version (IP format)
201000	Runtime registers in milliseconds (rw)
201001	Runtime registers in seconds (rw)
201002	Runtime registers in reg. 201003 Units (rw)
201003	* 10 ms units for reg. 201002 (rw)
201004	Runtime registers in milliseconds (ro)
202930	Web status (bit-coded) Bit 0 = 1: FTP server available Bit 1 = 1: HTTP server available Bit 2 = 1: E-mail available Bit 3 = 1: Data file function available Bit 4 = 1: Modbus/TCP has been licensed Bit 5 = 1: Modbus/TCP available Bit 6 = 1: Ethernet/IP available
202936	Control register file system 0xc4697a4b: Formatting the Flash Disk 0xd364e64d: Formatting the SD Card 0x2c9b3c94: Checking the SD Card 0x8f3d5185: Formatting the USB data carrier 0x17dbd42a: Checking the USB data carrier
202960	Password for system command register (0x424f6f74)
202961	System Command Registers
202980	Error history: Number of Entries
202981	Error history: Index
202982	Error history: Item
203000	Interface Monitoring: JetIP
203001	Interface Monitoring: SER
203005	Interface Monitoring: Debug server
203100 ...	32-bit overlay - Flag 0 ... 255
203107	
203108 ...	16-bit overlay - Flag 0 ... 255
203123	
203124 ...	32-bit overlay - Flag 2048 ... 2303
203131	
203132 ...	16-bit overlay - Flag 2048 ... 2303
203147	
209700	System logger: global enable
209701 ...	Enable system components
209739	

Application Program

210000	Application program running (Bit 0 = 1)
210001	JetVM version
210004	Error register (bit-coded) Bit 1: Error JX3 bus Bit 2: Error JX2 bus Bit 8: illegal jump Bit 9: illegal call Bit 10: illegal index Bit 11: illegal Opcode Bit 12: divide by 0 Bit 13: stack overflow Bit 14: stack underflow Bit 15: stack invalid Bit 16: Error when loading the application program Bit 24: Cycle time overrun Bit 25: Tasklock timeout Bit 31: Unknown error
210006	Highest task number

210007	Minimum program cycle time
210008	Maximum program cycle time
210009	Current program cycle time
210011	Current task number
210050	Current program count within an execution unit
210051	ID of the execution unit just processed
210056	Required total cycle time in μ s
210057	Calculated total cycle time in μ s
210058	Maximum time slice per task in μ s
210060	Task ID (for reg. 210061)
210061	Task priority for task [reg. 210060]
210063	Length of Scheduler Table
210064	Index in Scheduler Table
210065	Task ID in Scheduler Table
210070	Task ID (for reg. 210071)
210071	Timer number (0 ... 31)
210072	Manual triggering of a Timer Event (bit-coded)
210073	End of cyclic task (Task ID)
210074	Command for cyclic tasks
210075	Number of timers
210076	Timer number (for reg. 210077)
210077	Timer value in milliseconds
210100 ...	Task status
210199	
210400 ...	Task program address
210499	
210600	Task ID of a cyclic task (for reg. 210601)
210601	Processing time for a cyclic task in 1/10 of a percent
210609	Tasklock timeout in ms -1: Monitoring disabled
210610	Time overrun (bit-coded, Bit 0 -> Timer 0 etc.)

Networking via JetIP

230000	JetIP/TCP Server: Number of open connections
230001	JetIP/TCP Server: Mode
230002	JetIP/TCP Server: Time
232708	Timeout in milliseconds
232709	Response time in milliseconds
232710	Number of network errors
232711	Error code of the last access 0 = No error 1 = Timeout 3 = Error message of the remote station 5 = Invalid network address 6 = Invalid number of registers 7 = Invalid interface number
232717	Max. number of retries
232718	Number of retries

Modbus/TCP

272702	Register offset
272704	Input offset
272705	Output offset
278000 ...	16-bit I/O register; overlaid by virtual I/O 20001 through
278999	36000

E-mail

292932	IP address of SMTP server
292933	IP address of POP3 server
292934	Port number of SMTP server
292935	Port Number of POP3 server
292937	Status of E-Mail Processing
292938	E-Mail Task ID

File system / data file function

312977	Status of file operation
312978	Task ID

User-Programmable IP Interface

Reading the IP-PRIM connections list

350000	Last result (-1 = no connection selected)
350001	1 = Client; 2 = Server
350002	1 = UDP; 2 = TCP
350003	IP Address
350004	Port number
350005	Connection status
350006	Number of bytes sent
350007	Number of bytes received

Application Registers

1000000 ...	32 bit integer (remanent)
1005999	

CAN-PRIM register

200010500	CAN-PRIM status
200010501	CAN-PRIM command register
200010502	Message box number
200010503	FIFO level
200010504	FIFO data
200010506	Global receiving mask
200010507	Global receiving ID
200010510	Box status
200010511	Box configuration
200010512	CAN ID
200010513	Number of data bytes
200010514	Data bytes
...	
200010521	

Display

Function keys

361000 ...	Bit-coded mapping of function keys
361007	e.g. bit 0: 1 = key 1 is pressed

Ignition (IGN)

361100	Bit 0:
	0 = Ignition switched on
	1 = Ignition switched off

LEDs for keys

362000 ...	Bit-coded mapping of LEDs
362006	e.g. bit 0: 1 = LED key 1 on

I/O (IN1 ... IN15 and OUT)

362100	Bit-coded mapping of status LEDs
	e.g. bit 0: 1 = IN1 on
362200	Bit-coded mapping of output
	e.g. bit 0: 1 = OUT on

Digipot

363000	Current count value
363001	Digipot - Enter function
363002	Minimum count value
363003	Maximum count value

Display

364000	Backlighting
364001	Keys night-lighting
364003	Brightness sensor

Video

is displayed by default on object 14000 (rectangle)

364200	Video input (Input)
364201	Video input external Mux (only BTM 07)
364202	Video type
	1 = composite
	2 = svideo

364203	Video format
	1 = PAL
	2 = NTSC
364204	Video Options
	Bit 0: 1 = Interlaced
	Bit 1: 1 = Mirror vertical
364210	Video input brightness
364211	Video input contrast
364212	Video input saturation
364220	Video Output ID (Rectangle ID in IOP)
364230	Video Input Source X
364231	Video Input Source Y
364232	Video Input Source Width
364233	Video Input Source Height

Visualization

365000 ...	Name of IOP file
365029	
365050 ...	Name of language
365079	
365100	Language selection according to ID
365200	Number of available languages
365201	Current selection for the Info Register
365202	Info Register Default ID = 1
365203	Info Register size of IOP file
365210 ...	Info Register file name of IOP file
365240	
365260 ...	Info Register name of language
365289	

System status

367000	HAL name
367010	Backup battery / Battery full (> 2 V)

Special Flags - Network

2075	Error in networking via JetIP
------	-------------------------------

Special flags - interface monitoring

2088	OS flag - JetIP
2089	User flag - JetIP
2090	OS flag - SER
2091	User flag - SER
2098	OS flag - debug server
2099	User flag - debug server

32 Combined Flags

203100	0 ... 31
203101	32 ... 63
203102	64 ... 95
203103	96 ... 127
203104	128 ... 159
203105	160 ... 191
203106	192 ... 223
203107	224 ... 255

16 Combined Flags

203108	0 ... 15
203109	16 ... 31
203110	32 ... 47
203111	48 ... 63
203112	64 ... 79
203113	80 ... 95
203114	96 ... 111
203115	112 ... 127
203116	128 ... 143
203117	144 ... 159
203118	160 ... 175
203119	176 ... 191
203120	192 ... 207

203121	208 ... 223
203122	224 ... 239
203123	240 ... 255

32 Combined Special Flags

203124	2048 ... 2079
203125	2080 ... 2111
203126	2112 ... 2143
203127	2144 ... 2175
203128	2176 ... 2207
203129	2208 ... 2239
203130	2240 ... 2271
203131	2272 ... 2303

16 Combined Special Flags

203132	2048 ... 2063
203133	2064 ... 2079
203134	2080 ... 2095
203135	2096 ... 2111
203136	2112 ... 2127
203137	2128 ... 2143
203138	2144 ... 2159
203139	2160 ... 2175
203140	2176 ... 2191
203141	2192 ... 2207
203142	2208 ... 2223
203143	2224 ... 2239
203144	2240 ... 2255
203145	2256 ... 2271
203146	2272 ... 2287
203147	2288 ... 2303

Overlaid User Registers/Flags

1000000	256 ... 287
1000001	288 ... 319
1000002	320 ... 351
1000003	352 ... 383
1000004	384 ... 415
1000005	416 ... 447
1000006	448 ... 479
1000007	480 ... 511
1000008	512 ... 543
1000009	544 ... 575
1000010	576 ... 607
1000011	608 ... 639
1000012	640 ... 671
1000013	672 ... 703
1000014	704 ... 735
1000015	736 ... 767
1000016	768 ... 799
1000017	800 ... 831
1000018	832 ... 863
1000019	864 ... 895
1000020	896 ... 927
1000021	928 ... 959
1000022	960 ... 991
1000023	992 ... 1023
1000024	1024 ... 1055
1000025	1056 ... 1087
1000026	1088 ... 1119
1000027	1120 ... 1151
1000028	1152 ... 1183
1000029	1184 ... 1215
1000030	1216 ... 1247
1000031	1248 ... 1279
1000032	1280 ... 1311
1000033	1312 ... 1343
1000034	1344 ... 1375
1000035	1376 ... 1407
1000036	1408 ... 1439
1000037	1440 ... 1471
1000038	1472 ... 1503
1000039	1504 ... 1535
1000040	1536 ... 1567
1000041	1568 ... 1599
1000042	1600 ... 1631
1000043	1632 ... 1663

1000044	1664 ... 1695
1000045	1696 ... 1727
1000046	1728 ... 1759
1000047	1760 ... 1791
1000048	1792 ... 1823
1000049	1824 ... 1855
1000050	1856 ... 1887
1000051	1888 ... 1919
1000052	1920 ... 1951
1000053	1952 ... 1983
1000054	1984 ... 2015
1000055	2016 ... 2047

System Functions

4	BCD to HEX conversion
5	HEX to BCD conversion
20	Square Root
21	Sine
22	Cosine
23	Tangent
24	Arc Sin
25	Arc Cosine
26	Arc Tangent
27	Exponential Function
28	Natural Logarithm
29	Absolute value
30	Separation of digits before and after the decimal point
60	CRC generation for Modbus RTU
61	CRC check for Modbus RTU
65/67	Reading register block via Modbus/TCP
66/68	Writing register block via Modbus/TCP
90	Writing data file
91	Appending data file
92	Reading data file
96	Deleting data file
110	E-mail feature
150	Configuring NetCopyList
151	Deleting NetCopyList
152	Sending NetCopyList

Appendix

Introduction

This appendix contains electrical and mechanical data, as well as operating data.

Contents

Topic	Page
Technical Data	354
Index	362

A: Technical Data

Introduction

This chapter contains information on electrical and mechanical data, as well as on operating data of the JVM-407.

Contents

Topic	Page
Technical Data.....	355
Physical Dimensions.....	357
Operating Parameters - Environment and Mechanics.....	360
Operating Parameters - EMC	361

Technical Data

Technical Data - Electrical System: Power Supply

Parameter	Description
Rated voltage U BATT	DC 12 V or DC 24 V
Permissible voltage range	9 ... 32 VDC
Input current without camera	typ. 650 mA for DC 12 V
Input current without camera	typ. 320 mA for DC 24 V
Power consumption without camera	7.8 W

Camera Connection

Parameter	Description
Voltage	DC 12 V or U BATT, if U BATT < DC 13 V
Current	max. 1 A

Display

Parameter	Description
Display	7" TFT LCD flat screen
Brightness	LED backlight (white) 300 cd/m ²
Display resolution	800 x 480 pixels (WVGA)

Keys, Digipot

Parameter	Description
Keys	4 illuminated silicone keys with night-lighting
Digipot	16-position digital potentiometer with ENTER function

USB Stick

Parameter	Description
Memory size	up to 8 GBytes
Supply voltage	5 V, max. 150 mA
Short-circuit proof	yes, Short-circuit current: ~ 1 A

Memory Configurations

Parameter	Description
Number of remanent registers	6.000
Remanent memory for variables	24,000 bytes
Flash disk	12.875 MBytes

Battery

Parameter	Description
Operating life	up to 4 years
Battery type	CR1225 (lithium button cell)
Voltage	3 V
Capacity	48 mAh

**Technical Data -
Real-Time Clock**

Parameter	Description
Power reserve	4 years
Deviation	Max. 1 minute per month


Physical Dimensions

Introduction

This chapter details the physical dimensions of the JVM-407 and the conditions for installation.


Physical Dimensions

The diagram shows the dimensions of the JVM-407.



Permissible Installation Positions

The diagram shows the positions permitted for installation.




Explanations are as follows:

Number	Permissible Installation Positions
1	horizontally or tilted
2	vertical or tilted

Prohibited Installation Positions


The diagram shows the positions prohibited for installation.



The rear panel of the HMI JVM-407 has no moisture protection, particularly against spray or water droplets. If the installation location cannot be guaranteed to be moisture-free, this method of installation (see diagram above) is prohibited. The accumulation of moisture and water droplets in the device can lead to current leakages and corrosion.

Space Required for Installation and Service

The diagram shows the space required for the HMI JVM-407.



Ensure there is enough space around the housing for servicing requirements.


- It should be possible to disconnect the connector at any time.
- It should be possible to exchange the SD card at any time.
- It must be possible to easily loosen the wing nut on the SD card locking device.

Explanations are as follows:

Number	Description
1	Connectors for CANopen®, video, power supply, inputs and outputs
2	Wing nut to secure the SD card
3	Network connector
4	SD memory card

Space Required to Protect Against Overheating

The diagram indicates the safe distance to protect against overheating.



Please note:

- The JVM-407 increases the temperature of the environment as a result of heat emission under load. Power consumption is 7.8 W.
- The JVM-407 operates without interruption at an ambient temperature of up to +65 °C.

Consider the heat emission from the device, in particular when installing it in a critical environment:

- in the vicinity of the fuel tank
- in the vicinity of the fuel pipe
- in the vicinity of flammable vehicle components
- in the vicinity of thermally malleable vehicle components

Installation Location

The JVM-407 must be installed in the driver's cab.

Operating Parameters - Environment and Mechanics

Environment

Parameter	Value	Standard
Operating temperature range	-20 ... +65 °C	
Storage temperature range	-30 ... +80 °C	DIN EN 61131-2 DIN EN 60068-2-1 DIN EN 60068-2-2
Air humidity	10 ... 95 % Do not use a steam jet or other such devices to clean the JVM-407.	DIN EN 61131-2
Climate test	Humid heat	DIN EN 60068-2-30
Pollution degree	2	DIN EN 61131-2
Installation Location	The JVM-407 must be installed in the driver's cab.	

Mechanical Parameters

Parameter	Value	Standard
Vibration resistance	Vibration, broadband noise	DIN EN 60068-2-6 Severity level 2
Shock resistance	25 g occasionally, 11 ms, sinusoidal half-wave, 3 shocks in the directions of all three spatial axes	DIN EN 60068-2-27
Degree of protection Installation directly in console	front panel: IP64 rear panel: IP10	DIN EN 60529 including all changes to date
Degree of protection mounted on support arm	front panel: IP64 rear panel: IP64	DIN EN 60529 including all changes to date

Operating Parameters - EMC

EMC - Emitted Interference

As per Directive 72/245/EEC with all amendments up to 2009/19/EC checked and compliant.

EMC - Interference Immunity

Parameter	Value	Standard
Interference immunity to conducted faults	compliant	Directive 72/245/EEC with all changes up to 2009/19/EC
Interference immunity to external magnetic field	20 ... 1,000 MHz: 100 V/m 1,000 ... 2,000 MHz: 30 V/m	Directive 72/245/EEC with all changes up to 2009/19/EC
Load Dump	Impulse 5b 70 V	ISO 7637-2

B: Index

A

Application Program
 default path - 345
 loading - 344
 storing to an SD Card - 346
Automatic Copying of Controller Data - 312
 Example of a Command File - 328

C

CANopen® - 93
Changing an IP address - 76
Components of JVM-407 - 19

E

E-Mail Feature - 224
 Configuration - 225
 Creating E-Mails - 233
 Overview of Registers - 246
 Sending E-Mails - 240
EMC
 EMC - 14

F

File System - 151
 Formatting and Checking - 170
 Properties - 152
FTP Server - 177

H

HTTP Server - 181

I

Initial Commissioning - 81
Inserting Realtime Controller Values - 237
Installation
 Installing the Beam - 66
 Installing the JVM-407 - 63
Interfaces - 34
 CAN - 45
 CANopen® Bus Cable - Specification - 49
 Digital Inputs and Outputs - 38
 Ethernet - 43
 Example - Wiring - 35
 Power Supply - 36
 Video - 51

M

Memory - Overview - 193

Memory Types - 193
Modbus/TCP - 249
 Modbus/TCP Client - 255
 Modbus/TCP Server - 250
Monitoring Interface Activities - 219

N

Nameplate - 29

O

Operating Parameters
 EMC - 361
 Environment and Mechanics - 360
Operating System Update - 335
Order reference JVM-407 - 23
OS/Hardware Revision Registers - 31

P

Physical Dimensions - 24
Product Description – JVM-407 - 18
Programming
 Digipot - 207
 Digital Inputs and Outputs - 208
 Function Keys - 206
 Ignition and OFF delay - 209

Q

Quick Reference - 349

R

Real-time clock - 211
Runtime Registers - 215

S

SAE J1939 - 123
Safety Instructions - 11

T

Technical Data - 355

U

User administration - 156
User-Programmable CAN-PRIM Interface - 296
 Operating Principle - 297
 Overview of Registers - 303
 Programming the CAN-PRIM Interface - 299
 Restrictions - 298
User-programmable IP Interface - 268
 Overview of Registers - 283
 Programming the IP Interface - 270
 Sample Programs - 287



Jetter AG

Graeterstrasse 2
D-71642 Ludwigsburg

Germany

Phone: +49 7141 2550-0
Phone -
Sales: +49 7141 2550-433
Fax -
Sales: +49 7141 2550-484
Hotline: +49 7141 2550-444
Internet: <http://www.jetter.de>
E-Mail: sales@jetter.de

Jetter Subsidiaries

Jetter (Switzerland) AG

Münchwilerstrasse 19
CH-9554 Tägerschen

Switzerland

Phone: +41 71 91879-50
Fax: +41 71 91879-69
E-Mail: info@jetterag.ch
Internet: <http://www.jetterag.ch>

Jetter UK Ltd.

Old Witney Road
Eynsham
OX29 4PU Witney

Great Britain

Phone: +44 1865 883346
Fax: +44 1865 883347
E-Mail: info@jetter.uk.com
Internet: <http://www.jetter.uk.com>

Jetter USA Inc.

13075 US Highway 19 North
Florida - 33764 Clearwater

U.S.A

Phone: +1 727 532-8510
Fax: +1 727 532-8507
E-Mail: bschulze@jetterus.com
Internet: <http://www.jetter.de>