



User Manual

JC-970MC - Controller with Integrated Industrial PC

608 837 51

Item number: 608 837 51
Language of the original document: German
Document revision: 1.12.2
Date of issue: February 2018

This document has been compiled by Jetter AG with due diligence, and based on the known state of the art.

In the case of modifications, further developments or enhancements to products shipped in the past, a revised document will be supplied only if required by law, or deemed appropriate by Jetter AG. Jetter AG shall not be liable for any errors either in form or content, or for any missing updates, as well as for any damage or detriment resulting from such failure.

The logos, brand names, and product names mentioned in this document are trademarks of Jetter AG, of associated companies or other title owners and must not be used without consent of the respective title owner.

Address

How to contact us:

Jetter AG
Graeterstrasse 2
71642 Ludwigsburg, Germany
Germany

Phone - Switchboard:	+49 7141 2550-0
Phone - Sales:	+49 7141 2550-433
Phone - Technical Hotline:	+49 7141 2550-444
Fax - Sales:	+49 7141 2550-484
E-mail - Sales:	sales@jetter.de
E-mail - Technical Hotline:	hotline@jetter.de

Reference to products

This manual is an integral part of the JC-970MC control system:

Type: _____
Serial #: _____
Year of manufacture: _____
Order #: _____



To be entered by the customer:

Inventory #: _____
Place of operation: _____

Significance of this user manual

This document is an integral part of the JC-970MC:

- Keep this document in a way that it is always at hand until the JC-970MC will be disposed of.
- Pass this document on if the JC-970MC is sold or loaned/leased out.

In any case you encounter difficulties to clearly understand the contents of this document, please contact Jetter AG.

We would appreciate any kind of suggestions and contributions on your part. Please send your suggestions and comments to the e-mail address info@jetter.de. Your feedback will help us produce manuals that are more user-friendly, as well as address your wishes and requirements.

In this document you will find useful information on the following topics:

- Shipping
- Mechanical installation
- Electrical installation
- Programming
- Operation
- Maintenance
- Repairs

Therefore, you must carefully read, understand and observe this document, and especially the safety instructions.

In the case of missing or inadequate knowledge of this document Jetter AG shall be exempted from any liability. Therefore, the operating company is recommended to obtain the persons' confirmation that they have read and understood this manual in writing.

Table of contents

1	Safety instructions	9
	Basic safety instructions	10
	Instructions on EMC	12
2	Product description and configuration options	15
	Product description – JC-970MC	16
	Order reference/options	18
	Parts and interfaces	19
	Digital JX6-I/O submodule JX6-IO16CB of the JC-970MC-E01	22
	Physical dimensions	25
	List of documentation	26
3	Mechanical and electrical installation	29
3.1	Fastening and removing the JC-970MC	30
	Fastening the controller JC-970MC	30
	Removing the controller JC-970MC	31
3.2	Connections	32
	Power supply terminal X101	33
	Ethernet interface ETH - Port X102	34
	Ethernet interface ETH - Port X103	35
	Ethernet interface ETH - Port X104	35
	USB jacks - Port X105 and X106	36
	Jacks	37
	DisplayPort interface X109	38
	SD card interface - Slot SDCARD	38
	Serial interface RS-232 - Port X110	39
	Interface for digital inputs/outputs - Port X81 (variant -E01)	40
	Interface for rotary encoders - Port X82 (variant -E01)	40
3.3	JX2 system bus interfaces (variant -E01)	41
	JX2 system bus interfaces X91/X92 for variant -E01	42
	JX2 system bus - Pin assignment	43
	JX2 system bus cable - Specification	45
	JX2 system bus - Line lengths and baud rates	47
3.4	Local JX6-I/O submodules on the PCIe bus (variant -E01)	48
	Pinout of the JX6-SV1	49
	Pinout of the JX6-IO16CB	50
3.5	LEDs indicating various states	52
	LEDs GP	53
	GP1 ... GP4 LED indications during boot process	55
	Status LEDs - Ethernet interface	56
	Status LEDs	57
3.6	Control elements	58
	PWR button	59
	RSQ button	60
	Mode selector S11	61
3.7	Ethernet interface X102 - IP configuration	63
	Factory settings	64
	Determining the IP address of the JC-970MC	65
	The configuration memory	67

Table of contents

	Configuration file "config.ini".....	68
	Configuration registers	72
	Changing the IP address of the controller	73
	Making changes to the IP address of the JC-970MC using JetIPScan	74
	Setting the IP address via "config.ini" file	76
	Setting the IP address via non-volatile registers	77
	Setting the IP address automatically via USB flash drive	79
	Setting the IP address during runtime.....	80
	E-mail feature - Using names for IP addresses	81
	Setting a static route.....	83
4	Initial commissioning	87
	Preparations for initial commissioning of the controller.....	88
	Initial commissioning of a JC-970MC.....	89
5	Retrieving information on the controller	91
5.1	Identification by means of the nameplate.....	92
	Nameplate	92
5.2	Electronic Data Sheet EDS.....	93
	EDS File "eds.ini"	93
	EDS registers	96
5.3	Version registers	97
	Hardware revisions.....	97
	Software versions.....	97
6	Programming	99
	Abbreviations, module register properties and formats	100
	System run times, response times, remote peripheral devices	101
	Self-test and configuration check	101
6.1	Memory types - Overview.....	102
	Operating system memory	103
	File system memory	103
	Application program memory	104
	Memory for volatile application program variables.....	104
	Memory for non-volatile application program variables	105
	Special registers	107
	Inputs and outputs.....	108
	Flags.....	110
6.2	Numbering registers and I/Os.....	111
	Registers and module registers	112
	Slot numbering	114
	Register and I/O numbers of modules located on a riser card.....	115
	Register numbers of JX2 slave modules connected to the JX2 system bus	116
	Register and I/O numbers of JX2- and JX3-I/O modules on the JX2 system bus	117
	Register and I/O numbers of CANopen [®] modules on the JX2 system bus	119
	Register and I/O numbers of JX3 modules connected to a JX3-BN-ETH	121
	Real-time clock.....	123
	Technical specifications.....	123
6.3	Programming local JX6 submodules.....	124
	JX2- Systembus interface JX6-SB(- I)	125
	Digital I/O module JX6-IO16CB	127
	Combi module JX6-SV1	132
	Sample program for local JX6-I/O submodules	139

6.4	E-mail	143
6.4.1	Configuring the E-mail feature	144
	Structure of the configuration file	145
	Section [SMTP]	146
	Section [POP3].....	148
	Section [DEFAULT]	150
	Configuration file - Examples	151
6.4.2	Creating e-mails	152
	Name of the e-mail template file	153
	Structure of the e-mail template file	154
	Inserting real-time controller values	156
6.4.3	Sending an e-mail	161
6.4.4	Registers	162
	Registers - Overview.....	163
	Registers - Description.....	164
6.5	Sorting data	167
6.6	Modbus/TCP	168
6.6.1	Modbus/TCP server	169
	Addressing	170
	Supported commands - Class 0.....	172
	Supported commands - Class 1.....	173
	Supported commands - Class 2.....	174
6.6.2	Modbus/TCP client	175
6.6.3	Modbus/TCP client with STX variables	177
7	AutoCopy - Automatic copying of controller data	179
7.1	AutoCopy - How it works	181
	Launching the AutoCopy function	182
	Executing AutoCopy commands	183
	Terminating AutoCopy mode.....	184
8	Operating system update	185
8.1	Updating the operating system of the controller	186
	OS update by means of JetSym	187
	Updating the operating system by means of FTP.....	188
	Automatic OS update from USB flash drive.....	189
	Updating the OS from within the application program	190
8.2	Updating the operating system of a module	191
	OS update by means of JetSym	192
	Updating the operating system by means of FTP.....	193
	Automatic OS update from USB flash drive.....	194
	Updating the OS from within the application program	195
8.3	Updating the Windows® partition	198
9	Motion control	199
10	Quick reference - JC-970MC	200
Appendix 210		
A:	Technical specifications	211
	Technical specifications	212

Table of contents

	Operating parameters - Environment and mechanics	214
	CE directives, standards and certifications	215
B:	Additional information	216
C:	Index	217

1 Safety instructions

Introduction

This chapter contains safety instructions, information on residual dangers and measures for increasing electromagnetic immunity.

Content

Topic	Page
Basic safety instructions	10
Instructions on EMC	12

Basic safety instructions

Introduction

This device complies with the valid safety regulations and standards. Jetter AG attaches great importance to the safety of the users.

Of course, the user should adhere to the following regulations:

- Relevant accident prevention regulations
- Accepted safety rules
- EC guidelines and other country-specific regulations

Intended use

Usage according to the intended conditions of use includes operation in accordance with these operating instructions.

The controller JC-970MC is used to control machinery, such as conveyors, production machines, and handling machines.

Operate the JC-970MC only within the limits and conditions set forth in the technical specifications. The operating voltage of the JC-970MC is classified as SELV (Safety Extra Low Voltage). Therefore, the JC-970MC is not subject to the EU Low Voltage Directive.

Usage other than intended

This device must not be used in technical systems which to a high degree have to be fail-safe.

The JC-970MC is no safety-related part as per Machinery Directive 2006/42/EC. This device is not qualified for safety-relevant applications and must, therefore, NOT be used to protect persons.

If you intend to operate the device at ambient conditions not being in conformity with the permitted operating conditions, please contact Jetter AG beforehand.

Personnel qualification

Depending on the life cycle of the product, the persons involved must possess specific qualifications. These qualifications are required to ensure proper handling of the device in the corresponding life cycle.

Product life cycle	Minimum qualification
Transport/storage:	Trained and instructed personnel with knowledge in handling electrostatically sensitive components
Mounting/installation:	Specialized personnel with training in electrical engineering, such as industrial electronics technician.
Commissioning/programming:	Trained and instructed experts with profound knowledge of, and experience with, electrical/drive engineering, such as electronics engineer for automation technology.
Operation:	Trained, instructed and assigned personnel with knowledge in operating electronic devices.
Decommissioning/disposal:	Specialized personnel with training in electrical engineering, such as industrial electronics technician.

Modifications and alterations to the device

For safety reasons, no modifications and changes to the device and its functions are permitted.

Any modifications to the device not expressly authorized by Jetter AG will result in a loss of any liability claims to Jetter AG.

The original parts are specifically designed for the device. Parts and equipment from other manufacturers have not been tested by Jetter AG and are, therefore, not released by Jetter AG.

The installation of such parts may impair the safety and the proper functioning of the device.

Any liability on the part of Jetter AG for any damages resulting from the use of non-original parts and equipment is excluded.

Shipping

The device contains electrostatically sensitive components which can be damaged if not handled properly.

To exclude damages to the device during transport it must be shipped in its original packaging or in packaging protecting against electrostatic discharge.

- Use an appropriate outer packaging to protect the device against impact or shock.
 - In case of damaged packaging inspect the device for any visible damage. Inform your freight forwarder and Jetter AG.
-

Storing

When storing the device observe the environmental conditions given in the technical specification.

Repairing and maintaining

The operator is not allowed to repair the device. The device does not contain any parts that could be repaired by the operator.

If the device needs repairing, please send it to Jetter AG.

Disposal of obsolete equipment

When disposing of devices, the local environmental regulations must be complied with.

Instructions on EMC

Noise immunity of a system

The noise immunity of a system is determined by the weakest component of the system. For this reason, correct wiring and shielding of cables is of paramount importance.

Measures

Measures for increasing EMC in electric plants:


- Follow the instructions given in Application Note 016 *EMC-Compatible Installation of the Electric Cabinet*.

The following instructions are excerpts from Application Note 016:

- **Physically separate** signal and power lines. Jetter AG recommend spacing greater than 20 cm. Cables and lines should cross each other at an angle of 90°.
- The following line cables must be shielded:
Analog lines, data lines, motor cables coming from inverter drives (servo output stage, frequency converter), lines between components and interference suppressor filter, if the suppressor filter has not been placed at the component directly.
- Shield cables **at both ends**.
- Unshielded wire ends of shielded cables should be as short as possible.
- Draw the **entire shield** behind the isolation, and then clamp it under an earthed strain relief with the **greatest possible surface area**.

When male connectors are used:

- Draw the shield, in its entire perimeter, under the shielding clamp of the metallized connector housing (impedance shielding), respectively of the EMC gland bushing, its greatest possible surface area being clamped under a strain relief.
- Only use metallized connectors, e.g. Sub-D with metallized housing. Make sure that the strain relief is directly connected with the housing here as well.



Downloading Application Note 016

You can download Application Note 016 from the Jetter AG **Homepage** <http://www.jetter.de>. You will find Application Note 016 *EMC-compatible installation of electric cabinets* at *Downloads - Application Notes*.

**Notice!**

If you want to route USB ports to the outside of an electric cabinet, e.g. using a Weidmüller USB adaptor IE-FCM-USB-AB (1222550000), please use USB cables by Lindy (e.g. item number 41612, length 2 m, www.lindy.de).“

**Notice!**

As connection cable between DisplayPort and display, we recommend DisplayPort cables from Lindy (e.g. item number 41533, length 3 m, www.lindy.de).

2 Product description and configuration options

Introduction

This chapter covers the design of the device, as well as how the order reference is made up including all options.

Content

Topic	Page
Product Description - JC-970MC	16
Parts and interfaces.....	18
Order reference/options.....	18
Physical dimensions	25
List of documentation	26

Product description – JC-970MC

The controller JC-970MC

The JetControl 970MC is a PC-based high-end controller of excellent performance for control tasks.

It is logically divided into a controller (hereinafter referred to as JetControl or realtime partition) and an industrial PC with Windows® operating system. The industrial PC performs tasks that do not have to be in real-time, such as visualization tasks, storage of data, e.g. recipes, or database applications.


The controller, on the other hand, takes on hard real-time tasks, such as motion control.

The JC-970MC offers a motion control feature which lets the user program axis groups and complex path controls. Special attention was given to straightforward and efficient realization of complex path controls.

The controller can be integrated into a network via its Ethernet port.

The compact case of the controller JC-970MC has a fanless design and is equipped with a heat sink. The controller has been designed for being installed in a control cabinet.

Windows® PC operating systems do not have the real-time capability required to control industrial plants. Therefore, the JC-970MC uses a real-time operating system (RTOS) in parallel with Windows OS. This design allows deterministic processing of real-time tasks. Resources are allocated between these two operating systems by the virtualization software Hypervisor. The advantage of the virtualization approach is that RTOS is kept operational even when the Windows OS crashes. Furthermore, Windows can be shut down separately, while the controller continues to run. The strict separation of these two operating systems ensures a high level of stability. There is a direct connection between Windows and RTOS via an internal IP interface. This internal interface has got the IP address 192.168.2.3.



The two Ethernet ports X102 and X104 allow for access/remote access to the controller. Thus, remote maintenance of the Windows IPCs (via X104) and/or of the controller itself (via X102) is possible.

Controller and Windows IPC have got separate mass storages. For the IPC an SSD is used, for the controller a flash disk. This lets you easily update the controller via USB flash drive using the AutoCopy feature.

The register interface allows for direct data base access.

The JC-970MC can be equipped with two JI-PCIE-xxx cards. These cards must already be included in the order as they cannot be retrofitted.

Remote peripheral modules can be connected via Jetter Ethernet system bus.

Control and visualization are combined in one device. This reduces the number of components in the control cabinet

Product features

The product features are listed below:



- Hypervisor technology is used to separate the controller's OS from Windows.
- 250 point-to-point (PTP) axes via Ethernet
- 64 MC axes via Ethernet
- 60 point-to-point (PTP) axes via JX2 system bus (equipped with JX6-SB-I)
- 2 Ethernet ports (1 x Windows, 1 x RTOS)
- 4 USB ports (2 x Windows, 2 x RTOS)
- Powerful programming language JetSym STX
- Non-volatile registers (NVRAM): 120,000
- SDRAM: 64 MB as shared data and program memory
- Flash disk: 32 MB (RTOS)
- SSD 60 GB (Windows)
- Real-time clock
- Integrated Web server/e-mail feature
- Modbus/TCP

Engineering notes

JC-970MC supports the axis combinations listed below:

Max. number of PCIe riser cards JI-PCIE-Exx	Max. number of JX6-SB-I submodules	Max. number of PTP axes per JX6-SB-I	Total number of PTP axes connected to JX6-SB-I	Max. number of MC axes via Ethernet (X102)	Max. number of PTP axes via Ethernet (X102)
2	4	15	60	64	250



Notice!

JX6-SB-I: JX6-SB-I submodules do not support MC axes. Point-to-point axes only (PtP)

2 Product description and configuration options

Scope of delivery

The following items are included in the scope of delivery:

Quantity	Description
1	Controller JC-970MC
1	Power Subcon connector, 3-pin PSC 1.5/3-F
1	Microsoft® Software license agreement
1	Installation manual

Order reference/options

Order reference

The order reference consists of the name of the JC-970MC and the desired options. Each of the additional options given below supplements the JC-970MC. The order reference only reflects existing options.

JC-970MC	-	Exx
----------	---	-----

Element	Description
JC-970MC	Controller
E01	Two PCIe slots equipped with the following submodules: <ul style="list-style-type: none">• JX6-SB• JX6-SBI• JX6-IO16• JX6-SV

Item no.	Order reference	
10000741	JC-970MC	64 MC axes; no JI-PCIE-Exx expansion

Ordering additional options

The JC-970MC cannot be retrofitted with JI-PCIE-Exx cards by the customer. Retrofitting can be done by Jetter AG after sending in the device.

Integrated Web server and e-mail feature

If the controller JC-970MC is equipped with integrated Web server and e-mail feature, it is able to perform the following functions:

- **HTTP Server:** This feature lets the user download the homepages into the controller via FTP. These homepages can be accessed with any standard Internet browser.
 - **SMTP client:** This feature lets the controller send e-mails.
-


Modbus/TCP

The JC-970MC supports the **Modbus/TCP** protocol. The controller can act as both server (class 0, 1, 2) and client (class 0).

Parts and interfaces

Parts and interfaces

The controller JC-970MC features the following parts and interfaces:



The illustration shows variant -E01.

Number	Element	Description
1	X101	Power supply
2	X102 (ETH)	Ethernet port for connecting programming PCs, servo amplifiers JM-200-ETH, JX3-BN-ETH, Modbus-TCP and user-programmable TCP/IP devices to the controller.
3	X103 (ETH)	Ethernet port. Not used at the moment. Earmarked for real-time Ethernet, e.g. EtherCAT®

2 Product description and configuration options

Number	Element	Description
14	X104 (ETH)	Ethernet interface of the Windows operating system (= IPC side. Not accessible from the controller side!) An external programming PC can be connected here. To access the controller, the specific internal IP address 192.168.2.3 of the JetControl must be used.
4	X105	Bootable USB port (USB 3.0/2.0), e.g. for data backup. This port is only available from the IPC (Windows) side!
	X106	USB port (USB 3.0/2.0) For connecting a mouse, keyboard, etc. This port is accessible only from the IPC side!
5	X107/108	USB port (USB 2.0) For connecting a USB flash drive (USB 2.0) for AutoCopy purposes. This port is accessible only from the control system (RTOS)!
6	X109	Display port For connecting a digital monitor.
7	SDCARD	Card reader slot for SD memory cards The card reader supports SD/SDHC/SDXC SD memory cards. The "SD" LED indicates card reader activity. Note: To prevent data loss, the SD card must not be removed while the "SD" LED is lit. This port is accessible only from Windows OS!
8	S11 Mode selector	The mode selector has 3 positions: RUN Once the JC-970MC is energized, it boots and launches the application program. STOP Once the JC-970MC is energized, it boots, but does not launch the application program. LOAD The controller boots up, but does not launch the STX application program. Instead, it switches to AutoCopy mode.
9	X110	Serial interface RS-232 This interface is available only to Windows!
17	Status LEDs THERM/DRIVE/SD/WD	System status indicators THERM Temperature DRIVE Hard disk activity SD Card reader activity WD Watchdog timeout

Number	Element	Description
18	General LEDs GP1 ... GP4	Operating status indicators - Controller section
19	PWR LED	Indicates that the device is energized - Normal operation - green, lit - Standby mode - green, flashing
	PWR button	The PWR button works as an interrupter which lets you shut down and restart the device. See warning on page 59.
20	RSQ LED	Flashing red if the backup flash has been selected for booting.
	RSQ button	In the case of a corrupted BIOS flash, the RSQ button lets you force the controller to boot into a defined and safe state to allow for troubleshooting.
10	X92	Option (-E01): SB - JX2 system bus interface for connecting non-intelligent JX2 and CANopen [®] modules.
11	X91	Option (-E01): SB-I - JX2 system bus interface for connecting intelligent or non-intelligent JX2 and CANopen [®] modules.
12	X82	Option (-E01): SV - Counter module for connecting an incremental or absolute (SSI) rotary encoder.
13	X81	Option (-E01): IO16CB - IO module for connecting digital inputs and outputs
15	X205	Not assigned
16	Mounting holes	Machined keyholes (4x) for fixing the device in the electric cabinet.

2 Product description and configuration options

Optional Interfaces

At the moment, JC-970MC is available in the following configurations:

- JC-970MC-E01 equipped with the submodules listed below:

Number	Element	Description
13	X81	IO16CB - IO module for connecting digital inputs and outputs
12	X82	SV - Counter module for connecting an incremental or absolute (SSI) rotary encoder.
11	X91	SBI - Interface module for connecting Jetter's JX2 system bus (SBI = System Bus Intelligent)
10	X92	SB - Interface module for connecting Jetter's JX2 system bus (SB = System Bus)

Digital JX6-I/O submodule JX6-IO16CB of the JC-970MC-E01

Introduction

The digital input/output module is equipped with eight galvanically isolated 24 V inputs, and eight galvanically isolated 24 V outputs with a maximum current of 0.5 A each.

Inputs

The inputs are type 3 inputs and their voltage range is DC -3 V ... DC +32 V. An input voltage of -3 V ... 5 V corresponds to logic 0 and an input voltage of +12 V ... +32 V corresponds to logic 1.



Notice!

Possible damage to the device!
If a line with reverse polarity is connected, the digital input can be destroyed.

The input resistance is 4.7 kΩ. All inputs are electrically isolated through optocouplers.





Fig.: JX6-IO16CB - input circuit

The delay time of the transition from 0 to 1 or from 1 to 0 depends on the adjustable filter and can be set between 20 μs and 16 ms. The signal evaluation is carried out statically in the application program.



Legend
 U_{IN} - Input voltage
 I_{IN} - Input current
 U_{Hmax}, and U_{Hmin} - Voltage thresholds for the ON (1) condition
 I_{Hmax}, and I_{Hmin} - Current thresholds for the ON (1) condition
 U_{Tmax}, and U_{Tmin} - Voltage thresholds for the transition between ON OFF
 U_{Lmax}, and U_{Lmin} - Voltage thresholds for the OFF (0) condition
 I_{Lmax}, and I_{Lmin} - Current thresholds for the ON (0) condition

Fig.: Digital inputs - Current/voltage diagram

Length of connecting cables: Assuming a standard control cable with a capacitance of 300 nF/km and an input resistance of 4.7 kΩ and the shortest pulse duration of 20 μs, this results in a maximum cable length of 4.7 m. A pulse duration of 2 ms results in a cable length of 470 m.

Outputs

All outputs are protected against short circuit, undervoltage and thermal overload. The permissible supply voltage range is DC 18 V ... 32 V. The propagation delay of the outputs is < 200 μs. All outputs are electrically isolated through optocouplers.

The outputs are able to drive ohmic, capacitive and inductive loads. Without an additional discharge circuit, the maximum demagnetizing power under inductive load is limited to 200 mJ. The demagnetization voltage is approx. 45 V (max. 55 V) below the supply voltage of DC 24 V.

In the event of an error (overload, short circuit), the drivers generate an error signal. This can be filtered with a digital filter.

2 Product description and configuration options

The module can also be configured so that all outputs switch off when an error condition occurs (output register = 0).

If the supply voltage fails, all outputs are 0. The outputs are non-latching. If the controller starts in RUN mode, the outputs are switched according to the application program. If the controller starts in STOP mode, all outputs are 0.

Technical specifications JX6-IO16CB

General Data

Parameter	Description
Supply voltage (device internal)	+5 V DC +/- 5 %
Current consumption	approx. 0.25 A
Ambient temperature (in operation)	0 ... 55 °C
Forced ventilation	No
Air humidity	0 ... 95 % (non-condensing)

Inputs DC 24 V


Parameter	Description
Permissible voltage range	DC -3 ... +32 V
Voltage range for logic 0	DC -3 ... +5 V
Voltage range for logic 1	DC +12 ... +32 V
Filtering	Adjustable
Input resistance	4.7 kΩ
Insulation voltage	500 V

Outputs DC 24 V


Parameter	Description
Supply voltage	Min. DC +18 V DC, max. +32 V
Current consumption (all outputs disabled)	< 0.05 A
Voltage drop (output current 0.5 A)	0.4 V (0.6 V max.)
Leakage current	Max. 300 μA
Short-circuit current	Typically 0.7 A (1.4 A max.)
Switching delay	< 200 μs
Switch-off delay (error condition for all outputs off)	Adjustable
Permissible capacitive load	<10 μF
Permissible inductive load	<1 H
Diversity factor (40 °C)	1
Diversity factor (55 °C)	0.7

Physical dimensions

Mounting dimensions



Front view/view from right



Top view

All dimensions in mm.

Minimum clearances

To ensure sufficient convective air flow, the clearances mentioned below must be observed in mounting the JC-970MC in the control cabinet.

- Minimum clearance, above: 100 mm
- Minimum clearance, below: 100 mm
- Minimum clearance, right-hand side: 50 mm

Mounting orientation

The orientation of the JC-970MC is vertical.



List of documentation

Introduction

Various documents and software tools support you in engineering, installing and programming the JC-970MC. You can download both the documents and software tools from our **homepage** at <http://www.jetter.de>.



Engineering

The following documents and files support you in engineering the controller:

	Industrial automation catalog
	<ul style="list-style-type: none">Product descriptionTechnical specifications
	Manual on the controller JC-970MC
	<ul style="list-style-type: none">The document at hand



Engineering a JX2 station on the JX2 system bus

The following document and the following software tool support you in engineering a JX2 station on the JX2 system bus (JC-9xx):

	JX6-SB/JX2 system bus - User information
	<ul style="list-style-type: none">System bus topologyJX2 system bus specification
	System bus configurator
	<ul style="list-style-type: none">Excel file supporting you in engineering the JX2 system bus: JX2 System Bus Configurator



Engineering a JX3 station on the JX3 system bus

The following document and the following software tool support you in engineering a JX3 station on the JX3 system bus (JX3-BN-ETH):

	User manual on the bus node JX3-BN-ETH
	<ul style="list-style-type: none">Engineering a JX3 stationProduct descriptions on JX3 modules
	System bus configurator
	<ul style="list-style-type: none">Excel file supporting you in engineering the JX3 system bus: JX3 System Bus Configurator





Electrical installation

The following documents support you in installing the controller:

	<p>Installation manual</p> <p>It is included in the boxed JC-970MC and contains the following information:</p> <ul style="list-style-type: none"> ▪ Installing the controller ▪ Terminal assignments ▪ Specification of terminals ▪ Diagnostics by means of LEDs
	<p>User manual on the JC-970MC</p> <ul style="list-style-type: none"> ▪ The document at hand

Programming

The following documents and files support you in programming the controller:

	<p>User manual on the JC-970MC</p> <ul style="list-style-type: none"> ▪ The document at hand
	<p>JX6-SB - User information</p> <ul style="list-style-type: none"> ▪ Configuring the JX2-system bus ▪ Module numbering system ▪ Diagnostics of modules on the JX2 system bus
	<p>Application-oriented manuals</p> <ul style="list-style-type: none"> ▪ Jetter Ethernet system bus ▪ File system ▪ User-programmable PRIM interface ▪ System registers
	<p>Programming tool</p> <ul style="list-style-type: none"> ▪ JetSym

2 Product description and configuration options

3 Mechanical and electrical installation

Purpose of this chapter This chapter supports you in mechanical and electrical installation of the JC-970MC and describes the following topics:

- Mechanical installation
- Wiring the JC-970MC
- Description of indicators
- Description of control elements

Content

Topic	Page
Fastening and removing the controller JC-970MC.....	30
Connections.....	32
JX2 system bus interfaces (variant -E01).....	41
Local JX6-I/O submodules on the PCIe bus (variant -E01).....	48
LEDs indicating various states	52
Control elements.....	58
IP configuration.....	63

3.1 Fastening and removing the JC-970MC

Introduction


This chapter describes how to install and remove the controller JC-970MC.

Fastening the controller JC-970MC

Fastening

To fasten the controller JC-970MC, proceed as follows:

Step	Action
1	Hold the JC-970MC in vertical direction to the panel of the control cabinet, as is shown in the illustration below.
2	Make sure that the clearance above and below the controller is 100 mm respectively. For sufficient air circulation, a clearance of at least 50 mm must be kept on the side of the heat sink.
3	Mark on the panel four positions for the fastening screw threads. The dimensions can be taken from the illustration below.
4	Drill the holes and tap the threads.
5	Screw the fastening bolts into the thread by half of their length.
6	By means of the keyholes in the rear panel, hang up the controller by the fastening screws. Then screw them down tightly.



All dimensions in mm.

Removing the controller JC-970MC

Removal

To remove the controller JC-970MC, proceed as follows:

Step	Action
1	Remove power from the controller JC-970MC.
2	Disconnect all cables.
3	Unscrew the four fastening screw by half of their length.
4	Remove the controller JC-970MC from the fastening screws.

3.2 Connections

Content

Topic	Page
Power supply terminal X101	33
Ethernet port X102.....	34
Ethernet port X103.....	35
Ethernet port X104.....	35
USB ports X105 ... X108.....	36


Power supply terminal X101

Terminal X101

The power supply unit connects to terminal X101.

Pin assignment



Pin	Description
+	Supply voltage
	PE conductor
-	Reference potential

Technical specifications

Parameter	Description
Rated voltage	DC 24 V
Permissible voltage range	-15 % ... +20 %
Input current	6 A max. typical load 1.2 A (without USB)
Power consumption	144 W max.
Protection against polarity reversal	Yes



Notice!

Possible damage to the device!
If the power supply of the controller is outside the specification (voltage, frequency), this can lead to its destruction.

Connector for power supply terminal X101

The scope of delivery includes a 3-pin connector.

3 Mechanical and electrical installation

Terminal


Parameter	Description
Technology	Screw terminal
Screwdriver	SZS 0.6 x 3.5
AWG	16 ... 28
Single conductor	0.14 mm ² ... 1.5 mm ²
Flexible conductor	0.14 mm ² ... 1.5 mm ²
With wire end ferrule	0.14 mm ² ... 1.5 mm ²
Wire end ferrule with sleeve	0.14 mm ² ... 1.5 mm ²

Ethernet interface ETH - Port X102

Connection options

Port X102 lets you connect, for example, a programming PC to the controller (RTOS side)

Port X102



LED	Description
ACT/LINK	Is lit if X102 is connected to an Ethernet network.
SPEED	Indicates the connection speed: Off = 10 Mbit/s Green = 100 Mbit/s Amber = 1000 Mbit/s

Technical specifications

Parameter	Description
Connector type	RJ45 Ethernet port
Bit rate	10 MBit/s, 100 MBit/s (Cat 5e) 1,000 MBit/s (Cat 6)
Auto-crossover	Yes

Cables for ports X102 ... X103

For connecting devices to ports X102, X103 and X104 you can order the following cables:


Item no.	Item
60537500	Patch cable 1:1, 1 m gray Hirose, Cat 5e, shielded
60854512	Patch cable 1:1, 2 m gray Hirose, Cat 5e, shielded
60854514	Patch cable 1:1, 5 m gray Hirose, Cat 5e, shielded
60854515	Patch cable 1:1, 10 m gray Hirose, Cat 5e, shielded

Ethernet interface ETH - Port X103

Connection options

Port X103 is not used at the moment.

Port X103




Ethernet interface ETH - Port X104

Connection options

Port X104 is for connecting the integrated Windows IPC to an Ethernet network.

Port X104



LED	Description
ACT/LINK	Is lit if X104 is connected to an Ethernet network.
SPEED	Indicates the connection speed: Off = 10 Mbit/s Green = 100 Mbit/s Amber = 1000 Mbit/s

3 Mechanical and electrical installation

Technical specifications

Parameter	Description
Connector type	RJ45 Ethernet port
Bit rate	10 MBit/s, 100 MBit/s (Cat 5e) 1,000 MBit/s (Cat 6)
Auto-crossover	Yes

USB jacks - Port X105 and X106

Connection options

Ports X105 and X106 (USB 3.0) connect to USB devices (USB 3.0/2.0), such as mouse, keyboard, etc.

Ports X105 and X106 can be accessed only from the Windows operating system of the IPC.

Ports X105 and X106



Number	Description
X105	USB port 1 (USB 3.0)
X106	USB port 2 (USB 3.0)

Technical specifications

Parameter	Description
Maximum output current	0.9 A
USB type	Type A (host)
Specification	USB 3.0
Maximum permissible cable length	3 m

Jacks

Connection options

Ports X107 and X108 (USB 2.0) connect to USB flash drives. Access to the USB flash drive is possible only from the controller (RTOS).

The Autocopy function, see chapter 7 “AutoCopy - Automatic copying of controller data” on page 179 lets you automatically copy controller data from a USB flash drive to the controller or vice versa. To this end, sub-directory USB1 of the file system is used. For this, the USB flash drive must be connected to port X108.



Notice!

During operation, the assignment of USB1/USB2 to X107/X108 is not fix. The jack into which the first USB flash drive is plugged is automatically designated USB1. If a second USB flash drive is connected, USB2 is assigned to the corresponding jack. If the controller is rebooted with two inserted USB flash drives, X108 is automatically designated USB1.

For the AutoCopy function, the USB flash drive must be connected to the USB interface USB1. With jack X108 it is guaranteed in any case that USB1 is assigned to it when the controller is rebooted with inserted USB sticks.

- Therefore, plug the USB flash drive always into jack X108 for the AutoCopy function.

Ports X107 and X108



Number	Description
X107	USB port 2 (USB 2.0)
X108	USB port 1 (USB 2.0)

Technical specifications

Parameter	Description
Maximum output current	0.5 A
USB type	Type A (host)
Specification	USB 2.0
Maximum permissible cable length	5 m

**Notice!**

If you want to route USB ports to the outside of an electric cabinet, e.g. using a Weidmüller USB adaptor IE-FCM-USB-AB (1222550000), please use USB cables by Lindy (e.g. item number 41612, length 2 m, www.lindy.de).“

DisplayPort interface X109

Connection options

Port X109 connects to an external (digital) display.

Port X109**Note on EMC**

If there is image interference (stripes in the image) on the connected display, the display is exposed to increased EMC noise. We recommend the use of high-quality cables and ferrite cores, which can also be retrofitted into the display cable. Ferrite cores for retrofitting are available under our item number 60240700.

**Notice!**

As connection cable between DisplayPort and display, we recommend DisplayPort cables from Lindy (e.g. item number 41533, length 3 m, www.lindy.de).

SD card interface - Slot SDCARD

Connection options

Port X107 is a standardized slot for SD cards of the type SD/SDHC/SDXC. The **SD** LED indicates card reader activity. The card reader supports hot-plugging of SD cards and system booting. SD cards can be accessed only from Windows OS.

SDCARD

**Notice!**

Loss of data!

To prevent data loss, do not remove the SD card while the "SD" LED is lit.

Serial interface RS-232 - Port X110

Connection options

The serial interface is available only to Windows OS.


Port X110

Interface for digital inputs/outputs - Port X81 (variant -E01)

Connection options

Port X81 is the 25-pin female Sub-D connector of the I/O module **JX6-IO16CB**.
Port X81 connects to digital inputs or outputs.

Port X81



Contact assignment


For information on pin assignment refer to chapter 3.4, starting from page 48.

Interface for rotary encoders - Port X82 (variant -E01)

Connection options

The 15-pin Sub-D connector X82 **SV** connects to an incremental or absolute (SSI) rotary encoder.

Port X82



Contact assignment

For information on pin assignment refer to chapter 3.4, starting from page 48.

3.3 JX2 system bus interfaces (variant -E01)

Introduction This chapter describes the JX2 system bus interfaces of the JC-970MC, variant -E01. Connectivity between system bus and controller is provided via PCIe bus on the controller.

Possible number of JX2 system busses A riser card lets you plug two JX6-SB(-I) cards (variant E01) into the PCIe bus on the controller JC-970MC. That is, up to 2 JX2 system busses can be connected to the controller.
Submodules JX6-SB and JX6-SB-I take on converting the internal PCIe bus to the JX2 system bus.

Supported Modules The JX2 system bus on controller JC-970MC supports the following type of modules:

- JX2-I/O modules
- JX2 slave modules
- Servo amplifiers JetMove 1xx, JetMove 2xx, and JetMove 6xx
- IP67 modules Lion-S, and LJX7-CSL
- Third-party CANopen[®] modules, e.g. valve terminals

For more information about the peripheral devices, refer to the manuals of the respective devices and the application-oriented manuals.


Expandability Up to 31 JX2-I/O modules, 10 Smart-I/O modules, third-party CANopen[®] modules, as well as 16 JX2 slave modules or JetMoves can be connected to each of the JX2 system busses.

Content

Topic	Page
Position of system bus interface	42
JX2 system bus - Pin assignment	43
JX2 system bus cable - Specification	45
Line length and baud rate of the JX2 system bus	47

JX2 system bus interfaces X91/X92 for variant -E01


Location of the JX2 system bus interfaces X91/X92



Number	Element	Description
1	X91	JX2 system bus interface SBI
2	X92	JX2 system bus interface SB

JX2 system bus - Pin assignment

**Sub-D connector X91 -
Pin assignment**



Pin	Signal	Description
1	CMODE0	Commissioning
2	CL	Data signal
3	GND	Reference potential
4	CMODE1	Commissioning
5	Unused	
6	Unused	
7	CH	Data signal
8	Unused	
9	Unused	

3 Mechanical and electrical installation

Technical specifications

Parameter	Description
Type of connector	Female Sub-D connector
Number of pins	9
Electrical isolation	None
Baud rates	1,000/500/250/125 kBaud

Suitable cables

For connecting modules to the JX2 system bus you can order the following cables separately:


Item no.	Item
10309001	Cable assy # 530 0.2 m
10309002	Cable assy # 530 0.5 m
10309003	Cable assy # 530 1.0 m
10309004	Cable assy # 530 1.5 m
10309006	Cable assy # 530 2.0 m
10309016	Cable assy # 530 2.5 m
10309015	Cable assy # 530 3.0 m
10309007	Cable assy # 530 4.0 m
10309008	Cable assy # 530 5.0 m

JX2 system bus cable - Specification

JX2 system bus cable - Specification

Parameter	Description
Wire cross-section	1,000 kBaud: 0.25 ... 0.34 mm ² 500 kBaud: 0.34 ... 0.50 mm ² 250 kBaud: 0.34 ... 0.60 mm ² 125 kBaud: 0.50 ... 0.60 mm ²
Cable capacitance	60 pF/m max.
Resistivity	1,000 kBaud: max. 70 Ω/km 500 kBaud: max. 60 Ω/km 250 kBaud: max. 60 Ω/km 125 kBaud: max. 60 Ω/km
Number of cores	5
Shielding	Complete shielding, no paired shielding
Twisting	CAN_L and CAN_H cables are twisted pairwise

Connection diagram



Number	Part	Description
1	Male sub-D connector, 9-pin	For connection to BUS OUT
2	Female Sub-D connector, 9-pin	For connection to BUS-IN
3	Not connected	Do not connect these pins

3 Mechanical and electrical installation

Sub-D connector (male) Pinout of the 9-pin male Sub-D connector at the JX2 system bus cable:

Pin	Signal name	Description
1	CMODE0	Commissioning
2	CAN-L	Data signal
3	GND	Reference potential
4	CMODE1	Commissioning
5	TERM	Short-circuited with pin 3
7	CAN-H	Data signal

Female Sub-D connector Pinout of the 9-pin female Sub-D connector to the JX2 system bus cable:

Pin	Signal name	Description
1	CMODE0	Commissioning
2	CAN-L	Data signal
3	GND	Reference potential
4	CMODE1	Commissioning
7	CAN-H	Data signal

JX2 system bus - Line lengths and baud rates

Line lengths

The maximum cable length depends on the baud rate used and the number of expansion modules connected to the bus.

Baud rate	Cable length	Stub length	Total stub length
1,000 kBaud	25 m max.	0.3 m max.	3 m
500 kBaud	100 m max.	1.0 m max.	39 m
250 kBaud	200 m max.	3.0 m max.	78 m
125 kBaud	200 m max.	-	-

Rules for calculating the stub length

When engineering the line length, follow the rules listed below:

- Each non-intelligent JX2-I/O module connected to the system bus reduces the maximum line length by 1.0 m
- Each connected intelligent JX2-I/O slave module reduces the maximum line length by 1.0 m
- Each JetMove reduces the maximum line length by 1.0 m
- Each connected IP67-I/O module reduces the maximum line length by 1.0 m

Baud rates

The baud rate setting depends on the number of modules connected to the JX2 system bus:

JX2-I/O modules JX2 slave modules JetMove	JX-SIO CANopen [®] modules	1,000 kBaud	500 kBaud	250 kBaud	125 kBaud
x		x	x	x	x
	x	x	x	x	x
x	x	x			x

3.4 Local JX6-I/O submodules on the PCIe bus (variant -E01)

Introduction	This chapter describes JX6-I/O submodules on the controller's internal PCIe bus. As they are located in the controller, they are called local submodules.						
Possible number of local JX6-I/O submodules	Up to 2 riser cards (JI-PCIE-Exx) can be plugged into the controller's PCIe bus. Each riser card can accommodate up to 2 local JX6-I/O submodules. Thus, the controller can be equipped with a maximum of 4 JX6 submodules. The riser card takes on converting the controller-internal PCIe bus to the local JX6-I/O submodules.						
Supported Modules	JI-PCIE-Exx riser cards support the following JX6-I/O submodules: <ul style="list-style-type: none">▪ JX6-SV1: Counter module for connecting an incremental or absolute (SSI) rotary encoder.▪ JX6-IO16CB: Digital inputs/outputs 24 V▪ JX6-SB/JX6-SB-I: System bus module (see chapter <i>JX2 system bus interface on the PCIe bus</i>)						
Allowed combinations	Each JI-PCIE-Exx riser card can accommodate up to 2 JX6-I/O submodules. However, only certain combinations are allowed due to mechanical restrictions.						
Content	<table><thead><tr><th>Topic</th><th>Page</th></tr></thead><tbody><tr><td>Pinout of the JX6-SV1.....</td><td>49</td></tr><tr><td>Pinout of the JX6-IO16CB.....</td><td>50</td></tr></tbody></table>	Topic	Page	Pinout of the JX6-SV1.....	49	Pinout of the JX6-IO16CB.....	50
Topic	Page						
Pinout of the JX6-SV1.....	49						
Pinout of the JX6-IO16CB.....	50						


Pinout of the JX6-SV1

JX6-SV1 - Functions

The female Sub-D connector of the I/O submodule JX6-SV1 interfaces with the following I/O functions:

- 1 incremental encoder input 5 V differential or
- 1 incremental encoder input 24 V or
- 1 absolute encoder input SSI

Sub-D connector - Pinout



Pin	Signal Incremental encoder 5 V differential in- cremental encoder	Signal Incremental encoder 24 V	Signal Absolute encoder SSI
1	GND	GND	GND
2	K0+	K0	Unassigned
3	K0-	Unassigned	Unassigned
4	K1+	K1	Data+
5	K1-	Unassigned	Data-
6	K2+	K2	Unassigned
7	K2-	Unassigned	Unassigned
8	Unassigned	Unassigned	Clock-
9	Unassigned	Unassigned	Clock+
10	DC 5 V (50 mA)	Unassigned	Unassigned

Technical specifications


Parameter	Description
Type of connector	Female Sub-D connector
Number of pins	15
Electrical isolation	Only at relay contact

Pinout of the JX6-IO16CB

JX6-IO16CB - Interfaces

The Sub-D connector of the I/O module JX6-IO16CB is the interface to digital inputs and outputs. For information on programming the module refer to chapter 6.3 Programming local JX6 submodules, page 124.

Sub-D connector - Pinout



Pin	Signal	Description
1	Output 8	
2	Output 7	
3	DC 24 V	Power supply of the outputs
4	Output 6	
5	Output 5	
6	GND_A	Reference potential of the outputs
7	DC 24 V	Power supply of the outputs
8	Output 4	
9	Output 3	
10	GND_A	Reference potential of the outputs
11	DC 24 V	Power supply of the outputs
12	Output 2	
13	Output 1	
14	Input 8	
15	GND_E	Reference potential of the inputs
16	Input 7	
17	Input 6	
18	Input 5	
19	DC 24 V	Power supply of the outputs
20	Input 4	
21	Input 3	
22	Input 2	
23	Input # 1	
24	GND_A	Reference potential of the outputs
25	Not determined	

Technical specifications

Parameter	Description
Type of connector	Female Sub-D connector
Number of pins	25
Electrical isolation	Yes
Rated voltage	DC 24 V
Number of inputs	8
Number of outputs	8
Peak current per output	0.5 A

3.5 LEDs indicating various states

LEDs of the JC-970MC

The JC-970MC features the following LEDs:

- 4 LEDs for indicating operating system conditions and errors
 - 4 LEDs for indicating drive activities, overtemperature, watchdog timeout of the controller
 - 2 LEDs per port for indicating conditions of the Ethernet ports
-

Content

Topic	Page
LEDs of the controller	53
LEDs of the controller during boot process.....	55
Status LEDs of the Ethernet interface	56
Status LEDs	57

LEDs GP

LEDs GP

LEDs **GP1 ... GP4** (**General Purpose LEDs**) are for indicating operating system conditions and errors.



LED	Color	Description
GP1	Green	OS is running (RUN)
GP2	Amber	Special conditions (D1)
GP3	Red	Error (ERR)
GP4		Not assigned

Normal operating condition








In normal operating condition and with the application program running, the LEDs **GP1 ... GP4** indicate the following:

GP3	GP2	GP1	State
○ OFF	○ OFF	● ON	Normal operating condition <ul style="list-style-type: none"> ▪ Application program is running ▪ No error

3 Mechanical and electrical installation

Status indications of LEDs GP1 ... GP4

The table below lists the possible states of LEDs **GP1 ... GP4**:

LED	State	Description
GP1 (RUN)	 OFF	No power supply or failure
	 1Hz	Application program is not being executed
	 ON	Application program is being executed
GP2 (D1)	 OFF	Normal operating condition
	 ON	Special conditions
GP3 (ERR)	 OFF	No error
	 ON	Error; refer to error register
















GP1 ... GP4 LED indications during boot process

Normal boot process

If the following requirements are met, the controller goes through its normal boot process:

- Mode selector S11 is in *RUN* position.
- There is a valid OS.
- There must be a valid application program.


Then, LEDs **GP1 ... GP3** indicate the following:

Step	Description			
	GP3	GP2	GP1	State
1	 ON	 OFF	 OFF	Reset
2	 OFF	 ON	 OFF	Initializing the runtime environment of the application program and real-time communication
3	 OFF	 ON	 OFF	Motion control start
4	 OFF	 ON	 ON	Initializing additional functions (Web, Modbus/TCP etc.)
5	 OFF	 OFF	 ON	Normal condition; the application program is being executed

Status LEDs - Ethernet interface

Status LEDs - Ethernet interface

The status LEDs of the Ethernet port are located in the immediate vicinity of the RJ45 jack.



LED	LED color	Description
SPEED	Off	Network connection speed
	Green	- 10 MBit/s
	Yellow	- 100 MBit/s - 1,000 MBit/s
ACT/LINK	Yellow	ACTIVE - Flashing
		LINK - Lit

Status LEDs

Status LEDs

The controller JC-970MC indicates conditions and drive activities via its status LEDs. The status LEDs are located in the upper part of the JC-970MC front panel.



Indications of status LEDs

The status LEDs indicate the following:

LED	Function	Color	Description
THERM	Overtemperature warning	Red, flashing	System is shutting down due to overtemperature
DRIVE	Hard disk activity	Green	HDD activity
SD	SD memory card	Green	SD card reader activity
WD	Watchdog	Red, flashing	Watchdog timeout

3.6 Control elements

Control elements of a JC-970MC

The JC-970MC features the following control elements:


- PWR button for switching the controller ON or OFF
 - RSQ button for booting the controller from backup flash
 - Mode selector S11 with the positions RUN, STOP, and LOAD
-

Content

Topic	Page
PWR button.....	59
RSQ button	60
Mode selector	61

PWR button

PWR button



Function of the pushbutton

The PWR button works as an ON/OFF switch.

As soon as voltage is applied to terminal X101, the controller boots and the status LED **PWR** is lit green. Depending on the position of the mode selector, the STX application program is loaded or not, or the AutoCopy function is launched.

If you press the PWR shortly, nothing happens, as the Hypervisor prevents the system from shutting down.

If you press the PWR button for more than 4 seconds, a forced shutdown is triggered. As this does not trigger a powerfail interrupt, the application registers will **not** be backed up. That's the reason why we recommend to interrupt the power supply instead. This will trigger the powerfail interrupt and the non-volatile register range (register no 1,000,000 ... 1,199,999) will be backed up.



NOTICE

Loss of data!

A forced shutdown by means of PWR button may result in loss of data or other undesirable effects! All changes made to non-volatiles registers and flags since the controller was energized last will be lost.

- Back up your data before you shut down the system.
- We recommend the following workflow:
 - First, shut down Windows.
 - Then, de-energize the device.



NOTICE

Damage to the device!

Even when the controller JC-970MC is turned off by pressing the PWR button, the system is still energized. To de-energize the system, remove the power supply from terminal X101.

RSQ button

RSQ button



Function of the pushbutton

Pressing the RSQ button causes the system to boot from the backup flash. The LED RSQ is flashing red if the backup flash has been selected for booting. The backup flash contains a cloned BIOS (UEFI) version. In the event the system does not properly start-up or gets hung-up and restarting (cold booting) does not help, the RSQ function lets you boot from the backup flash and restart the system. To this end, press the RSQ button for more than 5 seconds. Whether the system is running or not, it will start-up using the backup flash for booting.

To revert to the default boot flash, the system must be cold started. To this end, press the PWR button or remove the power supply voltage and then reapply it.




Notice!

The rescue function is not intended for use within an application. It is intended to force the controller in the case of a corrupted BIOS flash to boot into a defined and safe state to allow for troubleshooting.

Mode selector S11

Mode selector



Position	Description
RUN	Once the controller has booted up, it launches the STX application program.
STOP	The controller boots up, but does not launch the STX application program.
LOAD	The controller boots up, but does not launch the STX application program. Instead, it switches to AutoCopy mode.

3 Mechanical and electrical installation

Functions of the mode selector

JC-970MC checks the position of mode selector S11 and proceeds as follows:

Step	Description	
1	Power supply of the controller is at terminal X101.	
2	The boot loader of the controller checks the position of selector S11.	
	If then ...
	... mode selector S11 = <i>RUN</i> or <i>STOP</i> , the OS is launched; --> proceed with step 3.
... mode selector S11 = <i>LOAD</i> , the controller starts the AutoCopy function.	
3	The controller checks the position of selector S11.	
	If then ...
	... mode selector S11 = <i>RUN</i> , the application program is launched.
	... mode selector S11 = <i>STOP</i> , the application program does not start.
4	If then ...
	... the position of mode selector S11 is changed once the controller has been turned on, this has no effect on the functioning of the controller.

3.7 Ethernet interface X102 - IP configuration

Introduction

This chapter describes how to configure Ethernet port X102 which is attributed to the controller itself (RTOS). Ethernet port X104 which is attributed to Windows must be configured in the Windows settings.

You can configure the following parameters for X102:

- IP address of the controller
- Subnet mask
- IP address of default gateway
- Static route of the IP address
- Static route of the subnet mask
- Static route of the gateway
- IP address of DNS server
- Controller name
- IP port number for the JetSym debugger
- Basic port number for communication via JetIP

Required skills of the network configurator

IP networks:

- IP addressing (IP address, port number, subnet masks etc.)
- FTP (connection setup, data transmission, etc.)

Jetter Ethernet system bus

The Jetter Ethernet system bus (JetIPScan, JetSync, Publish/Subscribe, etc.) and thus synchronous transfer of data packets is supported by port ETH (X102) only.

Content

Topic	Page
Factory settings	64
Determining the IP address JC-970MC	65
Configuration memory	67
Configuration file "config.ini"	68
Configuration registers	72
Making changes to the IP addresses of the controller	73
Making changes to the IP addresses JC-970MC using JetIPScan	74
Setting the IP address by means of "config.ini" file	76
Setting the remanent IP address by means of registers	77
Setting the IP address automatically by means of a USB flash drive	79
Setting the IP address at runtime	80
Using names for IP addresses	81
Setting a static route	83

Factory settings

Introduction

Before the JC-970MC is shipped, various parameters are set to a certain value. These parameters can be changed by the user.

Factory settings

Parameter	Value
ETH (X102): IP address	192.168.1.1
ETH (X102): Subnet mask	255.255.255.0
ETH (X102): IP address of default gateway	0.0.0.0
IP address of DNS server	0.0.0.0
Controller name	JetControl970MC
IP port number for debugger	52000
IP port number for JetIP	50000
User's password <i>admin</i>	admin
User's password <i>system</i>	system

Determining the IP address of the JC-970MC

Introduction

The program JetIPScan lets you retrieve IP address, subnet mask and the IP address of the Default Gateway of the Ethernet port ETH (X102).

Downloading JetIPScan

You can download JetIPScan from the Jetter AG **homepage** at <http://www.jetter.de>. The location of **jetipscan_1-08-01.zip** is [Down-loads/Software/Classics/Additional software/jetipscan](http://www.jetter.de/Downloads/Software/Classics/Additional%20software/jetipscan).

Contents of the jetipscan_1-08-01.zip

The zip file **jetipscan_1-08-01.zip** contains the following files:

- The program **JetIPScanV1.08_01.exe**
- The help **jetipscan_01_help_en.png**
- A batch file **read_IP_via_JETIPSCAN.bat** to determine the IP address
- A batch file **write_IP_via_JETIPSCAN_10_150.bat** to set IP address 192.168.10.150 for the controller

The batch files launch the program JetIPScan.

The files are unzipped to the folder **jetipscan_1-08-01**.

Prerequisites



First, an Ethernet connection between the PC and the controller JC-970MC must be established.

Then launch the JetIPScan program on your PC, for example via batch file **read_IP_via_JETIPSCAN.bat**.

3 Mechanical and electrical installation

Determining the IP address

To determine the IP address of the JC-970MC, proceed as follows:

Step	Action
1	Launch the JetIPScan program on your PC.
⇒	Result: JetIPScan shows all IP addresses, which are presently active on your PC.
2	Select the interface (IP address) that is connected to the controller JC-970MC for which you want to determine the IP address.
	 <pre> C:\JetIPScan\JetIPScanV1.08_01.exe JetIPScan Version 1.08 Host name is GR-43580. Interface 1: 169.254.222.61 Type the number of the address to choose the interface: 1 </pre>
⇒	Result: Among others, JetIPScan shows the IP address of the controller (here MyJetControl-940).
	 <pre> C:\JetIPScan\JetIPScanV1.08_01.exe 1. response is received from the IP Address: 192.168.10.150 MAC-Address: 00.04.4f.01.14.92 ***** Received Message ***** Bytes Received : 70 Protocol ID : JCSP Protocol Version : 1.00 Message Type : Unicast Response Index : 00 00 Mac-Adresse : 00.04.4f.01.14.92 IP-Adresse : 192.168.10.150 IP-Gateway : 0.0.0.0 IP-Mask : 255.255.255.0 Node Identification : 43 43 -> JetControl Node Identification Type: 09 70 Version Nummer : 1.1.0.10 Node Name : MyJetcontrol-940 Timeout has been exceeded. There is only 1 online controller. Drücken Sie eine beliebige Taste . . . </pre>

The configuration memory

Introduction

During the boot process, the controller reads the parameters for initializing the IP interface from the configuration memory. Registers 101200 ... 101299 let you access the data stored in the configuration memory.

When does this take effect?

The controller reads out data located in the configuration memory only during the boot process. If you make changes to the configuration memory, reboot the controller. Only this way, these changes will take effect.

Default values

Before the controller further processes data from the configuration memory, it checks them for plausibility. **If entries are invalid or absent, the controller uses the following default values:**

Parameter	Default value
ETH (X102): IP address	192.168.10.150
ETH (X102): Subnet mask	255.255.255.0
ETH (X102): IP address of default gateway	0.0.0.0
IP address of DNS server	0.0.0.0
ETH (X102): Static route of the IP address	0.0.0.0
ETH (X102): Static route of the subnet mask	0.0.0.0
ETH (X102): Static route of the gateway	0.0.0.0
Controller name	JetControl970MC
Suffix type of the name	0
IP port number for debugger	52000
IP port number for JetIP	50000

Related topics

- **Configuration file** *config.ini* (see page 68)
 - **Configuration registers** (see page 72)
-

Configuration file "config.ini"

Introduction

If the data for initializing the Ethernet interface ETH (X102) in the configuration memory are invalid, the controller JC-970MC uses the settings from the configuration file **config.ini**. The JC-970MC also uses **config.ini** for the AutoCopy function.

Properties

- You can access the config.ini through the file system of the controller.
 - For an FTP connection, the user must have administrator or system rights.
 - This file is located in the folder **System**.
 - You cannot delete the file, but only overwrite it.
 - When you format the flash disk, this file remains untouched.
-

File structure

The configuration file is a text file the entries of which are grouped into several sections. The controller replaces missing IP configuration parameters by their default values.

Example: *config.ini*

This is an example of a configuration file **config.ini**:

```
;JC-970MC System Configuration
;Copyright (c) 2009 by Jetter AG, Ludwigsburg, Germany

[IP]
Address      = 192.168.50.1
SubnetMask   = 255.255.255.0
DefGateway   = 192.168.50.11
DNSServer    = 192.168.1.44

[HOSTNAME]
SuffixType   = 0
Name         = JetControl970MC

[PORTS]
JetIPBase    = 50000
JVMDebug     = 52000

[FILES]
AutoCopyIni  = /USB1/autocopy.ini
```

Section [IP]

In section [IP] the required IP addresses and the subnet mask are specified.

Address	
In the given example	192.168.50.1
Description	IP address of the controller
Valid values	<ul style="list-style-type: none"> ▪ > 1.0.0.0 ▪ < 223.255.255.255
Illegal values	<ul style="list-style-type: none"> ▪ Network address ▪ Broadcast address
In the event of an illegal value	The controller resets all four values to their fallback values.
SubnetMask	
In the given example	255.255.255.0
Description	Specifies the subnet mask
Valid values	<ul style="list-style-type: none"> ▪ >= 128.0.0.0
Illegal values	<ul style="list-style-type: none"> ▪ 1 and 0 mixed
In the event of an illegal value	The controller resets all four values to their fallback values.
DefGateWay	
In the given example	192.168.50.11
Description	IP address of the gateway to other subnets; The controller must be able to reach the subnet (Address/SubnetMask), otherwise it will set this parameter to 0.0.0.0.
Valid values	<ul style="list-style-type: none"> ▪ >= 0.0.0.0 and ▪ < 223.255.255.255
Illegal values	<ul style="list-style-type: none"> ▪ Network address ▪ Broadcast address ▪ A value (Address/SubnetMask) which cannot be reached by the controller. ▪ <i>Address</i> value
In the event of an illegal value	The controller sets the value to 0.0.0.0
DNSServer	
In the given example	192.168.1.44
Description	IP address of the server for the Domain Name System
Valid values	<ul style="list-style-type: none"> ▪ >= 0.0.0.0 and ▪ < 223.255.255.255
In the event of an illegal value	The controller sets the value to 0.0.0.0

3 Mechanical and electrical installation

Section [HOSTNAME]

In section [HOSTNAME] the name of the controller is specified. If desired, the controller automatically generates an individual name. The JC-970MC presently does not use the host name.

SuffixType

In the given example	0
Description	The type of the automatically generated suffix that is attached to the controller name
Valid values	<ul style="list-style-type: none">▪ 0: No attachment▪ 1: Low-order byte of the IP address in decimal notation▪ 2: Low-order byte of the IP address in hexadecimal notation
In the event of an illegal value	0

Name

In the given example	JetControl970MC
Description	Specifies the controller name
Valid values	<ul style="list-style-type: none">▪ First character: 'A' ... 'Z', 'a' ... 'z'▪ Next characters: 'A' ... 'Z', 'a' ... 'z', '0' ... '9', '-'
In the event of an illegal value	JetControl970MC

Section [PORTS]

In section [PORTS] the IP port numbers of data and debug servers within the controller are specified. The IP port numbers must be consistent with, for example, the port numbers set in JetSym.

JetIPBase

In the given example	50000
Description	IP port number for OS updates and communication between controllers
Valid values	<ul style="list-style-type: none">▪ 1024 ... 65535
In the event of an illegal value	50000

JVMDebug

In the given example	52000
Description	IP port number for Debugger/Setup in JetSym
Valid values	<ul style="list-style-type: none">▪ 1024 ... 65535
In the event of an illegal value	52000

Changing the IP configuration

Step	Action
1	Create on your PC a configuration file named config.ini using a text editor and make the corresponding entries.
2	Open an FTP connection between the PC and the JC-970MC.
3	Log in as user with administrator or system rights. Default login information: User: <i>admin</i> ; Password: <i>admin</i>
4	Browse to directory <i>/System</i> JC-970MC.
5	Copy the configuration file config.ini , which has been created by you, to the controller.
6	Clear the FTP connection.
7	Reboot the controller. Result: If the data in the configuration memory is invalid, the configuration data of config.ini is used.

Related topics

- **Configuration memory** (see page 67)
 - **Configuration registers** (see page 72)
-

Configuration registers

Introduction

Configuration registers let you read out IP configuration parameters or make changes to them. A register area contains the data from the file **\System\config.ini**. Another range contains the parameters used for initializing the IP interface.

Register numbers

The basic register numbers of both ranges are dependent on the device. The register number is calculated by adding the number of the module register (MR) to the number of the basic register.

Controller	Data range	Basic register number	Register numbers
JC-970MC	config.ini	101100	101100 ... 101165
	Parameters used	101200	101200 ... 101265

Configuration registers

The following table lists the registers of both ranges, as well as their connection to the entries in the configuration file **\System\config.ini**:

Register	Section in config.ini	Name in config.ini	Description
MR 0	IP	Address	IP address of the controller
MR 1		SubnetMask	Specifies the subnet mask
MR 2		DefGateWay	IP address of gateway to other subnets
MR 3		DNSServer	IP address of the server for the Domain Name System
MR 32	HOSTNAME	SuffixType	The type of the automatically generated suffix that is attached to the controller name
MR 33 ... MR 51		Name	Specifies the controller name
MR 64	PORTS	JetIPBase	IP port number for OS updates and communication between controllers
MR 65		JVMDebug	IP port number for Debugger/Setup in JetSym



Notice!

If you make manual changes to data in the configuration registers, also change the entries in **config.ini** to ensure that the configuration data matches

Related topics

- **Configuration memory** (see page 67)
- **Configuration file *config.ini*** (see page 68)

Changing the IP address of the controller

Introduction

To be able to communicate with the controller (RTOS side) JC-970MC via Ethernet (X102), you must assign an unambiguous IP address to the controller.

Configuration options

There are several options to configure the IP address of the port ETH (X102):

- In the **config.ini** file
 - During runtime via special registers (volatile)
 - Via special registers (non-volatile)
 - ia the program JetIPScan (non-volatile)
-

Related topics

- **Setting the IP address by means of file *config.ini*** (see page 68)
 - **Setting the IP address during runtime** (see page 80)
-

Making changes to the IP address of the JC-970MC using JetIPScan

Introduction

The program JetIPScan lets you make changes to IP address, subnet mask and the IP address of the Default Gateway of the JC-970MC. Yet, this only applies to the Ethernet port ETH (X102).

Downloading JetIPScan

You can download JetIPScan from the Jetter AG **homepage** at <http://www.jetter.de>. The location of **jetipscan_1-08-01.zip** is [Down-loads/Software/Classics/Additional software/jetipscan](#).

Contents of the jetipscan_1-08-01.zip


The zip file **jetipscan_1-08-01.zip** contains the following files:

- The program **JetIPScanV1.08_01.exe**
- The help **jetipscan_01_help_en.png**
- A batch file **read_IP_via_JETIPSCAN.bat** to determine the IP address
- A batch file **write_IP_via_JETIPSCAN_10_150.bat** to set IP address 192.168.10.150 for the controller

The batch files launch the program JetIPScan.

The files are unzipped to the folder **jetipscan_1-08-01**.

Possible commands of the software JetIPScan



```
Administrator: Eingabeaufforderung - M:\Schnittstellen\JetIPScan\JetIPScan_1_08_01\JetIPScanV1...
Microsoft Windows [Version 6.1.7600]
Copyright (c) 2009 Microsoft Corporation. Alle Rechte vorbehalten.

C:\>M:\Schnittstellen\JetIPScan\JetIPScan_1_08_01\JetIPScanV1.08_01.exe /?
JetIPScan Version 1.08
Illegal parameter!!!
Please type option

-T and the value in terms of seconds <Default value is 5 seconds> to change the
Timeout value.

-R to read the values from each controllers. Additionally you can type

  -F and file name to save the response to a file.

  -T and the value in terms of seconds <Default value is 5 seconds> to cha
nge the Timeout value

-W to set IP-address, Mask or Gateway values and after that type

  -I to set the IP address or
  -M to set the Mask or
  -G to set the Gateway

  -F and file name to save the response to a file.


  -T and the value in terms of seconds <Default value is 5 seconds> to cha
nge the Timeout value
Drücken Sie eine beliebige Taste . . . _
```

Prerequisite

First, an Ethernet connection between the PC and the controller JC-970MC must be established.

Making changes to the IP address

To make changes to the IP address of the JC-970MC, proceed as follows:

Step	Action
1	Write a batch file. The content of the batch file is JetIPScanV1.08_01.exe -W -I 192.168.10.150 .
2	Execute the batch file.
⇒	Result: JetIPScan is launched and shows all IP addresses, which are presently active on your PC.
3	Select the interface (IP address) connected with the controller JC-970MC, of which you want to retrieve the IP address.
	
4	JetIPScan shows all the devices found. To make changes to the IP address of a device, select the respective device from the list.
⇒	Result: JetIPScan changes the IP address of the JC-970MC to the value 192.168.10.150.

Changing the subnet mask

To make changes to the subnet mask of the JC-970MC, proceed as follows:

Step	Action
1	Write a batch file. The content of the batch file is, for example JetIP-ScanV1.08_01.exe -W -M 250.255.248.0 .
2	Execute the batch file.
⇒	Result: JetIPScan is launched and shows all interfaces, which are presently active on your PC.
3	For all further steps, please refer to the instruction Changing the IP address .

Changing the Default Gateway

To make changes to the Default Gateway settings of the JC-970MC, proceed as follows:

Step	Action
1	Write a batch file. The content of the batch file is, for example, JetIP-ScanV1.08_01.exe -W -G 192.168.4.1 .
2	Execute the batch file.
⇒	Result: JetIPScan is launched and shows all interfaces, which are presently active on your PC.
3	For all further steps, please refer to the instruction Changing the IP address .

Setting the IP address via "config.ini" file

Configuration file *config.ini*

You can set the IP address of the JC-970MC in the **config.ini** file.

```
[IP]
Address    = aaa.bbb.ccc.ddd
...
```

Element	Description
Address	Enter the IP-address into this line.
aaa	First byte of IP address
bbb	Second byte of IP address
ccc	Third byte of IP address
ddd	Fourth byte of IP address

NOTICE

If the data in the configuration memory are not o.k., the controller uses the IP address settings from the configuration file **config.ini**. Yet, this only applies to the Ethernet port ETH (X102).

Transferring the configuration file

Step	Action
1	Establish an FTP connection to the JC-970MC.
2	Log in as user with administrator or system rights. Default login information: User: <i>admin</i> ; Password: <i>admin</i> User: <i>system</i> ; Password: <i>system</i>
3	Open the folder System .
4	Copy the file config.ini to the folder System .
5	Clear the FTP connection.
6	Reboot the JC-970MC.

Setting the IP address via non-volatile registers

Introduction

The IP interface ETH (X102) is initialized by the settings in the configuration memory during the boot process.

The following non-volatile settings can also be changed via registers:

- IP address of the controller
 - Subnet mask
 - IP address of default gateway
 - Static route of the IP address
 - Static route of the subnet mask
 - Static route of the gateway
 - IP address of DNS server
 - Host name and suffix type
 - Port numbers for JetIP and JetSym debugger
-

Registers - Overview

Register	Description
101200	ETH (X102): IP address
101201	ETH (X102): Subnet mask
101202	ETH (X102): IP address of default gateway
101203	IP address of DNS server
101216	ETH (X102): Static route of the IP address
101217	ETH (X102): Static route of the subnet mask
101218	ETH (X102): Static route of the gateway
101232	Host name suffix type
101233 through 101251	Host name

3 Mechanical and electrical installation

Register	Description
101264	Port number for JetIP
101265	Port number for STX debugger
101299	Saving the settings (0x77566152)

Setting IP addresses and subnet mask

For changing of the IP addresses, the subnet mask, and the Default Gateway of the Ethernet port ETH (X102) via non-volatile registers, proceed as follows:

Step	Action
1	Enter the IP address of Ethernet port ETH (X102) into register 101200.
2	Enter the subnet mask into register 101201.
3	Enter the IP address of the default gateway into register 101202.
4	To have the controller apply the values, you must enter a password. Enter value 2002149714 (0x77566152) into register 101299.
5	Boot the controller JC-970MC.

Result:

The settings are completed. Communication is possible again.

Related topics

- **Configuration memory** (see page 67)
 - **Setting the IP address during runtime** (see page 80)
 - **Setting up a static route** (see page 83)
-

Setting the IP address automatically via USB flash drive

Introduction

To have the IP configuration of the controller automatically set by a USB flash drive, you can apply the function *Copying controller data automatically (Auto-Copy)*. For this, use the registers described in the chapter *Setting the IP address by non-volatile registers*.

Prerequisites

You must be familiar with the AutoCopy function (see chapter 7).

AutoCopy command file

The example below shows a command file of the AutoCopy function:

```
[OPTIONS]
CommandCount = 1
LogFile = /USB1/autocopy.log
LogAppend = 0

# set registers for IP configuration
[COMMAND_1]
Command = DaFileRead
DaFile = /USB1/ip-setup.da
```

Data file *ip-setup.da*

This example shows a data file, by which the IP address, the subnet mask and the port number for the JetIP protocol are set in the configuration memory:

```
SD101
; Data File - Jetter AG
;
; Register 101200 ip address
RS 101200 -1062729066
; Register 101201; subnet mask
RS 101201 -512
; Register 101264 JetIP port number
RS 101264 51000
; Register 101299 write to configuration memory
RS 101299 2002149714
```

Note:

The register contents (e.g. IP address 192.168.10.150, subnet mask, etc.) are specified here as signed integer values (32 bits).

In the JetSym Setup window, you can have the IP address displayed in various notations (signed integer, hexadecimal, binary, ...).

Related topics

- **Configuration memory** (see page 67)
- **Automatic copying of controller data** (see page 179)

Setting the IP address during runtime

Introduction

The IP interface is initialized by the settings in the configuration memory during the boot process.

The following non-volatile settings can also be changed via registers:

- IP address of the controller
- Subnet mask
- IP address of default gateway

Important note

The settings made during runtime do not overwrite the parameters in the configuration memory. At de-energizing the controller, your settings will be lost.

Prerequisites

- No communication may take place via the IP interface during setting. Otherwise, this would lead to a loss of data.
- The values entered must be valid. This can be ensured, e.g. by including a validity check in the application program.
This is important because there is no check if you set the parameters during runtime of the controller.

Registers - Overview

Register	Description
104531	ETH (X102): IP address
104532	ETH (X102): Subnet mask
104533	ETH (X102): IP address of default gateway

Setting IP addresses and subnet mask

To make changes to the IP addresses and the subnet mask of Ethernet port ETH (X102), proceed as follows:

Step	Action
1	Enter the value 0.0.0.0 into R 104533.
2	Enter the value 0.0.0.0 into R 104532.
3	Enter IP address of Ethernet port ETH (X102) into register 104531.
4	Enter the desired subnet mask into R 104532.
5	Enter the desired IP address of the default gateway into R 104533.

Related topics

- **Configuration memory** (see page 67)
- **Setting the IP address via non-volatile registers** (see page 77)
- **Setting up a static route** (see page 83)

E-mail feature - Using names for IP addresses

Introduction

In configuring the e-mail client, you can use names as IP addresses for target systems. The controller resolves the names into IP addresses. A configuration file or the Domain Name System is used to resolve a name into its corresponding IP address.

Name resolution

Names are resolved to IP addresses in the following way:

Step	Description	
1	During the boot process the controller reads the IP address of the DNS server out of the configuration memory.	
2	During the boot process the controller reads the file <code>/etc/hosts</code> . Then, the controller creates a translation table with the names and IP addresses found in this file.	
3	After the boot process the controller detects a name instead of an IP address.	
4	Based on this translation table, the controller tries to resolve the name into a related IP address.	
	If then ...
	... the controller could resolve the name, proceed with step 6.
... the controller could not resolve the name, proceed with step 5.	
5	The controller tries to resolve the name into a related IP address by sending a request to the DNS server.	
	If then ...
	... the controller could resolve the name, it enters the name and IP address into the translation table; --> proceed with step 6.
... the controller could not resolve the name, the controller aborts the function, e.g. the system function for sending an e-mail, and issues an error message.	
6	The controller uses the IP address resolved for further communication.	

Configuration file *hosts*

This file holds the static assignment between name and IP address. The controller reads this file once during boot-up.

File format: Text
 Location: /etc
 File name: hosts

3 Mechanical and electrical installation

Example

```
# Example host file for JC-9xx
192.168.33.209    jetter_mail
192.168.33.208    jetter_demo
192.168.1.1      JC970MC
192.168.1.2      JC970MC
```

Domain Name System (DNS)

If a name cannot be found in the file **/etc/hosts**, the controller tries to resolve the IP address by obtaining the corresponding IP address from a DNS server. During boot-up, the controller reads the IP address of the DNS server out of the configuration memory.

Related topics

- **Configuration memory** (see page 67)
-

Setting a static route

Introduction

The operating system of the JC-970MC offers the possibility to configure simple routing of IP packets for Ethernet port ETH (X102). If networks have to be accessed which are not in the directly accessible range of the JC-970MC, the user must set up static routes to these networks. Static routes especially have to be established, if the default gateway cannot reach the destination network.

Saving a route to a configuration memory

For Ethernet port ETH (X102), entries can be made in the configuration memory. Non-volatile registers 101216 through 101218 let you make permanent changes to these entries. All entries saved to the configuration memory are activated when the controller is rebooted.

Saving a route at runtime

Another register set (R 104550 through 104555) lets you - during runtime - make further entries into the routing table or delete existing routes. This register set can hold up to five entries.

R 104550

Status

This register lets you read out the status when adding or deleting routes during runtime.

Register properties

Reading values	0	No error
	-1	Routing table is full
	-2	Entry not found
	-3	Port is not active
	-4	TCP/IP stack not initialized

R 104551

Command

This command lets you add or delete a route.

Register properties

Writing values	1	Add route
	2	Delete route

R 104552

Port number

This register lets you define the Ethernet port.

Register properties

Writing values	1	ETH 1 (X102)
----------------	---	--------------

R 104553

IP address of the static route

Enter the IP address of the route into this register.

Register properties

Writing values 0.0.0.0 ... 255.255.255.255

R 104554

Subnet mask of the static route

Enter the number of the subnet mask of the route into this register.

Register properties

Writing values 0.0.0.0 ... 255.255.255.255

R 104555

Gateway of the static route

Enter the Gateway IP address of the route into this register.

Register properties

Writing values 0.0.0.0 ... 255.255.255.255

Setting a static route


To either add the route to the routing table or delete it from there during runtime, proceed as follows:

Step	Action
1	Enter the port number into register 104552.
2	Enter the IP address into register 104553.
3	Enter the subnet mask into register 104554.
4	Enter the IP address of the gateway into register 104555.
5	Enter the command into register 104551.

Result: If register 104550 has got value 0, the command has been executed successfully. The route settings are active.

Example

The JC-940MC is connected with your in-house network, for example, via its Ethernet port X102 and a router.



The JC-940MC transmits frames to addresses within the subnets 192.168.20.xxx and 192.168.21.xxx.
The route set in the JC-940MC connects these with your in-house network via router.

Related topics

- **Setting the IP address using non-volatile registers** (see page 77)
- **Setting the IP address at runtime** (see page 80)

4 Initial commissioning

Purpose of this chapter The first part of this chapter provides a compact description on how to commission the JC-970MC and covers the following functions:

- Creation and execution of a program which increments a variable.

The second part of this chapter covers the initial commissioning of the bus node JX3-BN-ETH involving the following steps:

- Configuring the hardware of a JX3 station and installing it
- Configuring the software in JetSym
- Creating and executing a program to read out a module register of a peripheral module connected to the JX3-BN-ETH.
- Addressing the bus node JX3-BN-ETH
- Describing the Jetter Ethernet system bus by the following means:
 - Hardware Manager
 - Publisher/Subscriber mechanisms

Prerequisites Before the controller JC-970MC can be put into operation for the first time, the following requirements must be met:

- The controller must be connected to a PC directly via Ethernet or via switch or a hub.
- The programming software JetSym 5.1.3 or higher must be installed on the PC.
- Mode selector S11 must be in *STOP* position.
- The controller must be connected with the JX3-BN-ETH bus node.

Content

Topic	Page
Preparations for initial commissioning of the controller	88
Initial commissioning of a JC-970MC	89

Preparations for initial commissioning of the controller

Energizing the controller

Various diagnostic and self-test routines run when the controller is energized. The Windows part of the IPC performs its integrated Power-On Self Test (POST). In addition, the standard diagnostic options of Windows are also available, such as memory and CPU utilization. The controller section performs the following two tests:

- File system check of the internal USB flash drive (error register 200008, bit 0: Flash disk error)
- Check if the remanent registers were saved correctly at the last shutdown (error register 200008, bit 4: Error: Remanent registers)

To energize and boot the controller, proceed as follows:

Step	Action
1	Set the mode selector S11 to STOP position. This prevents the application program from being loaded.
2	Connect the 24 V DC supply voltage to terminal X101.
⇒	Result: The controller and the integrated industrial PC are booting up.
	The green LED GP1 (RUN) is flashing at a frequency of 1 Hz.
3	Configure the controller as described below.

If you want to start the controller in normal operation, set switch S11 to **RUN**. With this setting, the application program is loaded and executed.

Ethernet connection with the controller

The default IP address (factory setting) of the JC-970MC is 192.168.1.1. This lets you, for example, access the controller from an external programming PC via Ethernet port X102. Configure the Ethernet interface of your PC so that it is able to communicate with the controller via this IP address.

Internal IP address of the controller




You can also access the controller internally from the Windows section of the JC-970MC. For this purpose, the IP address of the controller is 192.168.2.3.

Behavior after power-up

If the mode selector is in position *STOP* when the controller is powered-up, the application program will not be launched.

LEDs


If commissioning has completed without errors, the LEDs GP are lit as follows:

LED	Indication	Description
GP1 (RUN)	 1Hz	Logic voltage supply is OK; application program has been stopped.
GP2 (D1)	 OFF	No error
GP3 (ERR)	 OFF	No error

Initial commissioning of a JC-970MC

Configuration

The initial commissioning is based on the following configuration:



Number	Part	Description
1	PC	Programming system
2	JC-970MC	Controller

Creating a program

To create and check the program, proceed as follows:

Step	Action
1	Launch the programming tool JetSym.
2	Create a new project.
3	Set the controller model (JC-970MC).
4	Set the IP address of the controller.
5	Open the program editor.
6	Enter the program specifications.
7	Upload the project to the controller.
8	Open a setup pane.
9	Enter the variable name (Count).
10	Activate the setup.

4 Initial commissioning

Software versions

The sample program requires the software versions listed below:

- JetSym: Version 5.1.3 or higher
- Controller JC-970MC: OS version 1.07 or higher

You can also find the latest sample programs in the JetSym online help.

JetSym STX program


The following program increments the content of a variable by one every 2 seconds:

```
Var
    Count:    Int;
End_Var;

Task Increment Autorun
    Loop
        Inc(Count);
        Delay(T#2s);
    End_Loop;
End_Task;
```

Setup pane

The JetSym setup pane shows the content of the variable:



	Name	Number	Content	Type
4	ProgramStartCounter	1000000	4	
5				
6				

Number	Description	Function
1	Present content of the variable	The content of the variable is incremented by one every 2 seconds.

5 Retrieving information on the controller

Purpose of this chapter This chapter describes how to retrieve the following information on the controller JC-970MC:

- Hardware revision
- Electronic Data Sheet (EDS) information. Numerous production-relevant data are stored in the EDS.
- OS version of the controller and its software components

Prerequisites To be able to identify the JC-970MC, the following prerequisites must be fulfilled:

- The controller must be connected to a PC.
- The programming tool JetSym 4.2 or higher must be installed on the PC.

Information for hotline requests If you wish to contact the hotline of Jetter AG in case of a problem, please have the following information on the JC-970MC ready:

- Serial number
- OS version number of the controller
- Hardware revision

Content

Topic	Page
Identification by means of the nameplate	92
Electronic Data Sheet EDS	93
Version registers	97

5.1 Identification by means of the nameplate


Introduction

The nameplate is attached to the housing of the JC-970MC and contains details, such as hardware revision number and serial number. If you wish to contact the hotline of Jetter AG in case of a problem, please have this information ready.

Nameplate

Nameplate

The nameplate attached to the right side of the JC-970MC contains the following information:



Number	Description
1	Hardware revision
2	Serial number
3	Controller name
4	Item number

5.2 Electronic Data Sheet EDS

Introduction

Each JC-970MC features an Electronic Data Sheet (EDS). Numerous production-relevant data are permanently stored in the EDS. Files in the file system of the JC-970MC or special registers let you retrieve EDS data.

EDS File "eds.ini"

Introduction


EDS data can be retrieved from the file **eds.ini**.

Properties

- You can access this file through the file system of the controller.
- For an FTP connection, the user needs administrator rights (user *admin*) or system rights (user *system*).
- The EDS file of the controller is located in the folder */System*.
- This file is read-only.
- The EDS file will even survive formatting of the disk drive.

Path to EDS files

The illustration below shows an example of the folder */System* holding the EDS files of the controller:



File structure

The EDS file is a text file the entries of which are grouped into several sections.

Example - Controller

Below is an example of an EDS file belonging to a JetControl 970MC:

5 Retrieving information on the controller

```
;Jetter AG Electronic Data Sheet
```

```
[IDENTIFICATION]
```

```
Version = 0  
Code = 2464  
Name = JC-970MC  
PcbRev = 02  
PcbOpt = 00
```

```
[PRODUCTION]
```

```
Version = 0  
SerNum = 10080703010015  
Day = 14  
Month = 08  
Year = 2016  
TestNum = 1  
TestRev = 01.10.03.50
```

```
[FEATURES]
```

```
Version = 0  
Axes = 64  
NumberOfPCISlots = 02  
STX = 1  
NVRegs = 120000
```

Section [IDENTIFICATION]

General hardware configuration can be seen from section [IDENTIFICATION].

Name	Example	Description
Version	0	Version of this section
Code	2464	Module code of JC-970MC
Name	JC-970MC	Corresponds to the information on the name-plate
PcbRev	02	Hardware revision
PcbOpt	00	Hardware option

Section [PRODUCTION]

Serial number and production date can be seen from section [PRODUCTION].

Name	Example	Description
Version	0	Version of this section
SerNum	20160814210003	Corresponds to the information on the name-plate
Day	14	Production date: Day
Month	08	Production date: Month
Year	2016	Production date: Year
TestNum	1	Internal usage
TestRev	01.10.03.50	Internal usage

Section [FEATURES]

Special properties of the controller can be seen in section [FEATURES]. The OS of the controller will ignore properties of missing entries in the file.

Name	Example	Description
Version	0	Version of this section
Axes	64	Number of MC-axes
Number-ofPCIslots	02	Number of PCIe slots
STX	1	Runtime environment for the application program is available
NVRegs	120000	Number of non-volatile application registers

EDS registers

Introduction

EDS registers let you retrieve entries from the Electronic Data Sheet (EDS).

Register numbers

The basic register number is dependent on the controller. The register number is calculated by adding the number of the module register (MR) to the number of the basic register.

Controller	Basic register number	Register numbers
JC-970MC	100000	100600 ... 100817

EDS registers of a controller

The following table lists the EDS registers of a controller, as well as their connection to the entries in the EDS file `/System/eds.ini`.

Register	Section in eds.ini	Name in eds.ini	Description
MR 600	IDENTIFICATION	Version	Version of this section
MR 601		Code	Module code
MR 602 ... MR 612		Name	Module name or controller name
MR 613		PcbRev	Hardware revision
MR 614		PcbOpt	Hardware option
MR 700	PRODUCTION	Version	Version of this section
MR 701 ... MR 707		SerNum	Serial number
MR 708		Day	Production date: Day
MR 709		Month	Production date: Month
MR 710		Year	Production date: Year
MR 711		TestNum	Internal usage
MR 712		TestRev	Internal usage
MR 800	FEATURES	Version	Version of this section
MR 804		Switch	Mode selector
MR 805		STX	Runtime environment for the application program
MR 806		NVRegs	Number of non-volatile registers
MR 810		Motion-Control	MC software
MR 811		Axes	Number of MC-axes
MR 812		Web	Web server and e-mail client
MR 813		ModbusTCP	Modbus/TCP client and server
MR 817		RTC	Real-time clock

5.3 Version registers

Introduction

The operating system provides several registers which can be used to read out revision numbers of the hardware or OS and its components. If you wish to contact the hotline of Jetter AG in case of a problem, please have this information ready.

Hardware revisions

Introduction

The controller JC-970MC features special registers, the content of which lets you identify the hardware.

Registers - Overview

The registers listed below let you retrieve the hardware revisions:

Register	Description
200170	Controller type

Version numbers in JetSym setup

The following screenshot shows a JetSym setup pane displaying the version registers:

	Name	Number	Content	Type	Comment
1					
2	JCtype	200170	970		
3					
4					

Software versions

Introduction

The JC-970MC features software with unique version numbers which can be read out from special registers.

Format of software version numbers

The software version numbers of the JC-970MC are four-figure values.

1	.	2	.	3	.	4
---	---	---	---	---	---	---

Element	Description
1	Major or main version number
2	Minor or secondary version number
3	Branch or intermediate version number
4	Build version number

Released version

A released version can be recognized by both Branch and Build having got value 0.

5 Retrieving information on the controller

Registers - Overview

The registers listed below let you read out the software versions:

Register	Description
200169	Operating system version
210001	Version of the runtime unit for the STX application program

Version numbers in JetSym setup

The following screenshot shows a JetSym setup pane displaying version registers. To have the version number displayed in the setup pane of JetSym, select the format **IP address**.

	Name	Number	Content	Type	Comment
1					
2	OS	200169	1.5.0.0		
3	STX	210001	1.5.0.54		
4					

Number	Description	Function
1	V. 1.05.0.00	OS version number of the controller JetSym displays this information in the title bar of each setup pane.

6 Programming

Introduction JetControl 970MC is an embedded control system with a real-time multitasking operating system. The user can freely distribute the control program to up to 100 tasks which are processed by the controller virtually parallel to each other. The programming language used is JetSym-STX which is based on IEC-61131-3 (ST). Although JetSym STX does not fully comply with IEC-61131-3 (ST), its scope of functions goes beyond this standard.

- Purpose of this chapter** This chapter supports you in programming the following functions:
- Determining the register numbers of connected modules
 - Determining the I/O numbers of connected modules
 - Programming additional functions
 - exchange data via various system buses
 - exchange data via user-programmable interfaces

- Prerequisites** To program the controller JC-970MC, the following requirements must be met:
- The controller must be connected to a PC.
 - The JetSym programming software must be installed on the PC.

Content

Topic	Page
Abbreviations, module register properties and formats.....	100
System run times, response times, remote peripheral devices.....	101
Memory types - Overview.....	102
Numbering registers and I/Os.....	111
Jetter Ethernet system bus.....	123
Real-time clock (RTC)	123
System runtime.....	123
Monitoring interface activities	124
Programming local JX6-I/O submodules.....	124
E-mails.....	143
Sorting data	167
Modbus/TCP.....	168
User-programmable IP interface	178

Abbreviations, module register properties and formats

Abbreviations

The following abbreviations are used in this manual:

Abbreviation	Description
R 100	Register 100
MR 150	Module register 150

Module register properties

Each module register is characterized by certain properties. For many module registers most properties are identical. For example, their value after reset is zero. In the following description, module register properties are mentioned only if a property deviates from the default properties listed below.

Module register property	Default property for most module registers
Type of access	Read/write
Value after reset	0 or undefined (e.g. revision/version number)
Takes effect	Immediately
Write access	Always
Data type	Integer

Numerical formats

The numerical formats used in this document are listed in the table below:

Notation	Numerical format
100	Decimal
0x100	Hexadecimal
0b100	Binary

JetSym sample programs

The notation for sample programs used in this document is listed in the table below:

Notation	Purpose
<code>Var, When, Task</code>	Keyword
<code>BitClear();</code>	Commands
<code>100 0x100 0b100</code>	Constant numerical values
<code>// This is a comment</code>	Comment
<code>// ...</code>	Further program processing

System run times, response times, remote peripheral devices

System run times

For more information on system run times refer to our application-oriented manual "System Registers" which is available for download from our homepage.

Response times

You can read out program response times from registers 210007 (minimum program cycle time), 210008 (maximum program cycle time), and 210009 (current program cycle time).

Peripherals not directly installed

For peripheral devices not installed directly in the controller, such as JX3 modules on a JX3-BN-ETH, you can define how they must behave in the event of communication loss. For more information refer to the application-oriented manual "Jetter Ethernet System Bus" and the online help which comes with JetSym.

If a communication error occurs with a connected JetMove servo amplifier, it is detected by the Motion Control or the STX program via timeout.

Self-test and configuration check

Existing tests

The programming language JetSym STX offers numerous possibilities to check the configuration and test the system, e.g. memory test, memory protection, illegal op code, division by 0, consistency of axis and IO configuration on the Ethernet system bus (NetConsistency), Try..Catch, etc. For more information on these topics refer to the JetSym online help.

6.1 Memory types - Overview

Introduction

The JC-970MC features several types of program and data memories. There is, for example, volatile and non-volatile memory. Volatile memory loses its content at switching off. Non-volatile memory keeps its content even when the power supply is off.

The memory is located directly in the CPU or in separate memory or I/O modules.

This chapter gives an overview of the available memory.

Content

Topic	Page
Operating system memory.....	103
File system memory.....	103
Application program memory.....	104
Memory for volatile application program variables	104
Memory for non-volatile application program registers.....	105
Memory for non-volatile application program variables	106
Registers on I/O modules	107
Special registers	107
Inputs and outputs	108
Flags	110

Operating system memory

Introduction	The OS is stored to a non-volatile flash memory in the CPU. Therefore, the OS can be executed immediately after the device is powered up.
Properties	<ul style="list-style-type: none">▪ Internal flash memory for storing OS data▪ Internal volatile RAM for storing OS data
Memory access	<ul style="list-style-type: none">▪ The user is not allowed to directly access the OS memory.▪ Changes to the OS can only be made by means of an OS update.
Related topics	<ul style="list-style-type: none">▪ Updating the operating system of the controller (see page 186)

File system memory

Introduction	The file system memory is for storing data and program files.
Properties	<ul style="list-style-type: none">▪ Internal flash disk▪ Non-volatile▪ Slow access: Milliseconds up to seconds▪ Limited number of write/erase cycles: approx. 1 million▪ Size of internal flash disk: 32 MB
Memory access	<ul style="list-style-type: none">▪ By controller OS (RTOS)▪ By JetSym▪ Via FTP connection▪ By the e-mail client▪ By browser (via HTTP server)▪ By means of file commands from within the application program

Application program memory

Introduction

By default, the application program is uploaded by JetSym to the controller as a compiled file with the extension .es9 where it is stored in a mass memory (flash). If the "Autorun" option is activated in the JetSym Hardware Manager, the program is loaded into the main memory (SDRAM) after the download and then executed.

Properties


- Stored as file within the file system
- Default directory `/app`
- Files may also be stored to other directories
- Size is limited by flash memory

Memory access

- By controller OS (RTOS)
- By JetSym
- Via FTP connection
- By means of file commands from within the application program

Memory usage

- After program start, the programming tool JetSym lets you determine the memory utilization by the application program in the SDRAM. Further information can be found in the JetSym online help under the search term "Memory usage".



Memory for volatile application program variables

Introduction

Volatile variables are used to store data which may be discarded when the JC-970MC is de-energized.

Properties

- They are global variables which are not assigned to permanent addresses (not %VL or %RL)
- Local variables
- Variables are stored in a compact way.
- Variables are initialized with value 0 when they are created.

Memory access

- By JetSym
- From the application program

Memory for non-volatile application program variables

Introduction

Non-volatile registers let you store data (variables) which must be saved when the JC-970MC is de-energized. These variables can be declared as %RL or %VL.



Notice!

Data can get lost!

During runtime, the operating system copies the area of non-volatile application registers into the volatile SDRAM memory because data can there be processed faster by the STX program.

If the voltage supply to the device is disconnected, a PowerFail interrupt is thrown. This interrupt causes all register variables to be copied from volatile to non-volatile memory.

An internal power supply provides the energy required for this process. Pressing the PWR button will **not** cause the PowerFail interrupt to be thrown. Thus, all data stored in the SDRAM memory will be discarded. That's the reason why we recommend not to use the PWR button, but to interrupt the power supply instead.

Properties of %VL variables

- Global variables with dedicated addresses (%VL)
- Register variables always occupy 4 bytes.
- Register variables are not initialized by the operating system.
- Number of register variables: 120,000
- Register numbers: 1000000 ... 1119999

Memory access

- By JetSym
- By the e-mail client
- By browser (via HTTP server)
- From HMIs
- From the application program
- From other controllers

JetSym STX program

The following sample program increments the content of a register variable every time the application program is started. This way, the number of program starts is counted.

```

Var
  ProgramStartCounter:   Int At %VL 1000000;
End_Var;


Task Work Autorun
  ProgramStartCounter := ProgramStartCounter + 1;
  Loop
    // ...
  End_Loop;
End_Task;

```

6 Programming

Setup pane

The JetSym setup pane displays the content of the register variable.



	Name	Number	Content	Type
4	ProgramStartCounter	1000000	4	
5				
6				

Number	Description	Function
1	Present content of the register variable	The content of the register variable is incremented by one every time the program is started.

Properties of %RL variables

- Global variables which are assigned to dedicated registers (%RL)
- Variables are stored in a compact way
- Size: 480,000 bytes
- Register numbers: 1000000 ... 1119999

Memory access

- By JetSym
- From the application program

JetSym STX program

The following program increments the content of four non-volatile variables every second.


The working range of the counters is between 0 and 255 (variable type: byte). For these four variables the four bytes of register 1000010 are used.

```
Var
    Cnt1, Cnt2, Cnt3, Cnt4:    Byte At %RL 1000010;
End_Var;

Task Count4 Autorun
    Loop
        Inc(Cnt1);
        Inc(Cnt2, 2);
        Inc(Cnt3, 5);
        Inc(Cnt4, 10);
        Delay(T#1s);
    End_Loop;
End_Task;
```

Setup pane

The JetSym setup pane displays the content of the variable. As the type of the four counters is byte, this will result in counter overflow after a relatively short time:



	Name	Number	Content	Type
6	Cnt1	1000010	2	
7	Cnt2	1000010	4	
8	Cnt3	1000010	10	
9	Cnt4	1000010	20	

Number	Description	Function
1	Current content of the variable Cnt1	The content of the variable is incremented by one every second.
2	Current content of the variable Cnt2	The content of the variable is incremented by two every second.
3	Current content of the variable Cnt3	The content of the variable is incremented by five every second.
4	Current content of the variable Cnt4	The content of the variable is incremented by ten every second.

Special registers

Introduction

Special registers let you control OS functions and retrieve status information.

Properties

- Global variables with dedicated addresses (%VL)
- When the operating system is launched, special registers are initialized using their default values.
- Register numbers: 100000 ... 999999
- Network registers: 1nnnxxxxxx (nnn = GNN)

Memory access

- By JetSym
- By the e-mail client
- By browser (via HTTP server)
- From HMIs
- From the application program
- From other controllers

Inputs and outputs

Introduction

Inputs and outputs are 1-bit variables. This means they can have the value TRUE or FALSE. Inputs and outputs are addressed in immediate read/write cycles.

Properties of virtual inputs/outputs

- They are global variables assigned to permanent addresses (%IX, %QX)
- Used for RemoteScan via Modbus/TCP
- Quantity: 16,000
- I/O numbers: 20001 ... 36000

Properties of digital inputs/outputs

- They are global variables assigned to permanent addresses (%IX, %QX)
- Located on modules connected to the JX2 system bus
- I/O numbers on the JX2 system bus: 201100201 ... 201203216
- I/O numbers of remote devices connected to a JX3-BN-ETH: 1nnn010201 ... 1nnn011716 (nnn = GNN)

Memory access

- By JetSym
- By the e-mail client
- By browser (via HTTP server)
- From HMIs
- From the application program

JetSym STX program

In the following program, moving lights are triggered on a digital output module connected to the first JX2 system bus. If a digital input is set at the second JX2 system bus, the corresponding output is activated for 100 ms.

```

Var
    Lights:    Array[8] Of Bool At %QX 201100309;
    HighSpeed: Bool At %IX 201200601;
End_Var;

Task RunningLight Autorun
    Var
        Idx:    Int;
    End_Var;
    Loop
        For Idx := 0 To 7 Do
            Lights[Idx] := True;
            If HighSpeed Then
                Delay(T#100ms);
            Else
                Delay(T#300ms);
            End_If;
            Lights[Idx] := False;
        End_For;
    End_Loop;
End_Task;

```

Setup pane

The JetSym setup pane displays the state of inputs and outputs:

	Name	Number	Content	Type
21	[-] Lights	201100309	array[8]	
22	[-] Lights[0]	201100309	0	
23	[-] Lights[1]	201100310	0	
24	[-] Lights[2]	201100311	1	
25	[-] Lights[3]	201100312	0	
26	[-] Lights[4]	201100313	0	
27	[-] Lights[5]	201100314	0	
28	[-] Lights[6]	201100315	0	
29	[-] Lights[7]	201100316	0	
30	HighSpeed	201200601	1	

Number	Description	Function
1	Present state of outputs	The outputs are set and reset one after another.
2	Present state of the output	When the input is set, the corresponding output is activated for 100 ms.

Flags

Introduction

Flags are one-bit operands. This means they can have the value TRUE or FALSE.

Properties of user flags

- Non-volatile

- Global variables which are assigned to permanent addresses (%MX)
 - Quantity: 256
 - Flag numbers: 0 ... 255
-

Properties of overlaid user flags

- Overlaid by registers 1000000 ... 1000055

- Global variables which are assigned to permanent addresses (%MX)
 - Non-volatile
 - Quantity: 1,792
 - Flag numbers: 256 ... 2047
-

Properties of special flags

- Global variables which are assigned to permanent addresses (%MX)
 - When the operating system is launched, special flags are initialized using their default values.
 - Quantity: 256
 - Flag numbers: 2048 ... 2303
-

Memory access

- By JetSym
 - By the e-mail client
 - By browser (via HTTP server)
 - From HMIs
 - From the application program
-

6.2 Numbering registers and I/Os

Introduction Controllers and modules produced by Jetter AG offer a host of functions which can be accessed by the user via registers. A unique number is assigned to each register and each digital input or output.

Purpose of register numbers Register numbers are applied in the following cases:

- Read/write access to a module register in the JetSym Setup pane.
- Declaration of a module register in a JetSym application program.
- Declaration of a module register as tag in JetViewSoft.

Purpose of I/O numbers I/O numbers can be used in the following cases:

- Read access to a digital input in the JetSym Setup pane.
- Read/write access to a digital output in the JetSym Setup pane.
- Declaration of a digital input/output as variable in a JetSym application program.
- Declaration of a digital input/output as tag in JetViewSoft.

Content

Topic	Page
Registers and module registers	112
Slot numbering	114
Register and I/O numbers of local JX6-I/O submodules	115
Register numbers of JX2 slave modules on the JX2 system bus	116
Registers and I/O numbers of JX2- and JX3-I/O modules on the JX2 system bus	117
Register and I/O numbers of IP67-I/O modules on the JX2 system bus.....	118
Register and I/O numbers of CANopen [®] modules on the JX2 system bus.	118
Register and I/O numbers of JX3 modules connected to a JX3-BN-ETH..	121
Registers and I/O numbers of JX3 modules from the JX3-BN-ETH perspective	123

Registers and module registers

Module registers - Definition

Module registers let you read process, configuration and diagnostics data from the module, or write such data to it. The module register number within a module is unique.

Access options

There are several ways to access registers directly:

- In an application program
- In a JetSym setup pane
- In a visualization application

The register number within the system is unique.

Definition - Global Node Number

The Global Node Number (GNN) is an ID number to identify Jetter controllers (e.g. controllers, bus nodes) within an Ethernet network.


- The GNN within a network has to be unambiguous for each Jetter device.
- The JetSym Hardware Manager automatically assigns the GNN during configuration.
- The value range of the GNN within a project is 000 ... 199.
- The controller has always got GNN 000.

Example: Module register

Module register 9 lets you read out the OS revision of a JX2-IO16 module:

Example: Register numbers on the JX2 system bus

A JX2-IO16 module is connected as first module to the upper JX2 system bus module located in the PCIe slot 1 (riser card 1). On the JX2 system bus, the module number of this module is 2.




Number	Element	Description
1	Register number	Can be used to directly access the register
2	Register prefix	20120300: For the first JX2-I/O module connected to a JC-970MC.
3	Module register number	r = 9: OS version of the JX2-IO16

Register number 201203009 in the JetSym Setup pane shows OS version 2.01.

	Name	Number	Content	Type
1	201203009	201203009	201	
2				
3				

Example: Registers on the Ethernet system bus

A JX3-AI4 module is connected to a bus node JX3-BN-ETH. The module number of the JX3 module is 2. The bus node has got the ID (GNN) 001.




Number	Element	Description
1	Register number	Can be used to directly access the register
2	Bus node ID, GNN	001: ID of the first JX3-BN-ETH
3	Module number	02: The first JX3-I/O module connected to the JX3-BN-ETH
4	Register prefix	100102
5	Module register number	0009: OS version of the JX3-AI4

Register number 1001020009 in the JetSym Setup pane shows OS version 1.4.0.0 in direct representation.

	Name	Number	Content	Type
1	1001020009	100102000	1.4.0.0	
2				

Slot numbering

Configuration



Code	Description
S	Slot number of the riser card on the PCIe bus
J	Number of the JX6-I/O submodule located on the riser card

Numbering

The slot number breaks down as follows:

- The left riser card on the PCIe bus is assigned number 1.
- The right riser card on the PCIe bus is assigned number 2.
- The lower module on the riser card is assigned number 1.
- The upper module on the riser card is assigned number 2.

Register and I/O numbers of modules located on a riser card

Register numbers of modules located on the riser card

The register number of modules located on a riser card breaks down as follows:

2	0	S	J	0	0	z	z	z
---	---	---	---	---	---	---	---	---

Element	Purpose	Value range
S	Number of the riser card	1 ... 2
J	Number of the module located on the riser card	1 ... 2
zzz	Module register number	100 ... 999

I/O numbers of modules located on a riser card

The I/O number of modules located on a riser card breaks down as follows:

2	0	S	J	0	0	1	z	z
---	---	---	---	---	---	---	---	---

Element	Purpose	Value range
S	Number of the riser card	1 ... 2
J	Number of the module located on the riser card	1 ... 2
zz	Module-specific I/O number	01 ... 08

Register numbers of JX2 slave modules connected to the JX2 system bus

Slave module numbers of JX2 slave modules

To determine the slave module numbers of intelligent JX2 slave modules and JetMoves on the JX2 system bus of the JC-9xx, proceed as follows:

- Count the JX2 slave modules left-to-right, starting from 2.
- Do not count the power supply module JX2-PS1.
- Leave out non-intelligent JX2-I/O modules.

Register numbers for JX2 slave modules

Register numbers for JX2 slave modules on the JX2 system bus of the JC-9xx break down as follows:

2	0	S	J	x	x	z	z	z
---	---	---	---	---	---	---	---	---

Element	Purpose	Value range
S	Number of the riser card	1 ... 2
J	Number of the JX6-I/O module (JX2 system bus) located on the riser card	1 ... 2
xx	Slave module number + 10	12 ... 27
zzz	Module register number	000 ... 999

Register and I/O numbers of JX2- and JX3-I/O modules on the JX2 system bus

I/O module numbers of JX2- and JX3-I/O modules

To determine the I/O module numbers of JX2- or JX3-I/O modules on the JX2 system bus of the JC-9xx, proceed as follows:

- Count the JX2- and JX3-I/O modules left-to-right, starting from 2.
- Leave out the intelligent JX2 slave modules and JetMoves.
- Leave out the power supply module JX2-PS1.
- Count the JX3-BN-CAN modules left-to-right, starting from 33.



Notice!

When JX3-I/O modules are used, set the timeout value in module register 20SJ02764 of the JX6-SB(-I) module to 8.

If JX3-DI/DO/DIO modules are used, their process data registers (MR 2-5) must not be used. For read or write access to registers overlaid by inputs and outputs use the registers listed in Quick Reference.

Register numbers for JX2- and JX3-I/O modules

Register numbers for JX2- and JX3-I/O modules connected to the JX2 system bus of the JC-9xx consist of the following elements:

2	0	S	J	0	3	x	x	z
---	---	---	---	---	---	---	---	---

Element	Purpose	Value range
S	Number of the riser card	1 ... 2
J	Number of the JX6-I/O module (JX2 system bus) located on the riser card	1 ... 2
xx	JX2-I/O module number minus 2	00 ... 30
	Module number of the JX3-BN-CAN minus 2	31 ... 61
z	Module register number	0 ... 9

I/O numbers for JX2- and JX3-I/O modules


I/O numbers for JX2- and JX3-I/O modules connected to the JX2 system bus of the JC-9xx consist of the following elements:

2	0	S	J	0	x	x	z	z
---	---	---	---	---	---	---	---	---

Element	Purpose	Value range
S	Number of the riser card	1 ... 2
J	Number of the SB/SB-I module located on the riser card	1 ... 2
xx	Module-specific I/O number of the JX2/JX3 module	02 ... 32
zz	I/O number on the JX2/JX3 module	1 ... 16

Example

Several JX2- and JX3-I/O modules are connected to a JC-9xxMC.



Number	Module	I/O module number	Register	I/O
1	JC-9xxMC	1	Refer to documentation on JC-970MC.	
2	JX2-PS1	-	-	-
3	JX2-ID8	2	20120300z	2012002zz
4	JX2-SER1	3	20120301z	2012003zz
5	JX3-BN-CAN	33	20120331z	-
6	JX3-DIO16	4	20120302z	2012004zz

Register and I/O numbers of CANopen[®] modules on the JX2 system bus

I/O module numbers of CANopen[®] modules

To determine the I/O module numbers of CANopen[®] modules on the JX2 system bus of the JC-9xx, proceed as follows:

- Determine the node ID. In most cases, the I/O module numbers correspond to the node ID of the CANopen[®] module.
- Exceptions: SMC EX120 and Lenze frequency inverter

Register numbers for CANopen[®] modules

Register numbers for CANopen[®] modules connected to the JX2 system bus of the JC-9xx consist of the following elements:

2	0	S	J	0	x	x	z	z
---	---	---	---	---	---	---	---	---

Element	Purpose	Value range
S	Number of the riser card	1 ... 2
J	Number of the JX6-I/O module (JX2 system bus) located on the riser card	1 ... 2
xx	I/O module number	70 ... 79
zz	Module register number	00 ... 99

I/O numbers for CANopen[®] modules


I/O numbers for CANopen[®] modules connected to the JX2 system bus of a JC-9xx consist of the following elements:

2	0	S	J	0	x	x	z	z
---	---	---	---	---	---	---	---	---

Element	Purpose	Value range
S	Number of the riser card	1 ... 2
J	Number of the JX6-I/O module (JX2 system bus) located on the riser card	1 ... 2
xx	Module-specific I/O module number	70 ... 79
zz	Module-specific I/O number	1 ... 64

Example

A CANopen[®] module is connected to a JC-9xxMC.



Number	Module	I/O module number	Register	I/O
1	JC-9xxMC	1	Refer to documentation on JC-970MC.	
2	Festo CPX	2	2012070zz	2012070zz

Register and I/O numbers of JX3 modules connected to a JX3-BN-ETH

Global Node Number of a JX3-BN-ETH on the Jetter Ethernet system bus

JetSym Hardware Manager assigns a Global Node Number to the bus node JX3-BN-ETH on the Jetter Ethernet system bus.

Register numbers for JX3 modules

The register number for JX3 modules connected to an Ethernet bus node consists of the following elements:

1	n	n	n	x	x	z	z	z	z
---	---	---	---	---	---	---	---	---	---

Element	Purpose	Value range
nnn	Global Node Number of the JX3-BN-ETH on the Ethernet system bus	001 ... 199
xx	Module number of the module within the JX3 station	02 ... 17
zzzz	Module register number	0000 ... 9999

I/O numbers for JX3 modules


The I/O number for JX3 modules connected to an Ethernet bus node consists of the following elements:

1	n	n	n	0	1	x	x	z	z
---	---	---	---	---	---	---	---	---	---

Element	Purpose	Value range
nnn	Global Node Number of the JX3-BN-ETH on the Ethernet system bus	001 ... 199
xx	Module number of the module within the JX3 station	02 ... 17
zz	Module-specific I/O number	1 ... 16

Example

Two bus nodes JX3-BN-ETH are connected to a JC-940MC (as an example).



Number	Module	Module number	GNN	Register	I/O
1	JC-9xxMC	1	0	Refer to documentation on JC-970MC.	
2	JX3-BN-ETH	-	1	Refer to documentation on JX3-BN-ETH	
3	JX3-DIO16	2	-	100102zzzz	10010102zz
4	JX3-DIO16	3	-	100103zzzz	10010103zz
5	JX3-BN-ETH	-	2	Refer to documentation on JX3-BN-ETH	
6	JX3-DIO16	2	-	100202zzzz	10020102zz

Real-time clock

Introduction

The controller is equipped with a realtime clock. This clock continues to run for some time even when the controller is de-energized. Then, the realtime clock is supplied with power from a GoldCap capacitor. Thus, the realtime clock is maintenance-free because there is no backup battery which needs to be replaced.

The realtime clock supports the Network Time Protocol (NTP) which is for synchronizing the time with a server on the Internet.

Purpose

Purpose of the realtime clock:

- Specifying the file date and time when creating a log file with timestamp

Restrictions

When using the real-time clock, the following restrictions apply:

- When the device is de-energized the power reserve is limited.
- The realtime clock has no automatic daylight savings time function.
- The realtime clock can only be set from Windows (IPC).
- When the clock has been set, wait 60 seconds before shutting down the device. Otherwise, any changes will be discarded.
- From the RTOS side the realtime clock is read-only.

Technical specifications

Technical data - Realtime clock

Parameter	Description
Power reserve The controller must have been energized for at least 1 hour.	Minimum: 1 week Typically: 3 weeks
Deviation	1 minute per month max.

Factory settings

At the end of the controller manufacturing process, the real-time clock is set to the actual date and time.

6.3 Programming local JX6 submodules

Introduction

This chapter describes how to program local JX6 submodules on the PCIe bus of the JC-970MC.

Content

Topic	Page
Submodule JX6-SB(-I)	125
Digital JX6-I/O submodul JX6-IO16CB	127
Combi module JX6-SV1	132
Sample program for local JX6-I/O submodules	139

JX2- Systembus interface JX6-SB(- I)

Introduction

This chapter describes how to configure the JX2 system bus interface on the PCIe bus of the JC-970MC.

Submodule JX6-SB(-I)

The local submodules JX6-SB and JX6-SB-I take on converting the PCIe bus to the JX2 system bus. The operating mode is Master /Slave.

Register

The following registers let you configure the JX2 system bus:

- **Configuration and status registers of the JX6-SB(-I) submodule**

2	0	S	J	0	0	z	z	z
---	---	---	---	---	---	---	---	---

Element	Purpose	Value range
S	Number of the riser card	1 ... 2
J	Number of the JX6-I/O submodule located on the riser card	1 ... 2
zzz	Module register number	100 163

- **JX2 system bus registers**

2	0	S	J	0	2	z	z	z
---	---	---	---	---	---	---	---	---

Element	Purpose	Value range
S	Number of the riser card	1 ... 2
J	Number of the JX6-I/O submodule located on the riser card	1 ... 2
zzz	Module register number	000 999

Further literature

For more information on registers and engineering of the JX2 system bus, refer to the JX6-SB(-I) user information or application-oriented manual. These manuals are available for download on our homepage.

Enhancements

Since revision 2.11.2 of the JX6-SB user information the following enhancements have been made:

- The value range I/O module numbers on the JX2 system bus
 - old: 0, 2 ... 32, 70 ... 79
 - new: 0, 2 ... 64, 70 ... 79
- The value range of the number of connected JX2-I/O and JX-SIO modules (register 2013)
 - old: 0 ... 41
 - new: 0 ... 64

- The following products have been added to the module code:
 - JX3 modules
 - JX-TP20-R
 - Festo CP-FB modules
 - LioN-S modules
 - Third-party I/O modules
 - Third-party slave modules
-

Digital I/O module JX6-IO16CB

Introduction

The digital input/output module is equipped with eight galvanically isolated 24 V inputs, and eight galvanically isolated 24 V outputs with a maximum current of 0.5 A each.

I/O numbers for local JX6-I/O submodules

I/O numbers for local JX6-I/O submodules built into the JC-970MC consist of the following elements:

2	0	S	J	0	0	1	z	z
---	---	---	---	---	---	---	---	---

Element	Purpose	Value range
S	Number of the riser card	1 ... 2
J	Number of the JX6-I/O submodule located on the riser card	1 ... 2
zz	Module-specific I/O number	01 ... 08

Register numbers

In this chapter only the module register number is specified. To calculate the actually used register number, add the basic register number of the corresponding controller. The basic register number is made up of the riser card number and the number of the submodule on the riser card.

2	0	S	J	0	0	z	z	z
---	---	---	---	---	---	---	---	---

Element	Purpose	Value range
S	Number of the riser card	1 ... 2
J	Number of the JX6-I/O submodule located on the riser card	1 ... 2
zzz	Module register number	100 ... 999

Registers - Overview

The local JX6-I/O module can be programmed using a set of module registers.

Register	Description
MR 100	State of the digital inputs
MR 101	Access to the digital outputs
MR 102	Error state of the digital outputs
MR 103	Control register
MR 104	Filter interval of inputs 1 to 4
MR 105	Filter interval of inputs 5 to 8

MR 100

Digital inputs

MR 100 shows the input state. At a voltage greater than 12 V, the bit assigned to this input is set in this register (= 1). At lower voltages, the assigned bit is not set (= 0).

Meaning of the individual bits

Bit 0	Input # 1
-------	-----------

Bit 1	Input 2
-------	---------

...

Bit 7	Input 8
-------	---------

Module register properties

Type of access	Read
----------------	------

Value after reset	State of the inputs
-------------------	---------------------

MR 101

Digital outputs

From MR 101, the output state can be read and the outputs can be energized and de-energized. When the bit is set, the assigned output is energized. When the bit is cleared, the assigned output is de-energized.

Meaning of the individual bits

Bit 0	Output 1
-------	----------

Bit 1	Output 2
-------	----------

...

Bit 7	Output 8
-------	----------

MR 102

Error state of the digital outputs

The error state of the digital outputs can be read from bit 7 of MR 102. The other bits of this register remain cleared (= 0). Even if the error is cleared, bit 7 remains set. Bit 7 can be cleared by writing any value to this register.

Meaning of the individual bits

Bit 7	Collective error message of the digital outputs
-------	---

0 = No error

1 = Error in at least one output

Module register properties

Values	0, 128
--------	--------

Value after reset	128
-------------------	-----

The following errors are recognized:

- Short-circuit of the output
- Overloading of the output

MR 103

Control register

The control register lets you configure the JX6-I/O module.

Meaning of the individual bits

Bit 0 Bit 7 in output register MR 101

- 0 = The error state of the digital outputs is stored to bit 7 of MR 101.
 1 = The state of output 8 is stored to bit 7 of MR 101 when reading.

Bit 1 Behavior at errors of digital outputs

- 0 = In case of an error only the faulty output is switched off.
 1 = In case of an error all outputs are switched off

Bit 3, 2 Filter interval for the error signal of the outputs

- 00 = 1.5 ... 2.0 ms
 01 = 0.4 ... 0.5 ms
 10 = approx. 0.1 ms
 11 = approx. 0.02 ms

Module register properties

Value after reset	1
-------------------	---

MR 104

Filter interval of inputs 1 to 4

This register lets you set the filter interval for inputs 1 to 4. Two bits of this register have been assigned to each input.

Meaning of the individual bits

Bit 1, 0 Filter interval of input 1

00 =	1.5 ... 2.0 ms
01 =	0.4 ... 0.5 ms
10 =	approx. 0.1 ms
11 =	approx. 0.02 ms

Bit 3, 2 Filter interval of input 2

00 =	1.5 ... 2.0 ms
01 =	0.4 ... 0.5 ms
10 =	approx. 0.1 ms
11 =	approx. 0.02 ms

Bit 5, 4 Filter interval of input 3

00 =	1.5 ... 2.0 ms
01 =	0.4 ... 0.5 ms
10 =	approx. 0.1 ms
11 =	approx. 0.02 ms

Bit 7, 6 Filter interval of input 4

00 =	1.5 ... 2.0 ms
01 =	0.4 ... 0.5 ms
10 =	approx. 0.1 ms
11 =	approx. 0.02 ms

MR 105**Filter interval of inputs 5 to 8**

This register lets you set the filter interval for inputs 5 to 8. Two bits of this register have been assigned to each input.

Meaning of the individual bits**Bit 1, 0 Filter interval of input 5**

00 =	1.5 ... 2.0 ms
01 =	0.4 ... 0.5 ms
10 =	approx. 0.1 ms
11 =	approx. 0.02 ms

Bit 3, 2 Filter interval of input 6

00 =	1.5 ... 2.0 ms
01 =	0.4 ... 0.5 ms
10 =	approx. 0.1 ms
11 =	approx. 0.02 ms

Bit 5, 4 Filter interval of input 7

00 =	1.5 ... 2.0 ms
01 =	0.4 ... 0.5 ms
10 =	approx. 0.1 ms
11 =	approx. 0.02 ms

Bit 7, 6 Filter interval of input 8

00 =	1.5 ... 2.0 ms
01 =	0.4 ... 0.5 ms
10 =	approx. 0.1 ms
11 =	approx. 0.02 ms

Related topics

- **Slot numbering of the riser card and of the JX6-I/O submodule** (see page 114)

Combi module JX6-SV1

Introduction

This submodule features a potential-free relay contact and a counter input for incremental encoders or SSI absolute encoders.

Register numbers

In this chapter only the module register number is specified. To calculate the actually used register number, add the basic register number of the corresponding controller. The basic register number is made up of the riser card number and the number of the submodule on the riser card.

2	0	S	J	0	0	z	z	z
---	---	---	---	---	---	---	---	---

Element	Purpose	Value range
S	Number of the riser card	1 ... 2
J	Number of the JX6-I/O submodule located on the riser card	1 ... 2
zzz	Module register number	100 ... 999

Registers - Overview

The JX6-SV submodule can be programmed using a set of module registers. The function of module registers 103 to 110 depends on whether an incremental encoder or an absolute encoder has been configured:

Register	Description
MR 100	Module ID
MR 101	Hardware configuration
MR 102	Reserve
MR 103	Strobe value/encoder value received
MR 104	Preset/pulse generator
MR 105	Count value
MR 106	Reference/offset
MR 107	Control register
MR 108	Status register
MR 110	Sampling timer

MR 100**Module ID**

This register shows you, whether a JX6-SV1 has been connected.

Module register properties

Type of access	Read
Value after reset	1 (JX6-SV1 plugged in)

MR 101**Hardware configuration**

This register is for setting the module hardware.
Always write 0 to bits that have not been documented.

Meaning of the individual bits**Bit 0 Relay**

- 0 = disabled; pin 14 not connected with pin 15
- 1 = enabled; pin 14 is connected with pin 15

Bit 2 CHD signal on the counter chip

- 0 = Counter zeroing/reference has been disabled
- 1 = Counter zeroing/reference has been enabled

Bit 5 Encoder type

- 0 = Incremental encoder
- 1 = SSI absolute encoder

MR 103

Incremental encoder: Strobe register

Module register properties

Values	24 bits
Write	Writing the actual count value to this register
Read	Reading the count value written to the register last

Absolute encoder: Encoder value

This register holds the position value output by the SSI encoder.
 Only if bit 0 is set in the status register (MR 108), there are valid values to be read.

Module register properties

Type of access	Read
Values	32 bits

MR 104

Incremental encoder: Preset

When writing a value into register MR 105, this value is taken over as new count value.

Module register properties

Values	24 bits
--------	---------

Absolute encoder: Clock generator

This register is for configuring the connected SSI encoder.

Meaning of the individual bits

Bit 9 ... Frequency of the SSI pulse signal
0

$$= \text{Module clock} / (\text{SSI clock} * 2) - 1$$

Example:

$$\text{Module clock} = 8 \text{ MHz}; \text{ SSI clock} = 500 \text{ kHz}$$

$$= 8,000,000 / (500,000 * 2) - 1 = 7$$

Bit 15 ... Data width of the SSI encoder in bits
10

$$= \text{Pulse number} * 2 + 1$$

Example:
 Number of increments = 24
 $= 24 * 2 + 1 = 49$

Module register properties	
Values	0 ... 65,535
Example	$49 * 1,024 + 7 = 50,183$

MR 105

Incremental encoder: Count value

This register lets you access the present count value of the incremental encoder.

Module register properties	
Values	24 bits
Read	Present count value
Write	The value of MR 104 is taken over into this register.

MR 106

Reference/offset

This register can be used both as reference or offset register, dependent on the settings in the control register

Module register properties	
Values	24 bits

MR 107

Control register

This register lets you set the operating modes and input filters.

Meaning of the individual bits

Bit 0 Strobe

- 0 = Strobe not allowed
- 1 = Strobe allowed

Bit 1 Reference strobe

- 0 = Reference strobe not allowed
- 1 = Reference strobe allowed (with /CHA * CHB * CHD)

Bit 2 Comparison with reference value

- 0 = Comparison is not being executed
- 1 = The count value is compared with the reference value In case of equal values, bit 2 is set in MR 008-

Bit 3 Counter zeroing

- 0 = No counter zeroing
- 1 = Once-only counter zeroing using CHC * CHD

Bit 4 Repeated counter zeroing

- 0 = No counter zeroing
- 1 = Counter zeroing at each CHC * CHD

Bit 5 Counting inputs

- 0 = Counter inputs are active
- 1 = Deactivating the counting inputs

Bit 6 Set by reference

- 0 = Set-by reference deactivated
- 1 = The counter is loaded with the reference value with CHC * CHD

Bit 9, 8 Pulse edge selection

- 00 = Pulse-direction mode
- 01 = Single evaluation
- 10 = Dual evaluation
- 11 = Four-fold evaluation

Bit 10 Addition of offset

- 0 = Addition disabled
- 1 = Addition of an offset to a count and strobe value

Bit 11 File format using an SSI encoder

- 0 = Binary
- 1 = Gray-format

Bit 12 Parity using an SSI encoder

- 0 = No parity bit

1 = Parity check

Bit 13 Polarity of the parity bit

0 = Even parity

1 = Odd parity

**Bit 23 ... Input filters
14**

Minimum signal duration until a signal is detected:

$$= (T_{sig} / T_{sys}) - 1$$

T_{sig} Minimum signal duration

T_{sys} Period of a system cycle (125 ns at 8 MHz)

Module register properties

Values 24 bits

Value after reset 0x300

MR 108

Status register

After read access to this register, all bits, except for bit 3, are cleared.

Meaning of the individual bits

Bit 0 Strobe

Incremental encoder:

0 = Strobe value not yet detected

1 = Strobing value detected

Absolute encoder:

0 = Invalid positioning value

1 = Valid positioning value

Bit 1 Reference strobe

1 = Reference strobe detected

Bit 2 Comparison with reference value

1 = Count value and reference value agree with each other

Bit 3 Counter zeroing

1 = Counter zeroing has been executed

Bit 4 Strobing value has been overwritten

Incremental encoder:

1 = The value in the strobe register has been overwritten

Absolute encoder:

1 = The position value has been overwritten

Bit 5 Lost reference value

1 = A new reference value got lost, as the previous value has not been read out yet.

Bit 6 Z track error

1 = Z track errors or maximum travel speed exceeded or illegal Z track change

Bit 7 Parity error

1 = A parity error has occurred

MR 110

Sampling timer

This register value determines the intervals of reading the position value from the encoder. When the register content is "0", sampling will not be carried out. If you write a value other than "0" to the register, a sampling cycle is carried out when the set interval has elapsed.

Module register properties

Values 0 ... 65,535

Calculation = $\text{Module frequency} / (\text{sampling frequency} * 2) - 1$

Example Module frequency = 8 MHz
Sampling frequency = 1 kHz
= $8,000,000 / (1,000 * 2) - 1 = 3,999$

Related topics

- **Slot numbering of the riser card and of the JX6-I/O submodule** (see page 114)
-

Sample program for local JX6-I/O submodules

Task	Cyclically read the position value of an absolute encoder with an SSI interface. Simultaneously physically establish moving lights
Solution	For reading the position value, use module JX6-SV1. Physically establish the moving lights by using module JX6-IO16CB.
Configuration used in the sample program	<p>This example is based on the following configuration:</p> <ul style="list-style-type: none"> ▪ The riser card is inserted in PCI slot 1 (S = 1) ▪ The JX6-IO16CB module is inserted in slot 1 of the riser card (J = 1). ▪ The JX6-SV1 module is inserted in slot 2 of the module board (J = 2).
Programming	<ul style="list-style-type: none"> ▪ In the task <i>Main</i>, the modules JX6-SV1 and JX6-IO16CB are initialized, and the cyclic task is started. ▪ Depending on a digital input the interval is set, at which each output of the moving lights is active. ▪ In the <i>While</i> loop, the eight outputs for the moving lights are activated and deactivated successively. ▪ The cyclic task <i>Encode</i> stops the sampling timer and reads the position value output by the encoder last. ▪ Then, the timer is started with an interval of 0.8 ms. After this, the JX6-SV1 transmits another position value from the SSI encoder so that at the next startup of the cyclic task, the result is ready for being fetched. ▪ Finally, the position value is masked according to the set format.
Software versions	<p>The sample program requires the software versions listed below:</p> <ul style="list-style-type: none"> ▪ JetSym: Version 5.1.3 or higher ▪ Controller JC-970MC: OS version 1.07 or higher <p>You can also find the latest sample programs in the JetSym online help.</p>
JetSym STX program	<pre> Type DIG_I808: Struct Inputs : Int; Outputs : Int; OutStatus : Int; Control : Int; FilterI1to4 : Int; FilterI5to8 : Int; End_Struct; JX6_SV1: Struct ModuleIdentification : Int; Config : Int; </pre>

```
        DAC                : Int;
        CntValue           : Int;
        CntBitClock       : Int;
        CntDummy           : Int;
        CntRef             : Int;
        CntControl         : Int;
        CntStatus          : Int;
        IntMask            : Int;
        Timer              : Int;
    End_Struct;
End_Type;

Const
    // Gray/bin conversion; 2MHz filter
    SSI_CONTROL           = 0x4800;
    // Delay 800 µs
    SSI_TIMER_1MS        = 3199;
End_Const;

Var
    DigitalIO            : DIG_I808   At %VL 201100100;
    Encoder              : JX6_SV1   At %VL 201200100;

    SSIDataMask         : Int;
    SSIsignBit          : Int;
    SSIsignExt          : Int;

    SSItimerValue       : Int;
    Position            : Int;

    OutputTime          : Int;
End_Var;

Function SetUpSSI(DataLen, Clock_kHz: Int): Int;
    Var
        i, j : Int;
    End_Var;

    // Configuration as an SSI encoder
    Encoder.Config := 32;

    i := 0xffffffff;
    j := 32 - DataLen;
    i >>= j;
    SSIDataMask := i;
    SSIsignExt := SSIDataMask Wxor 0xffffffff;
    SSIsignBit := DataLen - 1;

    // Data length of the SSI encoder in bits
```

```

i := DataLen * 2 + 1;
i <<= 10;

// Frequency of the SSI pulse signal
j := 4000 / Clock_kHz - 1;
Encoder.CntBitClock := i Wor j;

Encoder.CntControl := SSI_CONTROL;

SSItimerValue := SSI_TIMER_1MS;

// Start the timer
Encoder.Timer := SSItimerValue;
End_Function;

Task Main Autorun
Var
    OutMask:    Byte;
End_Var;

// 24-bit data length, 500 kHz
SetUpSSI(24, 500);

// Acknowledge the error state of the digital outputs
DigitalIO.OutStatus := 0;

TaskAllEnableCycle();

Loop
    If BitSet(DigitalIO.Inputs, 7) Then
        OutputTime := T#200ms;
    Else
        OutputTime := T#100ms;
    End_If;

    OutMask := 1;
    While OutMask Do
        DigitalIO.Outputs := OutMask;
        Delay(OutputTime);
        OutMask <<= 1;
    End_While;
End_Loop;
End_Task;

Task Encode    Cycle T#1ms
// Stop the sampling timer of the SSI encoder
Encoder.Timer := 0;
// Read the position value from the SSI encoder

```

```
Position := Encoder.CntValue;
// Restart timer
Encoder.Timer := SSItimerValue;

// Mask the data bits
Position := Position Wand SSIdataMask;
// Is a sign-extension required?
If BitSet(Position, SSIsignBit) Then
    // Sign extension to 32 bits
    Position := Position Wor SSIsignExt;
End_If;
End_Task;
```

6.4 E-mail

Introduction

The user creates template files for e-mails. Into these templates, the controller JC-970MC can enter variables for sending, if required. The controller sends e-mails to an e-mail server which will then forward the message.

This chapter describes how to configure the e-mail feature in the JC-970MC, and how the controller both creates and sends e-mails.

Activating the e-mail feature

To activate the e-mail feature in the JC-970MC, the following requirement must be met:

- A valid e-mail configuration file exists while the controller is booting.

If this requirement has been met, the corresponding bit in the web status register is set and the e-mail feature is available.

Required programmer's skills

To be able to use the e-mail feature, the following skills are required:

- Since files are used to configure the e-mail feature, and e-mails as such are based on these files, the user must be familiar with the file system.
- The user must be familiar with IP networks.

Content

Topic	Page
Configuring the E-mail feature	144
Creating e-mails.....	152
Sending an e-mail.....	161
Registers.....	162

6.4.1 Configuring the E-mail feature

Introduction This chapter gives a description on how to configure the e-mail feature so as to allow sending of e-mails from within the application program. During the boot process, the JC-970MC reads out configuration data from the file **/EMAIL/email.ini**.

- Prerequisites** For creating the configuration file, the following prerequisites must be fulfilled:
- The IP address of the e-mail server must be known.
 - If the IP address of the e-mail server is not known, name resolution through a DNS server must be possible - refer to *Using names for IP addresses*.
 - The log-on and authentication parameters at the e-mail server must be known.

To obtain this information contact your network administrator.

Content

Topic	Page
Structure of the configuration file	145
Section [SMTP]	146
Section [POP3]	148
Section [DEFAULT]	150
Configuration file - Examples	151

Structure of the configuration file

Introduction

The e-mail client is configured with the data from the **/EMAIL/email.ini** file. The JC-970MC reads the values during the boot process only.

Structure of the configuration file

This configuration file is a text file the entries of which are grouped into several sections.

- These sections are for entering values which are then used by the e-mail client.
- You can insert blank lines as required.
- The following characters precede a comment line: "!", "#" or ";".

Encrypted sending of e-mails

The JC-970MC supports the encrypted sending of e-mails.

To use this function, the **SMTP** section of the **email.ini** file must contain the **SECUREEMAIL** and **STARTTLS** entries. If these entries are missing, e-mails are sent unencrypted.

Sections

The configuration file contains up to three sections. Section [SMTP] is mandatory. The user does not need to create the other sections unless they are actually required.

Section	Configuration values
[SMTP]	<ul style="list-style-type: none"> ▪ IP address and port number of the SMTP server ▪ Log-on parameters ▪ With/without encryption
[POP3]	<ul style="list-style-type: none"> ▪ IP address and port number of the POP3 server ▪ Log-on parameters
[DEFAULT]	<ul style="list-style-type: none"> ▪ Name of an e-mail template file containing default values

Section [SMTP]

Introduction

This section lets you specify the parameters for establishing a connection with the SMTP server.

Example:

```
[SMTP]
IP           = 192.168.40.1
PORT        = 25000
HELO        = JetControl_2
USER        = JetControl0815
PASSWORD    = MyPassWord
SECUREMAIL  = 1
STARTTLS    = 0
```

Authentication

With this type of authentication, the JC-970MC performs a user logon to the SMTP server before sending an e-mail. During the logon process USER and PASSWORD must be entered. The JC-970MC supports the following authentication methods:

- LOGIN
- PLAIN
- CRAM-MD5

Configuration values**IP**

In the given example	192.168.40.1
Description	IP address of the SMTP server; can also be specified as name.
Valid values	<ul style="list-style-type: none"> ▪ > 1.0.0.0 ▪ < 223.255.255.255
Illegal values	<ul style="list-style-type: none"> ▪ Network address ▪ Broadcast address
In case of illegal value or missing entry	The e-mail feature is not available

PORT

In the given example	25,000
Description	Port number of the SMTP server
Valid values	<ul style="list-style-type: none"> ▪ > 0 ▪ < 65,536
Illegal values	<ul style="list-style-type: none"> ▪ > 65,335
In case of missing entry	25

HELO

In the given example	JetControl_2
Description	Name for logging on at the e-mail server
Valid values	String of 63 characters max.
In case of missing entry	When sending the e-mail, the controller uses the entry contained in [FROM].

USER

In the given example	JetControl0815
Description	Log-on name for SMTP authentication. If this entry exists, the entry PASSWORD is required, too.
Valid values	String of 63 characters max.
In case of missing entry	SMTP authentication will not be carried out.

PASSWORD

In the given example	MyPassWord
Description	Log-on password for SMTP authentication. If this entry exists, the entry USER is required, too.
Valid values	String of 63 characters max.
In case of missing entry	SMTP authentication will not be carried out.

SECUREMAIL

In the given example	1
Description	Encryption: If the value is 0 e-mails are sent unencrypted, if the value is 1 e-mails are sent encrypted.
Valid values	1 or 0
In case of missing entry	E-mails are sent unencrypted

STARTTLS

In the given example	0
Description	Encryption of the communication setup If STARTTLS is enabled (1), the connection to the server is established unencrypted. As soon as the connection is established, the e-mail is transmitted in encrypted form. If STARTTLS is disabled (0), establishing contact with the server is already encrypted.
Valid values	1 or 0
In case of missing entry	Connection setup to the server is already encrypted.

Section [POP3]

Introduction

This section lets you specify the parameters for establishing a connection with the POP3 server.

This section is required only in case the e-mail server requires authentication via POP3-before-SMTP.

Example:

```
[POP3]
IP      = 192.168.40.1
PORT    = 25100
USER    = JetControl4711
PASSWORD = Pop3PassWord
```

Authentication

This type of authentication requires the JC-970MC to log on at the POP3 server. During the logon process USER and PASSWORD must be entered. After that, the SMTP server allows e-mails to be sent for a given period of time (usually 10 to 30 minutes).

Configuration values

IP	
In the given example	192.168.40.1
Description	IP address of POP3 server; can also be specified as name.
Valid values	<ul style="list-style-type: none"> ▪ > 1.0.0.0 ▪ < 223.255.255.255
Illegal values	<ul style="list-style-type: none"> ▪ Network address ▪ Broadcast address
In case of illegal value or missing entry	POP3 log-on will not be carried out.
PORT	
In the given example	25,100
Description	Port number of POP3 server
Valid values	<ul style="list-style-type: none"> ▪ > 0 ▪ < 65,536
Illegal values	<ul style="list-style-type: none"> ▪ > 65,335
In case of missing entry	110

USER

In the given example	JetControl4711
Description	Log-on name for POP3 authentication. If this entry exists, the entry PASSWORD is required, too.
Valid values	String of 63 characters max.
In case of missing entry	POP3 log-on will not be carried out.

PASSWORD

In the given example	Pop3PassWord
Description	Log-on password for POP3 authentication. If this entry exists, the entry USER is required, too.
Valid values	String of 63 characters max.
In case of missing entry	POP3 log-on will not be carried out.

Section [DEFAULT]

Introduction

This section lets you specify the name of an e-mail template file which contains default settings for e-mails. If a section is not available in a given e-mail template, JC-970MC applies these default settings for sending an e-mail message.

Example

```
[DEFAULT]
MAILCFG = EmailDefaults.cfg
```

Related topics

- **Structure of the template file** (see page 154)
-

Configuration file - Examples

Introduction

This section contains several examples of the e-mail configuration file **/EMAIL/email.ini**.

Minimum configuration

If no authentication is required and the default value is assigned to the IP port of the SMTP server, the configuration file must contain only the IP address of the SMTP server.

```
[SMTP]
IP      = 192.168.40.1
```

Authentication through POP3 Log-on

In case the e-mail server requires previous log-on through POP3 and an e-mail template containing default setting has been defined:

```
[SMTP]
IP      = 192.168.40.1

[POP3]
IP      = 192.168.40.1
USER    = JetControl4711
PASSWORD = Pop3PassWord

[DEFAULT]
MAILCFG = EmailDefaults.cfg
```

Authentication through SMTP

In case the e-mail server requires an encrypted authentication:

```
[SMTP]
IP      = 192.168.40.1
USER    = JetControl0815
PASSWORD = MyPassWord
```

6.4.2 Creating e-mails

Introduction

This chapter describes how to create an e-mail. Then, the application program sends these e-mails.

For each e-mail the user has to create an e-mail template file.

Content

Topic	Page
Name of the e-mail template file	153
Structure of the e-mail template file	154
Inserting real-time controller values	156

Name of the e-mail template file

Introduction

This naming convention must only be kept to, if system function 110 is applied, which should not be used any further, though.

The STX feature `EMailSend()` lets you select any file name and directory, as long as the limitations owed to the file system are kept to.

The name of an e-mail template file consists of a fixed part of the name and a variable part. The variable part of the name allows the application program to choose various e-mails for sending.

File name

`email_#.cfg`

Part of the name	Description
<code>email_</code>	Name prefix which always remains fixed
<code>#</code>	Number of the e-mail; value between 0 and 255
<code>.cfg</code>	Fixed file extension

Storage location

E-mail template files must be stored to the same directory on the internal flash disk as is the configuration file.

`/EMAIL`

Examples

`email_0.cfg`
`email_37.cfg`
`email_255.cfg`

Structure of the e-mail template file

Introduction

An e-mail template file is a text file which is divided into sections. For sending the e-mail, the JC-970MC compiles the information contained in these sections.

E-mail template file settings.

- Sections [FROM] and [TO] are mandatory. This information may be specified either in the e-mail to be sent or in the e-mail template file containing the default settings.
- All parameters in these sections can be tagged with realtime controller values (refer to *Inserting realtime controller values*).

[FROM]

Sender

[TO]

Addressee

[CC]

Additional addressee(s)

[SUBJECT]

Subject

[ATTACHMENT]

Complete path and file name

[MESSAGE]

E-mail message text

Sections

[FROM]

Description

E-mail sender

Comments

Please check with your IT administrator which information must be entered here.

Length

63 characters

Example

[FROM]
JetControl@jetter.de

[TO]

Description

E-mail addressee

Comments

Several addressees are separated by the semicolon “;”.

Length

255 characters

Example

[TO]
service@mydomain.com

[CC]	
Description	Additional e-mail addressee(s)
Comments	Several addressees are separated by the semicolon “;”.
Length	255 characters
Example	[CC] service@mydomain.com;hotline@mydomain.com

[SUBJECT]	
Description	Subject
Length	255 characters
Example	[SUBJECT] Fatal Error

[ATTACHMENT]	
Description	Complete name of the file to be attached
Comments	The attached file must be a text file.
Length	511 characters
Example	[ATTACHMENT] /logfiles/error_report.log

[MESSAGE]	
Description	E-mail message text
Comments	Text only message
Length	65,535 characters
Example	[MESSAGE] Have a nice day ! JetControl.

Inserting real-time controller values

Introduction

Actual real-time controller values are integrated into parameter entries within the sections via tag functions. This way, the contents respectively states of registers, text registers, inputs, outputs and flags can be displayed.

Tag delimiters

All tags start and end with defined strings (delimiters). Between these tag delimiters, the variables are defined.

Delimiter	String
Tag start	<JC:DTAG
Tag end	/>

Variable definition

The variable definition in a tag contains attributes which are used to set, for example, how the value of a variable is to be displayed:

name

Description	Variable name
Comments	Code letter followed by the variable number
Example	name="R1000023"

type

Description	Variable type of notation
Example	type="REAL"

format

Description	Representation format
Comments	Refer to format definition
Example	format="+0#####.###"

factor

Description	Factor by which the real-time controller value is multiplied
Comments	Multiplication is executed prior to adding the offset
Example	factor="1.5"

offset

Description	Value which is added to the real-time controller value
Comments	Multiplication by the factor is executed prior to adding the value to the real-time controller value
Example	offset="1000"

Format definition

You can define the representation of variables by means of their attribute.

- The number of digits/characters used for representing a variable can be defined by the character "#".
- Prefix "0" sets the output of leading zeros. This applies to the register types INT, INTX and REAL.
- Prefix "+" sets the output of a sign. This applies to the register types INT and REAL.
- Prefixing a blank sets the output of a blank. This applies to the register types INT and REAL.

Registers/text registers

The variable name begins with a capital "R" followed by the register number. The following types are possible:

Type	Notation
INT	Integer, decimal
INTX	Integer, hexadecimal
INTB	Integer, binary
BOOL	Register content = 0 --> Display: 0 Register content != 0 --> Display: 1
REAL	Floating point, decimal
STRING	Text register

Standard type: INT

Example:

```
<JC:DTAG name="R1000250" type="REAL" format="+0#####.###" factor="3.25" offset="500" />
```

Result:

This instruction causes the contents of register 1000250 to be multiplied by 3.25. Then, 500 is added to the product. The result appears in the Web browser with sign and at least five integer positions before the decimal point. Leading zeros are added as appropriate. Furthermore, three decimal positions are added.

Flags

The variable name begins with a capital "F" followed by the flag number. The following types are possible:

Type	Notation
BOOL	Flag = 0 --> Display: 0 Flag = 1 --> Display: 1
STRING	Flag = 0 --> Display: FALSE Flag = 1 --> Display: TRUE

Standard type: BOOL

Example:

```
<JC:DTAG name="F100" type="STRING" format="#" />
```

Result:

The state of flag 100 is displayed as string "T" or "F".

Inputs

The variable name begins with a capital "I" followed by the input number.
The following types are possible:

Type	Notation
BOOL	Input = 0 --> Display: 0 Input = 1 --> Display: 1
STRING	Input = 0 --> Display: OFF Input = 1 --> Display: ON

Standard type: BOOL

Example:

```
<JC:DTAG name="I201200308" type="STRING" />
```

Result:

The state of input 201200308 is displayed as "ON" or "OFF".

Outputs

The variable name begins with a capital "O" followed by the output number.
The following types are possible:

Type	Notation
BOOL	Output = 0 --> Display: 0 Output = 1 --> Display: 1
STRING	Output = 0 --> Display: OFF Output = 1 --> Display: ON

Standard type: BOOL

Example:

```
<JC:DTAG name="O201100308" />
```

Result:

The state of output 201100308 is inserted as "1" or "0".

Access via pointer register

Access via pointer register is realized by inserting the capital letter "P" in front of the variable name. In each case the value of the variable is displayed whose number corresponds to the content of the register specified in the variable name.

Examples:

```
<JC:DTAG name="PR1000300" />
```

Result: The content of the register is displayed whose number is contained in register 1000300.

```
<JC:DTAG name="PF1000300" />
```

Result: The state of the flag is displayed whose number is contained in register 1000300.

```
<JC:DTAG name="PI1000300" />
```

Result: The state of the input is displayed whose number is contained in register 1000300.

```
<JC:DTAG name="PO1000300" />
```

Result: The state of the output is displayed whose number is contained in register 1000300.

Access via pointer register and offset

To specify the number of the variable to be displayed, it is also possible to add a constant value or another register content to the pointer register value

Examples:

```
<JC:DTAG name="PR1000300 + 100" />
```

Result: The content of the register is displayed whose number results from the addition of the content of register 1000300 and value 100.

```
<JC:DTAG name="PR1000300 + R1000100" />
```

Result: The content of the register is displayed whose number results from the addition of the content of register 1000300 and the content of register 1000100.

```
<JC:DTAG name="PF1000300 + 100" />
```

Result: The state of the flag is displayed whose number results from the addition of the content of register 1000300 and value 100.

```
<JC:DTAG name="PF1000300 + R1000100" />
```

Result: The state of the flag is displayed whose number results from the addition of the content of register 1000300 and the content of register 1000100.

```
<JC:DTAG name="PI1000300 + 100" />
```

Result: The state of the input is displayed whose number results from the addition of the content of register 1000300 and the value 100.

```
<JC:DTAG name="PI1000300 + R1000100" />
```

Result: The state of the input is displayed whose number results from the addition of the content of register 1000300 and the content of register 1000100.

```
<JC:DTAG name="PO1000300 + 100" />
```

Result: The state of the output is displayed whose number results from the addition of the content of register 1000300 and the value 100.

```
<JC:DTAG name="PO1000300 + R1000100" />
```

Result: The state of the output is displayed whose number results from the addition of the content of register 1000300 and the content of register 1000100.

6.4.3 Sending an e-mail

Introduction

This chapter gives a description on how to send previously created e-mails from within the application program.

When sending an e-mail from the application program, the JC-970MC creates the e-mail based on the e-mail template file and inserts variable values if required.

Processing within the application program

Sending an e-mail may take considerable time. Therefore, other tasks of the application program are processed while an e-mail is being sent. Only one e-mail function call is possible at a time. While an e-mail of a task is being sent, all other tasks which invoke the e-mail function are therefore blocked until this operation is completed.

System function 110

As of JetSym 5.0, system function 110 is outdated. Instead, apply JetSym STX function `EMailSend()`.

JetSym STX function EMailSend()

The JetSym STX function `EMailSend()` is described in detail in the JetSym online help.

Declaration of functions:

```
Function EMailSend(Const Ref FileName: String): Int;
```

6.4.4 Registers

Introduction

This chapter gives a description of those registers from which you can query the status of e-mail processing.

Content

Topic	Page
Registers - Overview.....	163
Registers - Description.....	164

Registers - Overview

Introduction

The JC-970MC provides several registers for querying the processing status of the e-mail function.

Registers - Overview

Register	Description
202930	Web status
292932	IP address of SMTP server
292933	IP address of POP3 server
292934	Port number of SMTP server
292935	Port number of POP3 server
292937	Status of e-mail processing
292938	ID of the task that is just sending an e-mail

Registers - Description

R 202930

Web status

The Web status register displays all available functions in bit-coded mode.

Meaning of the individual bits

Bit 0 FTP server

1 = available

Bit 1 HTTP server

1 = available

Bit 2 E-mail

1 = available

Bit 2 is set only if the configuration file **/EMAIL/email.ini** is available.

Bit 3 Data file function

1 = available

Bit 4 Modbus/TCP

1 = existing

Bit 5 Modbus/TCP

1 = available

Bit 7 FTP client

1 = available

Module register properties

Type of access Read

Value after reset Depending on options purchased

R 292932

IP address of the SMTP server;

This register lets you read the IP address of the SMTP server in the same format as specified in the file **/EMAIL/email.ini**.

Module register properties

Type of access Read

Value after reset Depending on configuration

Takes effect Once R 202930.2 = 1

R 292933**IP address of POP3 server**

This register lets you read the IP address of the POP3 server in the same format as specified in the file **/EMAIL/email.ini**.

Module register properties

Type of access	Read
Value after reset	Depending on configuration
Takes effect	Once R 202930.2 = 1

R 292934**Port number of the SMTP server**

This register lets you read the port number of the SMTP server in the same format as specified in the file **/EMAIL/email.ini**.

Module register properties

Type of access	Read
Value after reset	Depending on configuration
Takes effect	Once R 202930.2 = 1

R 292935**Port number of POP3 server**

This register lets you read the port number of the POP3 server in the same format as specified in the file **/EMAIL/email.ini**.

Module register properties

Type of access	Read
Value after reset	Depending on configuration
Takes effect	Once R 202930.2 = 1

R 292937

Status of e-mail processing

This register lets you track the e-mail status.

Module register properties

Values	0	No e-mail is being sent
	1	Parameters are being handed over to the e-mail client of the JC-970MC.
	2	E-mail is being compiled and connection with the server is being established.
	3	E-mail has been sent to the server.
Type of access	Read	

R 292938

Task ID (e-mail)

Shows the ID of the task that is just sending an e-mail

Module register properties

Values	0 ... 99	Task ID
	255	There is no task sending an e-mail.
Value after reset	255	
Type of access	Read	

6.5 Sorting data

Introduction	This chapter describes system function 50. This system function is used to trigger the sorting algorithm provided by the operating system.
Application	For sorting data in controller registers by their value. The sort algorithm is provided by the operating system of the controller. The data to be sorted are indirectly addressed through a descriptor using parameter 1.
System function 50	As of JetSym 5.0, system function 50 is outdated. Instead, apply JetSym STX function <code>QSort()</code> .
JetSym STX function QSort()	The JetSym STX function <code>QSort()</code> is described in detail in the JetSym online help. Declaration of functions: <code>Function QSort(DataPtr: Int, ElementCnt: Int, ElementSize: Int, SortOffset: Int, SortType: STXBASETTYPE, SortMode: QSORTMODE): Int;</code>

6.6 Modbus/TCP

Introduction

This chapter describes the functions of the Modbus/TCP server and client integrated into the JC-970MC.

Required programmer's skills

To be able to use the functions described in this chapter, the user must be familiar with the following:

- Modbus/TCP and supported commands
- IP networks

Content

Topic	Page
Modbus/TCP server	169
Modbus/TCP client.....	175
Modbus/TCP client with STX variables.....	177

6.6.1 Modbus/TCP server

Introduction After successful start of the Modbus/TCP server, an external client can access registers, flags, inputs and outputs.
 This chapter describes the addressing process and the commands supported by the Modbus/TCP server.

Number of possible connections Four connections may be opened at the same time.

Restriction Modbus/TCP only supports transmission of registers with a width of 16 bits. From this follows, that only the 16 least significant bits are transmitted when 32-bit registers are sent.
 When assigning incoming register values to the internal 32-bit registers no sign extension will be carried out.

Content

Topic	Page
Addressing	170
Supported commands - Class 0	172
Supported commands - Class 1	173
Supported commands - Class 2	174

Addressing

Introduction

The addresses which have been received via Modbus/TCP can be modified locally in the Modbus-TCP server. For this purpose, three registers have been provided. The basic addresses for accessing registers, inputs and outputs are entered into these registers. Then, the address contained in the Modbus/TCP frame specifies the address with reference to the basic address.

R 272702

Register offset

The basic address for accessing registers via Modbus/TCP is entered into R 272702.

Register properties

Value after reset	1000000
-------------------	---------

R 272704

Input offset

The basic address for accessing inputs via Modbus/TCP is entered into R 272704.

Register properties

Value after reset	100000000
-------------------	-----------

R 272705

Output offset

The basic address for accessing outputs via Modbus/TCP is entered into R 272705.

Register properties

Value after reset	100000000
-------------------	-----------

Example 1

The Modbus/TCP server on the JetControl receives from a Modbus/TCP client the command **read multiple registers** starting from register number 100. The number of registers to be read is 5. Register 272702 *Register Offset* contains the value 1000000.

Hence, registers 1000100 through 1000104 will be read.

Example 2

The Modbus/TCP server on the JetControl receives from a Modbus/TCP client the command **read input discretes** specifying input number 210 and the instruction to read this input. Register 272704 *Input Offset* contains the value 100000000.

Hence, input 100000210 of a peripheral module, such as JX3-DI16, will be read.

Example 3

The Modbus/TCP server on the JetControl receives from a Modbus/TCP client the command **write coils** specifying output number 205 and the instruction to set this output. Register 272705 *Output Offset* contains value 100000000. Hence, output 100000205 of a peripheral module JX3-DO16 will be set.

Supported commands - Class 0

fc 3

read multiple registers

Reading register sets

The starting register number within the JC-970MC is calculated as follows:
Register number specified in the command plus the content of R 272702
Register Offset.

fc 16

write multiple registers

Writing register sets

The starting register number within JC-970MC is calculated as follows: Register
number specified in the command plus the content of R 272702 *Register Offset*.

Supported commands - Class 1

fc 1**read coils**

Reading outputs

The output number within the JC-970MC is calculated as follows: Output number specified in the command plus the content of register 272705 *Output Offset*.

fc 2**read input discretes**

Reading inputs

The input number within the JC-970MC is calculated as follows: Input number specified in the command plus the content of register 272704 *Input Offset*.

fc 4**read input registers**

Reading inputs blockwise in 16-bit words.

The starting register number within the JC-970MC is calculated as follows: Register number specified in the command plus the content of R 272702 *Register Offset*.

fc 5**write coil**

Enabling/disabling an individual output

The output number within the JC-970MC is calculated as follows: Output number specified in the command plus the content of register 272705 *Output Offset*.

fc 6**write single register**

Entering values into the 16 least significant bits of a register

The starting register number within the JC-970MC is calculated as follows: Register number specified in the command plus the content of R 272702 *Register Offset*.

Supported commands - Class 2

fc 15

force multiple coils

Enabling/disabling several outputs

The output number within the JC-970MC is calculated as follows: Output number specified in the command plus the content of register 272705 *Output Offset*.

fc 23

read/write registers

Reading/writing registers simultaneously

The starting register number within the JC-970MC is calculated as follows: Register number specified in the command plus the content of R 272702 *Register Offset*.

6.6.2 Modbus/TCP client

Introduction

The Modbus/TCP client included in JC-970MC supports only Class 0 Conformance.

This class uses commands for reading and writing multiple registers. Up to 125 registers with a width of 16 bits can be transmitted in one frame.

As protocol ID "0" is used. Sent and received frames are associated by means of the transaction ID.

This chapter describes how to carry out noncyclical or cyclical transmission to a Modbus/TCP server using system functions.

Number of possible connections

Connections to eleven different Modbus/TCP servers may be opened at the same time.

Noncyclical data transmission

System functions 65 and 67 *reading registers*, as well as 66 and 68 *writing registers* are used to establish a acyclical transmission channel to a Modbus/TCP server.

These system functions establish a connection to the specified Modbus/TCP server, transmit the desired data and clear down the connection.

If RemoteScan has already established a connection for cyclical data transmission, this connection will be used. Setting-up and clearing-down the connection is, therefore, not required.

Cyclical data transmission

Cyclical data transmission is made through the configurable function `RemoteScan`. The inputs and outputs 20001 through 36000 that are combined in the 16-bit registers 278000 through 278999 are cyclically transmitted from and to the Modbus/TCP servers.

To each Modbus/TCP server (IP address and port) a connection is established. The connection is established independent of how many communication units are configured on this server.

If several communication units are configured on one Modbus/TCP server, accesses are serialized since servers often do not support **command pipelining**. If several servers have been configured, communication is carried out in parallel.

Combined inputs and outputs

Register	Inputs and outputs
278000	20001 ... 20016
278001	20017 ... 20032
278002	20033 ... 20048
...	...
278999	35985 ... 36000

These registers and the inputs and outputs mapped to them are merely storage cells within the RAM. There is no direct mapping to the hardware. Therefore, it is not defined whether inputs or outputs are mapped to a register. Assignment is made not until configuration in the communication units takes place.

Unit ID

The instruction header of a Modbus/TCP frame contains a *Unit ID*. The Unit ID

is not evaluated by Modbus/TCP devices, as they can be addressed without ambiguity by their IP address. Therefore, in the case of system functions 65, 66 and 80 always value "1" is sent.

Converters from Modbus/TCP to Modbus RTU use the *Unit ID* for addressing the Modbus RTU servers. Therefore, the corresponding system functions for reading and writing registers (system functions 67 and 68), as well as for initializing RemoteScan (system function 85) have been provided. These system functions can be used to set the Unit ID.

Restriction

Modbus/TCP only supports transmission of registers with a width of 16 bits. From this follows, that only the 16 least significant bits are transmitted when 32-bit registers are sent.

When assigning incoming register values to the internal 32-bit registers no sign extension will be carried out.

Outdated system functions

As of JetSym 5.0, the system functions are outdated. Instead, apply the corresponding JetSym STX functions.

JetSym STX functions

This is a comparison between the system functions and the corresponding JetSym STX functions.

System functions	Corresponding JetSym STX function
60	Function ModbusCRCgen(FramePtr: Int, Length: int): Int;
61	Function ModbusCRCcheck(FramePtr: Int, Length: int): Int;
65/67	Function ModbusReadReg(Const Ref MbParam: MODBUS_PARAM): Int;
66/68	Function ModbusWriteReg(Const Ref MbParam: MODBUS_PARAM): Int;
80/85	Function RemoteScanConfig(Protocol: RSCAN_PROTOCOL, Elements: Int, Const Ref Configuration: RSCAN_DSCR): Int;
81	Function RemoteScanStart(Protocol: Int): Int;
82	Function RemoteScanStop(Protocol: Int): Int;

6.6.3 Modbus/TCP client with STX variables

Introduction	<p>The Modbus/TCP client included in JC-970MC supports only Class 0 conformance.</p> <p>This class uses commands for reading and writing multiple registers. One frame transmits up to 125 registers of 16 bits width.</p> <p>As protocol ID, "0" is used. Assignment of transmitted and received frames is carried out using the transaction ID.</p> <p>This chapter describes how to carry out noncyclical or cyclical transmission to a Modbus/TCP server using STX functions.</p>
Number of possible connections	<p>Connections to eleven different Modbus/TCP servers may be opened at the same time.</p>
Noncyclical data transmission	<p>Functions <code>ModbusReadReg()</code> and <code>ModbusWriteReg()</code> are used to establish a noncyclical transmission channel to a Modbus/TCP server.</p> <p>These functions copy data between registers of a Modbus/TCP server and STX variables. They establish a connection to the specified Modbus/TCP server, transmit the desired data and clear down the connection again.</p> <p>If <code>RemoteScan</code> has already established a connection for cyclical data transmission, this connection will be used. Setting-up and clearing-down the connection is, therefore, not required.</p>
Cyclical data transmission	<p>Cyclical data transmission is made through the configurable function <code>RemoteScanConfig()</code>. The data are cyclically transmitted from and to the Modbus/TCP servers by means of STX variables.</p> <p>To each Modbus/TCP server (IP address and port) a connection is established. The connection is established independent of how many communication units are configured on this server.</p> <p>If several communication units are configured on one Modbus/TCP server, accesses are serialized since servers often do not support command pipelining. If several servers have been configured, communication is carried out in parallel.</p>
Unit ID	<p>Converters from Modbus/TCP to Modbus RTU use the <i>Unit ID</i> for addressing the Modbus RTU servers. For this reason, the Unit ID can be set.</p>

JetSym STX functions

The JetSym STX functions are described in detail in the JetSym online help.

System functions	Corresponding JetSym STX function
60	Function ModbusCRCgen(FramePtr: Int, Length: int): Int;
61	Function ModbusCRCcheck(FramePtr: Int, Length: int): Int;
65/67	Function ModbusReadReg(Const Ref MbParam: MODBUS_PARAM): Int;
66/68	Function ModbusWriteReg(Const Ref MbParam: MODBUS_PARAM): Int;
80/85	Function RemoteScanConfig(Protocol: RSCAN_PROTOCOL, Elements: Int, Const Ref Configuration: RSCAN_DSCR): Int;
81	Function RemoteScanStart(Protocol: Int): Int;
82	Function RemoteScanStop(Protocol: Int): Int;

7 AutoCopy - Automatic copying of controller data

Introduction

This chapter describes the AutoCopy function which allows to copy data within the controller and/or between controller, the connected expansion modules and a controller within the network. To this end, you can create a command file which is then stored along with the data to a USB flash drive. This command file is automatically processed by the controller during the boot process.

A detailed description of the AutoCopy function with all commands and examples can be found in the application-oriented manual „File System“ at www.jetter.de => Downloads=> Product independent Documentation => Application-oriented Manuals

Features

AutoCopy performs the following functions:

- Storing registers and flags to a file
 - Restoring registers and flags from a file
 - Creating directories
 - Deleting directories
 - Copying files
 - Deleting files
-

Areas of application

Basically, AutoCopy is used in the following scenarios:

- Where remote maintenance is not possible
- Where there is no PC on site
- Where the operator is not able or should not be allowed to make modifications to the plant

The AutoCopy function lets you:

- Modify the application program
 - Modify the application data
 - Modify the controller configuration
 - Update the operating system (of the controller and modules on the system bus)
-

Prerequisites

For automatic copying of controller data, the following prerequisites must be fulfilled:

- The programmer must be familiar with the file system.
 - In the configuration file **config.ini** of the controller, the path and file name of the command file in the section *[FILES]* must be entered in **AutoCopyIni**. For access to the configuration file, at least system rights are required.
 - The command file and other required files are available.
-

7 AutoCopy - Automatic copying of controller data

config.ini - Example

This is an example of a configuration file **config.ini** with an entry *AutoCopyIni*:

```
;JC-970MC System Configuration
;Copyright (c) 2009 by Jetter AG, Ludwigsburg, Germany

[IP]
Address      = 192.168.10.209
SubnetMask   = 255.255.255.0
DefGateway   = 0. 0. 0. 0
DNSServer    = 192.168. 10.244

[HOSTNAME]
SuffixType   = 0
Name         = JetControl970MC

[PORTS]
JetIPBase    = 50000
JVMDebug     = 52000

[FILES]
AutoCopyIni  = /USB1/autocopy.ini
```

Naming convention

In this description, *Full Name* means the name of the file or directory including its full path.

7.1 AutoCopy - How it works

Introduction

This chapter describes how to launch and execute the AutoCopy function.

Content

Topic	Page
Launching the AutoCopy function.....	182
Executing the AutoCopy function:.....	183
Terminating AutoCopy mode	184

Launching the AutoCopy function

Introduction

The AutoCopy function can only be launched when the controller is booting (i.e. after startup).

Prerequisites

You have created the command file and stored it to the respective directory.

	Value	Remarks
File name	autocopy.ini	All lower case letters
Directory	/USB1/	Root directory on the USB flash drive

Launching the AutoCopy feature

To launch the AutoCopy function, proceed as follows:

Step	Action
1	Disconnect the controller from the power supply.
2	Set the mode selector S11 to <i>LOAD</i> position.
3	Switch the controller on.
4	Wait for the amber LED GP2 (D1) to be lit and for the green LED GP1 (RUN) to flash slowly at approximately 1 Hz.
⇒	Result: The controller executes the AutoCopy function.
5	Wait for the amber LED GP2 (D1) to be lit and for the green LED GP1 (RUN) to flash fast at approximately 4 Hz.
⇒	Result: The AutoCopy process is completed.

Executing AutoCopy commands

Introduction

During the boot process in AutoCopy mode the controller executes the commands contained in the command file.

Restrictions

In AutoCopy mode the following restrictions of controller functions apply:

- The controller does not execute the application program.
- There is no communication with the controller.
- When the AutoCopy function is completed the controller must be restarted.
















AutoCopy function - Steps

The AutoCopy process involves the following steps:

Step	Description
1	The controller opens the file /USB1/autocopy.ini that is specified by the entry AutoCopyIni in the configuration file /System/config.ini .
2	The controller reads the values from section [OPTIONS] .
3	The controller reads the command and its parameters from section [COMMAND_1] , processes it and writes the results, if any, into the log file.
4 ... n	The controller processes the other commands in ascending order up to the number given in section [OPTIONS] .
n+1	The controller calculates the statistic values for all command results and writes them into the log file.

LEDs of the JC-970MC in AutoCopy mode

During the boot process of the controller, the OS status LEDs indicate the following:

Step	GP			Description
1	GP3	GP2	GP1	State
	 ON	 OFF	 OFF	Reset
2	GP3	GP2	GP1	State
	 OFF	 ON	 OFF	Initialization
3	GP3	GP2	GP1	State
	 OFF	 ON	 1Hz	The AutoCopy function is executed.
4a	GP3	GP2	GP1	State
	 OFF	 ON	 4Hz	AutoCopy function is completed; no errors occurred
4b	GP3	GP2	GP1	State
	 ON	 ON	 4Hz	AutoCopy function is completed; errors occurred

Terminating AutoCopy mode

Introduction

Only a restart of the controller terminates the Autocopy mode.

Prerequisite

Processing the AutoCopy command is completed.

Terminating AutoCopy mode

To exit the AutoCopy mode, proceed as follows:

Step	Action
1	Disconnect the controller from the power supply.
2	Set the mode selector to <i>RUN</i> or <i>STOP</i> position.
3	Switch the controller on.

Result: The controller relaunches.

8 Operating system update

Introduction

Jetter AG are continuously striving to enhance the operating systems for their controllers and peripheral modules. Enhancing means adding new features, upgrading existing functions and fixing bugs.
 This chapter describes how to perform an operating system update for a system equipped with a JC-970MC.

Downloading an operating system

You can download operating systems from the Jetter AG **homepage**-
<http://www.jetter.de>. OS files are available for download in the downloads area of the respective product.

JC-9xx system - Devices

Operating systems can be updated on the following devices that are part of a system with the JC-970MC controller:

- Controller JC-970MC
- JX2 slave modules on a JX2 system bus
- Bus nodes on a JX2 system bus
- Bus nodes on a JX3 system bus
- Analog modules on a JX3 system bus
- Digital inputs and outputs on a JX3 system bus

Content

Topic	Page
Updating the operating system of the controller.....	186
Updating the operating system of a module.....	191
Updating the Windows® partition	198

8.1 Updating the operating system of the controller

Introduction

This chapter describes how to update the OS of the JC-970MC. There are several options to transfer the OS file to the controller:

- From within the programming tool JetSym
 - Via FTP connection
 - From the application program
-

Content

Topic	Page
OS update by means of JetSym	187
OS update via FTP	188
Automatic OS update from a USB flash drive.....	189
OS update from within the application program	190

OS update by means of JetSym

Introduction

The programming tool JetSym offers an easy way to transfer an OS file to a controller.

Prerequisites

- A new OS file for the JC-970MC must be available.
- A UDP/IP and a TCP/IP connection between programming tool and JC-970MC must be possible.
The number of the IP port must be set in the configuration memory as IP basic port number for JetIP communication.
- The operating system of the JC-970MC must be running.

Recommendation:

For this reason make sure that during this time the controller is not disconnected from the power supply. Make sure it remains energized.

Updating the OS

To update the OS, proceed as follows:

Step	Action
1	Select in the JetSym menu Build menu item Update OS... . Alternative: In the Advanced Configuration dialog of the Hardware Manager, click on the button Update OS . Result: The file selection dialog opens.
2	Select the new OS file here. Result: In JetSym, a confirmation dialog opens.
3	Launch the OS upload by clicking the button Yes .
4	Wait until the update process is completed.
5	To activate the transferred OS, re-boot the controller.

Updating the operating system by means of FTP

Introduction

Using an FTP client an OS file can be transferred to the JC-970MC.

Prerequisites

- A new OS file for the JC-970MC must be available.
 - An FTP connection to the controller must be possible.
 - The login parameters for a user with administrator or system rights must be at hand.
 - The operating system of the JC-970MC must be running. Therefore, make sure it remains energized.
-

Updating the OS

To update the OS, proceed as follows:

Step	Action
1	Open an FTP connection to the JC-970MC.
2	Log in with administrator or system rights
3	Navigate to the directory <i>/System/OS</i> .
4	Transfer the OS file.
5	Wait until the transfer process is completed.
6	Clear the FTP connection.
7	To activate the transferred OS, re-boot the controller.

Automatic OS update from USB flash drive

Reference:

An automatic OS update of the controller from the USB flash drive can be carried out using the AutoCopy function. For a detailed description, turn to chapter *AutoCopy* (see page 179).

Updating the OS from within the application program

Introduction

The file functions included in the STX language let you carry out a program-controlled OS update of a JC-970MC from within an OS file.

Prerequisites

- An OS file must be available in the file system of the JC-970MC.
- The operating system of the JC-970MC and the application program must be running.

Note:

Make sure it remains energized.

Updating the OS

To start an OS update out of the application program, proceed as follows:

Step	Action
1	Copy the OS file to a file of any name and of the extension *.os in the directory /System/OS.
2	To activate the updated OS, for example by writing to the system command register, re-boot the controller.

JetSym STX program

```

Var
    SourceName:      String;
    DestinationName: String;
    UpdateIt:        Bool;
End_Var;

//*****
// Name:      OSupdate
// 1. Activate 'Tracing' in JetSym
// 2. Set the name of the source file in 'SourceName'
// 3. Set the flag 'UpdateIt'
//*****

Task OSupdate Autorun
    Var
        ResCopy:    Int;
    End_Var;

    DestinationName := '/System/OS/OperatingSystem.os';
    Loop
        UpdateIt := False;
        When UpdateIt Continue;
        ResCopy := FileCopy(SourceName,
                            DestinationName);
        Trace('Result : ' + IntToStr(ResCopy) + '$n');
    End_Loop;
End_Task;

```

8.2 Updating the operating system of a module

Introduction

This chapter describes how an OS update of a module connected to the system bus of the JC-970MC is carried out. There are several options to transfer the OS file to the module:

- From within the programming tool JetSym
 - Via FTP connection
 - From a USB flash drive
 - From the application program
-

Content

Topic	Page
OS update by means of JetSym	192
OS update via FTP	193
Automatic OS update from a USB flash drive	194
OS update from within the application program	195

OS update by means of JetSym

Introduction

The programming tool JetSym offers an easy way to transfer an OS file to a module connected to the system bus of the controller.

Prerequisites

- A new OS file for the JC-970MC must be available.
- A UDP/IP and a TCP/IP connection between programming tool and IP port of the controller is possible (timeout 4,000 ms min.).
The number of the controller in the configuration memory is set as IP basic port number for JetIP communication.
- The operating system is running.
- The system bus has been put into operation by the controller without any errors.
- The boot loader or the operating system of the module is running.
- The controller must remain energized during the OS update process.

Updating the OS

To update the OS, proceed as follows:

Step	Action						
1	In JetSym, click on the menu Build and select item Update OS... , or click in the Advanced Configuration window of the Hardware Manager on OS Update . Result: The file selection dialog opens.						
2	Select the new OS file here. Result: In JetSym, a confirmation dialog opens.						
3	Confirm by clicking Yes . Result: JetSym opens an input box for entering the interface type and module number.						
4	Enter the number of the riser card (1), the number of the submodule (1 or 2) and the module number (2 ... 63). Launch the OS upload by clicking the button Update .						
5	Wait until the update process is completed.						
6	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">If ...</th> <th style="text-align: center;">... then ...</th> </tr> </thead> <tbody> <tr> <td>... you wish to update other modules, ...</td> <td>... proceed with step 1.</td> </tr> <tr> <td>... do not you wish to update other modules, ...</td> <td>... reboot the controller to launch the new operating system.</td> </tr> </tbody> </table>	If then you wish to update other modules, proceed with step 1.	... do not you wish to update other modules, reboot the controller to launch the new operating system.
If then ...						
... you wish to update other modules, proceed with step 1.						
... do not you wish to update other modules, reboot the controller to launch the new operating system.						

Updating the operating system by means of FTP

Introduction

Using an FTP client an OS file can be transferred to a module connected to the system bus of the controller.

Prerequisites

- An new OS file for the module must be available.
- An FTP connection to the controller must be possible.
- The login parameters for a user with administrator or system rights must be at hand.
- The operating system is running.
- The system bus has been put into operation by the controller without any errors.
- The boot loader or the operating system of the module is running.
- The controller must remain energized during the OS update process.

Updating the OS

To update the OS, proceed as follows:

Step	Action	
1	Establish an FTP connection to the controller	
2	Log in with administrator or system rights	
3	Navigate to the OS directory of the module Example: <i>/System/PCI-Slot1/SB-Module1/JX2-Slave02/OS</i> or <i>/System/PCI-Slot1/SB-Module2/JX3-Module05/OS</i>	
4	Transfer the OS file into this directory.	
5	Wait until the update process is completed.	
6	If then ...
	... you wish to update other modules, proceed with step 3.
	... do not you wish to update other modules, clear the FTP connection. Then reboot the controller to launch the new operating system.

Automatic OS update from USB flash drive

Reference: An automatic OS update of a JX2 or JX3 module from the USB flash drive can be carried out using the AutoCopy function. For a detailed description, turn to chapter *AutoCopy* (see page 179).

Updating the OS from within the application program

Introduction

The file functions included in the STX language allow transferring an OS file to a module on the JX2 or JX3 system bus of the controller.

Prerequisites

- The OS file for the module is available in the file system of the controller.
- The operating system of the controller and the application program are running.
- The system bus has been put into operation by the controller without any errors.
- The boot loader or the operating system of the module is running.
- The controller must remain energized during the OS update process.

Updating the OS

To update the OS of a module, proceed as follows:

Step	Action	
1	Open the OS file in read-only mode.	
2	Open a file with any name and the extension *.os in the OS directory of the module in write mode. Example: /System/PCI-Slot1/SB-Module1/JX2-Slave02/OS/system.os or /System/PCI-Slot1/SB-Module2/JX3-Module05/OS/Any.os	
3	Read the data out of the OS file.	
4	Write these data to the target file for the module.	
5	Close both files.	
6	If then ...
	... you wish to update other modules, proceed with step 1.
	... do not you wish to update other modules, reboot the controller to launch the new operating system.

Software versions

The sample program requires the software versions listed below:

- JetSym: Version 5.1.3 or higher
- Controller JC-970MC: OS version 1.07 or higher

You can also find the latest sample programs in the JetSym online help.

Sample program

```

Var
    SourceName:           String;
    DestinationName:     String;
    UpdateIt:             Bool;
End_Var;
    
```

```

//*****
// Name:      FileCopy
//! \param[in] SrcName      name of source file
//! \param[in] DstName     name of destination file
//! \return    >= 0        size of source file
//! \return    < 0        error
//! \brief    copies a file
//*****
Function FileCopy(Ref SrcName: String,
                  Ref DstName: String):Int;

    Var
        SrcFile, DstFile:    File;
        FileBuffer:         Array[1000] Of Byte;
        Result:             Int;
        ReadSize:           Int;
        WriteSize:          Int;
        FileSize:           Int;
    End_Var;

    Result := 0;
    FileSize := 0;
    // open source file for reading
    If FileOpen(SrcFile, SrcName, 'r') Then
        // open destination file for writing
        If FileOpen(DstFile, DstName, 'w') Then
            // read first block of data
            ReadSize := FileRead(SrcFile,
                                FileBuffer,
                                SizeOf(FileBuffer));
            While ReadSize <> 0 Do
                // write read data to destination file
                WriteSize := FileWrite(DstFile,
                                       FileBuffer,
                                       ReadSize);
                If WriteSize <> ReadSize Then
                    // write error
                    Result := -3;
                    Exit;
                End_If;
                Inc(FileSize, WriteSize);
                // read next block of data
                ReadSize := FileRead(SrcFile,
                                    FileBuffer,
                                    SizeOf(FileBuffer));
            End_While;
            // close both files
            FileClose(SrcFile);
            FileClose(DstFile);

```

```
        Else
            // can't open destination file
            FileClose(SrcFile);
            Result := -2;
        End_If;
    Else
        // can't open source file
        Result := -1;
    End_If;
    If Result < 0 Then
        FileCopy := Result;
    Else
        FileCopy := FileSize;
    End_If;
End_Function;

//*****
// 1. Enable Tracing in JetSym
// 2. Put source file name into 'SourceName'
// 3. Put destination file name into 'DestinationName'
// 4. Set flag 'UpdateIt'
//*****
Task OSupdate Autorun
    Var
        ResCopy:    Int;
    End_Var;

    Loop
        UpdateIt := False;
        When UpdateIt Continue;
        ResCopy := FileCopy(SourceName,
                            DestinationName);
        Trace('Result : ' + IntToStr(ResCopy) + '$n');
    End_Loop;
End_Task;
```

8.3 Updating the Windows[®] partition

Off-the-shelf Windows system	The Windows section of the JC-975MC works like a normal Windows installation.
Windows updates	You can use the standard Windows on-board tools to perform updates.
Backup/Restore	You can backup and restore the Windows system partition (C:) and data partition (D:) using Windows on-board tools.

9 Motion control

Programming

Please refer to the JetSym help for a description on functions and programming of the Motion Control.

The Motion Control is programmed in the Motion API interface in the programming language STX.

10 Quick reference - JC-970MC

Corresponding OS version

This quick reference summarizes in brief the registers and flags of the JC-970MC with OS version 1.07.4.08

Internal IP address of the controller section

IP address 192.168.2.3 lets you access the controller section from the Windows IPC.

General overview - Registers

100000 ... 100999	Electronic Data Sheet (EDS)
101000 ... 101999	Configuration
102000 ... 102999	Real-time clock
104000 ... 104999	Ethernet
108000 ... 108999	CPU
200000 ... 209999	General system registers
210000 ... 219999	Application program
230000 ... 239999	Networking via JetIP
240000 ... 249999	JetSync
250000 ... 259999	Ethernet system bus
260000 ... 269999	RemoteScan
270000 ... 279999	Modbus/TCP
290000 ... 299999	E-mail
310000 ... 319999	File system/data files
320000 ... 329999	FTP client
350000 ... 359999	User-programmable IP interface
380000 ... 389999	Error history
390000 ... 399999	I/O networking
470000 ... 470999	NetConsistency: Basic drivers
471000 ... 471999	NetConsistency: First instance
1000000 ... 1119999	Application registers (remanent; Int/Float)
20SJ00000 ... 20SJ19999	JX2 modules; JetMove 2xx JX6 submodules
50000000 ... 59999999	Motion control
1nnn020000 ...	Networking via Jetter Ethernet system bus
1nnn179999	GNN: nnn = 000 ... 199:
1nnn202000 ...	JX3 module registers
1nnn227999	
1nnn810000 ...	JX2 module registers
1nnn819999	
1nnn980000 ...	JetMove registers
1nnn980199	
1nnn990000 ...	Indirect access via local R 236xxx
1nnn999999	
1nnn990000 ...	Indirect access with variable destination window
1nnn999999	
20001 ... 36000	Virtual I/Os for RemoteScan
20SJ0xx01 ... 20SJ0xx16	JX2 modules (xx: 02 ... 32); JX3 modules via JX3-BN-CAN (xx: 02 ... 17)
1nnn01xx01 ...	JX3 modules via JX3-BN-ETH
1nnn01xx16	GNN: nnn = 000 ... 199: xx: 02 ... 17

I/Os - General overview

20001 ... 36000	Virtual I/Os for RemoteScan
20SJ0xx01 ... 20SJ0xx16	JX2 modules (xx: 02 ... 32); JX3 modules via JX3-BN-CAN (xx: 02 ... 17)
1nnn01xx01 ...	JX3 modules via JX3-BN-ETH
1nnn01xx16	GNN: nnn = 000 ... 199: xx: 02 ... 17

Electronic Data Sheet (EDS)

[Identification]	
100600	Internal version number
100601	Module ID
100602 ...	Module name (register string)
100612	
100613	PCB revision
100614	PCB options
[Production]	
100700	Internal version number
100701 ...	Serial number (register string)
100707	
100708	Day
100709	Month
100710	Year
100711	TestNum
100712	TestRev
[Features]	
JC-9xx	
100800	Internal version number
100804	Switch
100805	STX
100806	Non-volatile registers
100810	Motion Control
100812	HTTP/e-mail
100813	Modbus/TCP
100817	RTC

Configuration

From the /System/config.ini file	
101100	IP address
101101	Subnet mask
101102	Default gateway
101103	DNS server
101132	HOSTNAME suffix type
101133 ...	HOSTNAME (register string)
101151	
101164	JetIP port number
101165	Port number for STX debugger
Used by the system	
101200	ETH (X102): IP address
101201	ETH (X102): Subnet mask
101202	ETH (X102): Default gateway
101203	DNS server
101216	ETH (X102): Static route of the IP address
101217	ETH (X102): Static route of the subnet mask
101218	ETH (X102): Static route of the gateway
101232	HOSTNAME suffix type
101233 ...	HOSTNAME (register string)
101251	
101264	JetIP port number
101265	Port number for STX debugger
101299	Write trigger (0x77566152)

Real-time clock

Direct access	
102910	Milliseconds
102911	Seconds
102912	Minutes
102913	Hours
102914	Day of the week (0 = Sunday)
102915	Day
102916	Month
102917	Year
Buffer access	
102920	Milliseconds
102921	Seconds
102922	Minutes
102923	Hours
102924	Day of the week (0 = Sunday)
102925	Day
102926	Month

102927	Year
102928	Read/write trigger

Ethernet

Link status	
104002	Link status ETH1
	0 No link
	10 10 MBit/s, half-duplex
	20 10 MBit/s, full duplex
	100 100 MBit/s, half-duplex
	200 100 MBit/s, full duplex
	1000 1000 MBit/s, half-duplex
	2000 1000 MBit/s, full duplex
IP	
104531	ETH (X102): Current IP address (rw)
104532	ETH (X102): Current subnet mask (rw)
104533	ETH (X102): Current default gateway (rw)
Routing table	
104550	Status
	0 No error
	-1 Routing table is full
	-2 Entry not found
	-3 Port is not active
	-4 TCP/IP stack not initialized
104551	Command
	1 Add route
	0 Delete route
104552	Port number
	1 ETH (X102)
104553	IP address
104554	Subnet mask
104555	Gateway

CPU

108002	All LED ON/OFF (bit-coded)
	Bit 0: LED GP1 (RUN)
	Bit 1: LED GP3 (ERR)
	Bit 2: LED GP2 (D1)
108003	LED GP1 (RUN)
	0 = OFF
	1 = Flashing slowly
	2 = Flashing fast
	3 = ON
108004	LED GP3 (ERR)
	0 = OFF
	3 = ON
108005	LED GP2 (D1)
	0 = OFF
	3 = ON
108015	Mode selector
	1 = LOAD
	2 = RUN
	3 = STOP

General system registers

200000	OS version (major * 100 + minor)
200001	Application program is running (bit 0 = 1)
200008	Error register (identical with 210004)
	Bit 0: Flash disk error
	Bit 2: Error on JX2 system bus
	Bit 3: Error on Ethernet system bus
	Bit 4: Error on application register
	Bit 7: Error in expanded error register
	Bit 8: Illegal jump
	Bit 9: Illegal call
	Bit 10: Illegal index
	Bit 11: Illegal opcode
	Bit 12: Division by 0
	Bit 13: Stack overflow
	Bit 14: Stack underflow
	Bit 15: Illegal stack
	Bit 16: Error when loading the application program
	Bit 17: Memory protection violated
	Bit 24: Timeout - Cycle time
	Bit 25: Timeout - Task lock
	Bit 31: Unknown error
200009	Enhanced error register (bit-coded)
	Bit 3: Error in ModConfig.da
	Bit 10: A bus node (publish/subscribe client) has reported an error to the controller
	Bit 12: Error message by JetIPScan
	Bit 16: Error message by NetConsistency
	Bit 22: Warning: Logger has been activated
200010	Enhanced error register (bit-coded)
	Bit 1: Error in the MC object
200051	JetIPScan error number register
200061	Error number register of NetConsistency
200169	OS version (IP format)
200170	Controller type (970)
201000	Runtime register in milliseconds (rw)
201001	Runtime register in seconds (rw)
201002	Runtime register in R 201003 Units (rw)
201003	* 10 ms units for R 201002 (rw)
201004	Runtime register in milliseconds (ro)
201005	Runtime registers in microseconds (ro)
202930	Web status (bit-coded)
	Bit 0 = 1: FTP server available
	Bit 1 = 1: HTTP server available
	Bit 2 = 1: E-mail available
	Bit 3 = 1: Data file function available
	Bit 4 = 1: Modbus/TCP exists
	Bit 5 = 1: Modbus/TCP available
202936	Control register - File system
	0xc4697a4b: Formatting the flash disk

232711	Error code of last access 0 = No error 1 = Timeout 3 = Error message from the remote station 5 = Invalid network address 6 = Invalid amount of registers 7 = Invalid interface number
232717	Maximum number of retries
232718	Number of retries
Network registers	
235000 ...	IP addresses
235399 ...	
235400 ...	Port numbers
235799	
236000 ...	Indirect register numbers
236399	
	GNN: nnn = 000 ... 199:
1nnn020000 ...	JX3 module registers
1nnn179999	
1nnn202000 ...	JX2 module registers
1nnn227999	
1nnn810000 ...	JetMove registers
1nnn819999	
1nnn980000 ...	Indirect access via local register 236xxx
1nnn980199	
1nnn990000 ...	Indirect access with variable destination window
1nnn999999	

Ethernet system bus

Subscriber	
250000	Status (bit-coded) Bit 0 = 1: No CRC Bit 1 = 1: Error in connection with a subscription Bit 7 = 1: Subscriber is running
250001	Command 102: Restart 105: STOPP 110: Acknowledge error
250002	Subscription ID of the last error
250003	Number of subscriptions
250004	CRC of configuration file
250010	Selection via command
250011	Selection via ID
Subscription	
250020	Status
250021	Mode
250022	Number of elements
250023	Multicast group
250024	Hash
250025	Current sequence number
250026	Size (bytes)
250027	Timeout
250028	Number of received publications
250029	Number of timeout errors
250030	Number of sequence number errors
250100 ...	9 more subscriber register blocks
250999	
Address of the bus node (or controller) exceeding the timeout time	
254001	GNN
254002	IP address
254003	Port number
Publisher	

255000	Status (bit-coded) Bit 0 = 1: No CRC Bit 1 = 1: Error in connection with a publication Bit 7 = 1: Subscriber is running
255001	Command 102: Restart 105: STOPP 110: Acknowledge error
255002	Publication ID of the last error
255003	Number of publications
255004	CRC of configuration file
255010	Selection via command
255011	Selection via ID
Publication	
255020	Status
255021	Mode
255022	Number of elements
255023	Multicast group
255024	Hash
255025	Current sequence number
255026	Size (bytes)
255027	Cycle time
255028	Number of publications sent
255029	Number of retries
255030	Number of transmit errors
255100 ...	9 more publisher register blocks
255999	

RemoteScan

262965	Protocol type
262966	Amount of configuration blocks
262967	Status

Modbus/TCP

272702	Register offset
272704	Input offset
272705	Output offset
278000 ...	16-bit I/O registers overlaid by virtual I/Os 20001 ... 36000
278999	

E-mail

292932	IP address of SMTP server
292933	IP address of POP3 server
292934	Port number of SMTP server
292935	Port number of POP3 server
292937	Status of e-mail processing
292938	Task ID - E-mail

File system/data file function

312977	Status of file operation
312978	Task ID

FTP client

320000	Number of open connections
320001	Command
320002	Timeout
320003	Server port
320004	Selection via number
320005	Selection via handle
320006	Server socket: IP address
320007	Server socket: Port
320008	Client socket: IP address
320009	Client socket: Port
320100	Access status
320101	Task ID

User-programmable IP interface

Reading out the connection list

350000	Last result (-1 = no connection selected)
350001	1 = Client; 2 = Server
350002	1 = UDP; 2 = TCP
350003	IP address
350004	Port number
350005	Connection state
350006	Number of sent bytes
350007	Number of received bytes

Error history

380000	Status
Bit 0 = 1:	Recording
Bit 1 = 1:	Stop if buffer is full
Bit 2 = 1:	Stop on error code
Bit 3 = 1:	Non-volatile memory
380001	Command
1:	Clear error log
2:	Start error log
3:	Stop error log
4:	Stop if error buffer is full
5:	Circular buffer
6:	Stop on error code ON
7:	Stop on error code OFF
10:	Non-volatile memory
11:	Dynamic memory
380002	Buffer length
380003	Maximum buffer length
380004	Number of error entries
380005	Index to error list
380006	Error entry
380007	Error stop code
380008	Number of codes until stop

I/O networking

Status register

390000 + node	Error register
* 10	
390001 + node	Enhanced error register 1
* 10	
390002 + node	Enhanced error register 2
* 10	
390003 + node	JetSync status
* 10	
390004 + node	Subscriber status
* 10	
390005 + node	Subscription ID of the last error
* 10	

Address of a bus node (not of a controller) having reported an error

394001	GNN
394002	IP address
394003	Port number

Control register

395000 + node	Command
* 10	

NetConsistency function

Applies to JC-340, JC-350, JC-970MC, and JC-945MC only.

Basic drivers

470000 ...	Cookie
470008	
470009	Version
470010	Status
Bit 0 = 1:	Error
Bit 1 = 1:	Alarms
Bit 2 = 1:	Basic driver initialized
470011	Command
0:	There are no commands
470020	Maximum possible number of instances
470021	Number of instances ready for operation
470030	Max. number of error messages for the logger
470031	Number of error messages transmitted to the logger
470032	Max. number of warnings for the logger
470033	Number of warnings forwarded to the logger
470034	Max. possible number of error history entries
470035	Number of entries in the error history
470040	Error numbers
470041	Time of the error in ms
470042	Instance, at which the error occurred
470043	Number of error parameters
470044 ...	Error parameters 1 through 5
470048	
470049	Number of characters of the error message
470050 ...	Text of the error message
470157	
471010	Status
Bit 0 = 1:	Error
Bit 1 = 1:	Alarms
Bit 2 = 1:	An instance has been initialized
Bit 3 = 1:	Execution in process
471011	Command
0:	There are no commands

Application registers

1000000 ...	32-bit integer or floating point number (non-volatile)
1119999	

Basic register for initializing the PCIe bus

20SJ00000	Global status register
Bit 30:	Initialization completed
Bit 31:	Error when initializing
20SJ00001	Command register
1:	Initializing the bus
20SJ00002	Number of detected riser cards
20SJ00005	Bus initialization status
0:	Initialization is running
1:	Initialization OK
-1:	Error when initializing
20SJ00006	Number of JX2 modules
20SJ00007	Types of the JX6-I/O submodules
73:	JX6-SB and JX6-SB-I
5:	JX6-SV1
16:	JX6-IO16CB
20SJ00010	Timeout while waiting for resetting the command
20SJ00011	Timeout while waiting for semaphore
20SJ00012	Timeout in the interpreter for total access

Access to controller modules (JX6-SB(I))

Flag 2105 = 1	reports an error
20SJ00050	Access error - controller module

20SJ00051	Slot number - 1 Access error - controller module Axis number - 1	20SJ02085 20SJ02086 20SJ02087 20SJ02088	SysBus application regs: Register number (65-89) SysBus application regs: Object number SysBus application regs: Sub-index SysBus application regs: Length
20SJ00052	Access error - controller module Register number	20SJ02638	Special flag, overload
<hr/>			
Digital I/O module JX6-IO16CB			
20SJ00100	State of the digital inputs		Bit 0: Flag 2048 Timeout during an access to a JX2-I/O module
20SJ00101	State of digital outputs		Bit 1: Flag 2049 Timeout during an access to a JX2 slave module
20SJ00102	Error state of the digital outputs		Bit 2: Flag 2050 Timeout during register access to a JX2-I/O module
20SJ00103	Control register		
20SJ00104	Filter time of the inputs 1 through 4		
20SJ00105	Filter time of the inputs 5 through 8	20SJ02639	Special flag, overload
<hr/>			
Combi module JX6-SV1			
20SJ00100	Module ID		Bit 1: Flag 2065 Activated error signalization for output driver errors
20SJ00101	Hardware configuration		Bit 3: Fatal system bus error
20SJ00102	Analog output	20SJ02651	Special flag, overload
20SJ00103	Strobe value/encoder value received		Bit 14: Flag 2270 Timeout during an access to an inactive JX-SIO module
20SJ00104	Preset/pulse generator	20SJ02652	Special flag, overload
20SJ00105	Count value		Bit 0: Flag 2272 Access to an unknown JX-SIO register
20SJ00106	Reference/offset		Bit 1: Flag 2273 Access to a JX-SIO register that is not supported
20SJ00107	Control register		Bit 2: Flag 2274 Timeout when monitoring a JX-SIO module
20SJ00108	Status register		Bit 3: Flag 2275 JX-SIO module is not ready for operation
20SJ00110	Sampling timer		Bit 4: Flag 2276 Overflow during a read access to a 32-bit register
<hr/>			
Submodule JX6-SB(-I)			
Operating mode "Master-Slave"			
20SJ00100	Status register		Bit 5: Flag 2277 Selecting the upper 8 bits for 32-bit write access to JX-SIO-registers
20SJ00101	Command register		
20SJ00109	Firmware version number		
20SJ00201	Register index of the JX-SIO		
20SJ00202	Register date of the JX-SIO		
<hr/>			
JX2 system bus registers			
20SJ02000	Version of JX2 system bus driver (IP)		
20SJ02008	Error (bit-coded)	20SJ02760	Max. number of I/O update retries
	Bit 3: I/O or CANopen® module timeout	20SJ02761	Index of array of I/O retry counters
	Bit 4: JX2 slave module timeout	20SJ02762	Array of I/O retry counters
	Bit 9: Error of I/O module periphery	20SJ02763	Timeout for I/O update of I/O modules [ms]
	Bit 13: Error during JX2 system bus initialization	20SJ02764	Timeout for register access to I/O modules [ms]
	Bit 14: Timeout of system registers	20SJ02765	Timeout for register access to JX2 slave modules [ms]
20SJ02011	I/O module number at timeout	20SJ02995	Bootloader version of JX2 system bus interface
20SJ02012	JX2 slave module number at timeout	20SJ03xx0 ...	Registers on I/O modules
20SJ02013	Amount of connected I/O modules	20SJ03xx9	xx: I/O module number - 2 (00 ... 22)
20SJ02014	Amount of connected JX2 slave modules		
20SJ02015	Index to module array	20SJ04000	Inputs/outputs mapped to registers (see below)
20SJ02016	Module array	...	
20SJ02023	Dummy I/O module	20SJ04367	
20SJ02024	JX2 slave dummy modules	20SJ05x00	I/O registers: CANopen®/JX-SIO
20SJ02028	Monitoring interval for I/O modules [10 ms]	...	x: I/O module number - 70 (0...9)
20SJ02029	Baud rate of JX2 system bus	20SJ06x99	
20SJ02032	ON delay	20SJ07x00	Configuration registers: CANopen®/JX-SIO
20SJ02039	I/O module where a peripheral fault has occurred (bit-coded)	...	x: I/O module number - 70 (0...9)
20SJ02070	Number of CANopen® modules	20SJ07x99	
20SJ02071	Actual I/O sum of modules on the JX2 system bus	20SJxx100 ...	JX2 slave registers
20SJ02072	Version of JX2 system bus driver (IP)	20SJxx999	xx: JX2 slave number + 10
20SJ02073	Timeout for register access to CANopen® modules	<hr/>	
20SJ02074	CANopen® sync intervall [ms]	CAN-Prim registers	
20SJ02077	Enabling JX2 system bus special functions	20SJ10500	Status register
	Bit 2: CAN-Prim		Bit 1 = 1: CAN message received
	Bit 3: CAN-Prim only		Bit 2 = 0: 11-bit CAN ID
			Bit 2 = 1: 29-bit CAN ID
20SJ02080	CANopen® module index for JX2 system bus application registers	20SJ10501	Command register 7 = clear FIFO

10 Quick reference - JC-970MC

	8 = Set CAN ID to 11 bits
	9 = Set CAN ID to 29 bits
	10 = Check boxes for received messages
20SJ10503	FIFO buffer occupancy
20SJ10504	FIFO data
20SJ10506	Global receive mask
20SJ10507	Global receive ID

20SJ10530 + box * 20	Status register of the box
20SJ10531 + box * 20	Configuration register of the box
20SJ10532 + box * 20	CAN-ID
20SJ10533 + box * 20	Number of data bytes
20SJ10534 ...	Data bytes
20SJ10541 + box * 20	
20SJ10542 + box * 20	CAN-ID mask
20SJ10543 + box * 20	Command register of the box
20SJ10544 + box * 20	Received CAN-ID

Inputs/outputs

20001 ...	Virtual I/Os for RemoteScan
36000	
20SJ00101 ...	JX6-IO16CB
20SJ00108	
20SJ0xx01 ...	JX2 modules (xx: 02 ... 32);
20SJ0xx16	JX3 modules via JX3-BN-CAN (xx: 02 ... 17)
1nnn01xx01 ...	JX3 modules via JX3-BN-ETH
1nnn01xx16	GNN: nnn = 000 ... 199; xx: 02 ... 17

32 combined inputs

JX2 system bus: + 20SJ00000
Network: + 1nnn910000

4000	101..108	109..116	201..208	209..216
4001	109..116	201..208	209..216	301..308
4002	201..208	209..216	301..308	309..316
4003	209..216	301..308	309..316	401..408
4004	301..308	309..316	401..408	409..416
4005	309..316	401..408	409..416	501..508
4006	401..408	409..416	501..508	509..516
4007	409..416	501..508	509..516	601..608
4008	501..508	509..516	601..608	609..616
4009	509..516	601..608	609..616	701..708
4010	601..608	609..616	701..708	709..716
4011	609..616	701..708	709..716	801..808
4012	701..708	709..716	801..808	809..816
4013	709..716	801..808	809..816	901..908
4014	801..808	809..816	901..908	909..916
4015	809..816	901..908	909..916	1001..1008
4016	901..908	909..916	1001..1008	1009..1016
4017	909..916	1001..1008	1009..1016	1101..1108
4018	1001..1008	1009..1016	1101..1108	1109..1116
4019	1009..1016	1101..1108	1109..1116	1201..1208
4020	1101..1108	1109..1116	1201..1208	1209..1216
4021	1109..1116	1201..1208	1209..1216	1301..1308
4022	1201..1208	1209..1216	1301..1308	1309..1316
4023	1209..1216	1301..1308	1309..1316	1401..1408
4024	1301..1308	1309..1316	1401..1408	1409..1416
4025	1309..1316	1401..1408	1409..1416	1501..1508
4026	1401..1408	1409..1416	1501..1508	1509..1516
4027	1409..1416	1501..1508	1509..1516	1601..1608
4028	1501..1508	1509..1516	1601..1608	1609..1616
4029	1509..1516	1601..1608	1609..1616	1701..1708
4030	1601..1608	1609..1616	1701..1708	1709..1716
4031	1609..1616	1701..1708	1709..1716	1801..1808
4032	1701..1708	1709..1716	1801..1808	1809..1816
4033	1709..1716	1801..1808	1809..1816	1901..1908
4034	1801..1808	1809..1816	1901..1908	1909..1916

4035	1809..1816	1901..1908	1909..1916	2001..2008
4036	1901..1908	1909..1916	2001..2008	2009..2016
4037	1909..1916	2001..2008	2009..2016	2101..2108
4038	2001..2008	2009..2016	2101..2108	2109..2116
4039	2009..2016	2101..2108	2109..2116	2201..2208
4040	2101..2108	2109..2116	2201..2208	2209..2216
4041	2109..2116	2201..2208	2209..2216	2301..2308
4042	2201..2208	2209..2216	2301..2308	2309..2316
4043	2209..2216	2301..2308	2309..2316	2401..2408
4044	2301..2308	2309..2316	2401..2408	2409..2416

16 combined inputs

JX2 system bus: + 20SJ00000
Network: + 1nnn910000

4060	101..108	109..116
4061	109..116	201..208
4062	201..208	209..216
4063	209..216	301..308
4064	301..308	309..316
4065	309..316	401..408
4066	401..408	409..416
4067	409..416	501..508
4068	501..508	509..516
4069	509..516	601..608
4070	601..608	609..616
4071	609..616	701..708
4072	701..708	709..716
4073	709..716	801..808
4074	801..808	809..816
4075	809..816	901..908
4076	901..908	909..916
4077	909..916	1001..1008
4078	1001..1008	1009..1016
4079	1009..1016	1101..1108
4080	1101..1108	1109..1116
4081	1109..1116	1201..1208
4082	1201..1208	1209..1216
4083	1209..1216	1301..1308
4084	1301..1308	1309..1316
4085	1309..1316	1401..1408
4086	1401..1408	1409..1416
4087	1409..1416	1501..1508
4088	1501..1508	1509..1516
4089	1509..1516	1601..1608
4090	1601..1608	1609..1616
4091	1609..1616	1701..1708
4092	1701..1708	1709..1716
4093	1709..1716	1801..1808
4094	1801..1808	1809..1816
4095	1809..1816	1901..1908
4096	1901..1908	1909..1916
4097	1909..1916	2001..2008
4098	2001..2008	2009..2016
4099	2009..2016	2101..2108
4100	2101..2108	2109..2116
4101	2109..2116	2201..2208
4102	2201..2208	2209..2216
4103	2209..2216	2301..2308
4104	2301..2308	2309..2316
4105	2309..2316	2401..2408
4106	2401..2408	2409..2416

8 combined inputs

JX2 system bus: + 20SJ00000
Network: + 1nnn910000

4120	101..108
4121	109..116
4122	201..208
4123	209..216
4124	301..308
4125	309..316
4126	401..408
4127	409..416
4128	501..508
4129	509..516
4130	601..608
4131	609..616
4132	701..708

4133	709..716
4134	801..808
4135	809..816
4136	901..908
4137	909..916
4138	1001..1008
4139	1009..1016
4140	1101..1108
4141	1109..1116
4142	1201..1208
4143	1209..1216
4144	1301..1308
4145	1309..1316
4146	1401..1408
4147	1409..1416
4148	1501..1508
4149	1509..1516
4150	1601..1608
4151	1609..1616
4152	1701..1708
4153	1709..1716
4154	1801..1808
4155	1809..1816
4156	1901..1908
4157	1909..1916
4158	2001..2008
4159	2009..2016
4160	2101..2108
4161	2109..2116
4162	2201..2208
4163	2209..2216
4164	2301..2308
4165	2309..2316
4166	2401..2408
4167	2409..2416

32 combined outputs

JX2 system bus: + 20SJ00000
Network: + 1nnn910000

4200	101..108	109..116	201..208	209..216
4201	109..116	201..208	209..216	301..308
4202	201..208	209..216	301..308	309..316
4203	209..216	301..308	309..316	401..408
4204	301..308	309..316	401..408	409..416
4205	309..316	401..408	409..416	501..508
4206	401..408	409..416	501..508	509..516
4207	409..416	501..508	509..516	601..608
4208	501..508	509..516	601..608	609..616
4209	509..516	601..608	609..616	701..708
4210	601..608	609..616	701..708	709..716
4211	609..616	701..708	709..716	801..808
4212	701..708	709..716	801..808	809..816
4213	709..716	801..808	809..816	901..908
4214	801..808	809..816	901..908	909..916
4215	809..816	901..908	909..916	1001..1008
4216	901..908	909..916	1001..1008	1009..1016
4217	909..916	1001..1008	1009..1016	1101..1108
4218	1001..1008	1009..1016	1101..1108	1109..1116
4219	1009..1016	1101..1108	1109..1116	1201..1208
4220	1101..1108	1109..1116	1201..1208	1209..1216
4221	1109..1116	1201..1208	1209..1216	1301..1308
4222	1201..1208	1209..1216	1301..1308	1309..1316
4223	1209..1216	1301..1308	1309..1316	1401..1408
4224	1301..1308	1309..1316	1401..1408	1409..1416
4225	1309..1316	1401..1408	1409..1416	1501..1508
4226	1401..1408	1409..1416	1501..1508	1509..1516
4227	1409..1416	1501..1508	1509..1516	1601..1608
4228	1501..1508	1509..1516	1601..1608	1609..1616
4229	1509..1516	1601..1608	1609..1616	1701..1708
4230	1601..1608	1609..1616	1701..1708	1709..1716
4231	1609..1616	1701..1708	1709..1716	1801..1808
4232	1701..1708	1709..1716	1801..1808	1809..1816
4233	1709..1716	1801..1808	1809..1816	1901..1908
4234	1801..1808	1809..1816	1901..1908	1909..1916
4235	1809..1816	1901..1908	1909..1916	2001..2008
4236	1901..1908	1909..1916	2001..2008	2009..2016
4237	1909..1916	2001..2008	2009..2016	2101..2108
4238	2001..2008	2009..2016	2101..2108	2109..2116
4239	2009..2016	2101..2108	2109..2116	2201..2208

4240	2101..2108	2109..2116	2201..2208	2209..2216
4241	2109..2116	2201..2208	2209..2216	2301..2308
4242	2201..2208	2209..2216	2301..2308	2309..2316
4243	2209..2216	2301..2308	2309..2316	2401..2408
4244	2301..2308	2309..2316	2401..2408	2409..2416

16 combined outputs

JX2 system bus: + 20SJ00000
Network: + 1nnn910000

4260	101..108	109..116
4261	109..116	201..208
4262	201..208	209..216
4263	209..216	301..308
4264	301..308	309..316
4265	309..316	401..408
4266	401..408	409..416
4267	409..416	501..508
4268	501..508	509..516
4269	509..516	601..608
4270	601..608	609..616
4271	609..616	701..708
4272	701..708	709..716
4273	709..716	801..808
4274	801..808	809..816
4275	809..816	901..908
4276	901..908	909..916
4277	909..916	1001..1008
4278	1001..1008	1009..1016
4279	1009..1016	1101..1108
4280	1101..1108	1109..1116
4281	1109..1116	1201..1208
4282	1201..1208	1209..1216
4283	1209..1216	1301..1308
4284	1301..1308	1309..1316
4285	1309..1316	1401..1408
4286	1401..1408	1409..1416
4287	1409..1416	1501..1508
4288	1501..1508	1509..1516
4289	1509..1516	1601..1608
4290	1601..1608	1609..1616
4291	1609..1616	1701..1708
4292	1701..1708	1709..1716
4293	1709..1716	1801..1808
4294	1801..1808	1809..1816
4295	1809..1816	1901..1908
4296	1901..1908	1909..1916
4297	1909..1916	2001..2008
4298	2001..2008	2009..2016
4299	2009..2016	2101..2108
4300	2101..2108	2109..2116
4301	2109..2116	2201..2208
4302	2201..2208	2209..2216
4303	2209..2216	2301..2308
4304	2301..2308	2309..2316
4305	2309..2316	2401..2408
4306	2401..2408	2409..2416

8 combined outputs

JX2 system bus: + 20SJ00000
Network: + 1nnn910000

4320	101..108
4321	109..116
4322	201..208
4323	209..216
4324	301..308
4325	309..316
4326	401..408
4327	409..416
4328	501..508
4329	509..516
4330	601..608
4331	609..616
4332	701..708
4333	709..716
4334	801..808
4335	809..816
4336	901..908

4337	909..916
4338	1001..1008
4339	1009..1016
4340	1101..1108
4341	1109..1116
4342	1201..1208
4343	1209..1216
4344	1301..1308
4345	1309..1316
4346	1401..1408
4347	1409..1416
4348	1501..1508
4349	1509..1516
4350	1601..1608
4351	1609..1616
4352	1701..1708
4353	1709..1716
4354	1801..1808
4355	1809..1816
4356	1901..1908
4357	1909..1916
4358	2001..2008
4359	2009..2016
4360	2101..2108
4361	2109..2116
4362	2201..2208
4363	2209..2216
4364	2301..2308
4365	2309..2316
4366	2401..2408
4367	2409..2416

Special flags for networks

2075	Error in networking via JetIP
------	-------------------------------

Special flags - Publish/subscribe

2080	Enable for publishing an error
2081	Error collection of the subscriber

Special flags - Interface monitoring

2088	OS flag - JetIP
2089	User flag - JetIP
2098	OS flag - Debug server
2099	User flag - Debug server

32 combined flags

203100	0 ... 31
203101	32 ... 63
203102	64 ... 95
203103	96 ... 127
203104	128 ... 159
203105	160 ... 191
203106	192 ... 223
203107	224 ... 255

16 combined flags

203108	0 ... 15
203109	16 ... 31
203110	32 ... 47
203111	48 ... 63
203112	64 ... 79
203113	80 ... 95
203114	96 ... 111
203115	112 ... 127
203116	128 ... 143
203117	144 ... 159
203118	160 ... 175
203119	176 ... 191
203120	192 ... 207
203121	208 ... 223
203122	224 ... 239

203123	240 ... 255
--------	-------------

32 combined special flags

203124	2048 ... 2079
203125	2080 ... 2111
203126	2112 ... 2143
203127	2144 ... 2175
203128	2176 ... 2207
203129	2208 ... 2239
203130	2240 ... 2271
203131	2272 ... 2303

16 combined special flags

203132	2048 ... 2063
203133	2064 ... 2079
203134	2080 ... 2095
203135	2096 ... 2111
203136	2112 ... 2127
203137	2128 ... 2143
203138	2144 ... 2159
203139	2160 ... 2175
203140	2176 ... 2191
203141	2192 ... 2207
203142	2208 ... 2223
203143	2224 ... 2239
203144	2240 ... 2255
203145	2256 ... 2271
203146	2272 ... 2287
203147	2288 ... 2303

Overlaid application registers/flags

1000000	256 ... 287
1000001	288 ... 319
1000002	320 ... 351
1000003	352 ... 383
1000004	384 ... 415
1000005	416 ... 447
1000006	448 ... 479
1000007	480 ... 511
1000008	512 ... 543
1000009	544 ... 575
1000010	576 ... 607
1000011	608 ... 639
1000012	640 ... 671
1000013	672 ... 703
1000014	704 ... 735
1000015	736 ... 767
1000016	768 ... 799
1000017	800 ... 831
1000018	832 ... 863
1000019	864 ... 895
1000020	896 ... 927
1000021	928 ... 959
1000022	960 ... 991
1000023	992 ... 1023
1000024	1024 ... 1055
1000025	1056 ... 1087
1000026	1088 ... 1119
1000027	1120 ... 1151
1000028	1152 ... 1183
1000029	1184 ... 1215
1000030	1216 ... 1247
1000031	1248 ... 1279
1000032	1280 ... 1311
1000033	1312 ... 1343
1000034	1344 ... 1375
1000035	1376 ... 1407
1000036	1408 ... 1439
1000037	1440 ... 1471
1000038	1472 ... 1503
1000039	1504 ... 1535
1000040	1536 ... 1567
1000041	1568 ... 1599
1000042	1600 ... 1631

1000043	1632 ... 1663	151	Function NetCopyListSend(Handle: Int): Int;
1000044	1664 ... 1695	152	Function NetCopyListDelete(Handle: Int): Int;
1000045	1696 ... 1727		
1000046	1728 ... 1759		
1000047	1760 ... 1791		
1000048	1792 ... 1823		
1000049	1824 ... 1855		
1000050	1856 ... 1887		
1000051	1888 ... 1919		
1000052	1920 ... 1951		
1000053	1952 ... 1983		
1000054	1984 ... 2015		
1000055	2016 ... 2047		

System functions

For reasons of compatibility, the system functions are listed below. In JetSym STX, use the corresponding JetSym STX functions instead of system functions.

4	Converting BCD to HEX
5	Converting HEX to BCD
20	Square root
21	Sine
22	Cosine
23	Tangent
24	Arc sine
25	Arc cosine
26	Arc tangent
27	Exponential function
28	Natural logarithm
29	Absolute value
30	Separation of digits before and after the decimal point
50	Sorting register values
60	CRC generation for Modbus RTU
61	CRC check for Modbus RTU
65/67	Reading register block via Modbus/TCP
66/68	Writing register block via Modbus/TCP
80/85	Initializing RemoteScan
81	Starting RemoteScan
82	Stopping RemoteScan
90	Writing a data file
91	Appending a data file
92	Reading a data file
96	Deleting a data file
110	E-mail feature
150	Configuring NetCopyList
151	Deleting NetCopyList
152	Sending NetCopyList

JetSym STX functions

System func-tions	Corresponding JetSym STX function
4	Function Bcd2Hex(Bcd: Int): Int;
5	Function Hex2Bcd(Hex: Int): Int;
50	Function QSort(DataPtr: Int, ElementCnt: Int, ElementSize: Int, SortOffset: Int, SortType: STXBASETYPE, SortMode: QSORTMODE): Int;
60	Function ModbusCRCgen(FramePtr: Int, Length: int): Int;
61	Function ModbusCRCcheck(FramePtr: Int, Length: int): Int;
65/67	Function ModbusReadReg(Const Ref MbParam: MODBUS_PARAM): Int;
66/68	Function ModbusWriteReg(Const Ref MbParam: MODBUS_PARAM): Int;
80/85	Function RemoteScanConfig(Protocol: RSCAN_PROTOCOL, Elements: Int, Const Ref Configuration: RSCAN_DSCR): Int;
81	Function RemoteScanStart(Protocol: Int): Int;
82	Function RemoteScanStop(Protocol: Int): Int;
90/91	Function FileDAWrite(Const Ref FileName: String, Const Ref Mode: String, VarType: DAWRITE_TYPE, First: Int, Last: int): Int;
92	Function FileDARead(Const Ref FileName: String): Int;
110	Function EmailSend(Const Ref FileName: String): Int;
150	Function NetCopyListConfig(IPAddr: Int, IPPort: Int, Const Ref List: TNetCopyListL): Int;

Appendix

Introduction

The appendix contains electrical and mechanical data, as well as operating data.

Content

Topic	Page
Appendix A: Technical specifications	211
Appendix B: Additional information	216
Appendix C: Index.....	217

A: Technical specifications

Introduction This chapter contains information on electrical and mechanical data, as well as on operating data of the JC-970MC.

Content

Topic	Page
Technical specifications	212
Operating parameters - Environment and mechanics.....	212
CE directives, standards and certifications	215

Technical specifications

Power supply

Parameter	Description
Rated voltage	24 V DC
Permissible voltage range	-15 % ... +20 %
Input current	6 A max., typically 1.2 A (without USB)
Power consumption	144 W max.
Voltage dips	Duration of voltage dips \leq 10 ms Interval between two voltage dips \geq 1 s Severity level PS2

Memory configurations

Parameter	Description
Non-volatile memory (registers)	120,000 registers
Program/data memory	16 MB/16 MB

Optional expansions

Parameter	Description
2 pcs. PCIeexpress slots for JI-PCIE-Exx add-on cards (terminals X81, X82, X91, X92)	<p>At the moment, the following add-on cards are available:</p> <p>JI-PCIE-E01: for connecting a maximum of 31 JX2 or JX3 modules (JX3-BN-CAN is required), and a maximum of 15 JetMove-100/200 servo drives via JX2 system bus</p> <p>JI-PCIE-E02: for connecting a maximum of 62 JX2 or JX3 modules (JX3-BN-CAN is required), and a maximum of 30 JetMove-100/200 servo drives via two JX2 system busses</p> <p>JI-PCIE-E03 for connecting a maximum of 31 JX2 or JX3 modules (JX3-BN-CAN is required), and a maximum of 15 JetMove-100/200 servo drives via JX2 system bus, as well as 16 local digital I/Os for quick processing of machine signals</p> <p>JI-PCI-E04 for connecting a maximum of 31 JX2 or JX3 modules (JX3-BN-CAN is required), and a maximum of 15 JetMove-100/200 servo drives via JX2 system bus, as well as 1 incremental or SSI encoder to the interface on the card</p>

Parameter	Description
Remote modules via Ethernet System Bus (X102)	JX3-BN-ETH bus nodes for JX3-I/O modules JM-200 servo drives equipped with Ethernet interface (option -ETH or -JC-310)

Features

Parameter	Description
Real-time clock	Yes
Web server	Yes
E-mail client	Yes
Modbus TCP	Yes

Real-time clock

Parameter	Description
Power reserve	Minimum: 1 week Typically: 3 weeks
Deviation	1 minute per month max.

Operating parameters - Environment and mechanics

Environmental conditions

Parameter	Value	Standard
Operating temperature range	0 °C ... +50 °C	
Storage temperature range	-20 ... +70 °C	
Air humidity	93 % at 40 °C non-condensing	IEC 60068-2-78
Corrosion immunity/ chemical resistance	No special protection against corrosion. Ambient air must be free from higher concentrations of acids, alkaline solutions, corrosive agents, salts, metal vapors, or other corrosive or electroconductive contaminants	
Maximum operating altitude	2,000 m above sea level	DIN EN 61131-2

Mechanical parameters

Parameter	Value	Standard
Vibration resistance	5 ... 57.6 Hz, 0.075 mm amplitude 57.6 ... 150 Hz, 1 g	IEC 60068-2-6:2008-10
Shock resistance	15 g, 11 ms, half sine wave	IEC 60068-2-27:2010-2
Degree of protection	IP20	DIN EN 60529
Mounting orientation	Vertical	
Weight	4.9 kg	
Dimensions (HxWxD), mm	305 x 155 x 220.4	

CE directives, standards and certifications

CE directives

CE directive	
Electrical safety	General Product Safety Directive 2001/95/EC
Electromagnetic Compatibility (EMC)	EMC Directive 2004/108/EC
CE marking	CE Directive 93/68/EEC
RoHS II Directive	2011/65/EU

Electrical safety

Electrical safety	Harmonized Standards
Europe	Information technology equipment - Safety - Part 1: General requirements EN 60950-1:2006+A11:2009+A12:2011+A1:2010+AC:2011

EMC - Immunity to interference

EMC	Harmonized Standards
Europe	Industrial, scientific and medical equipment - Radio-frequency disturbance characteristics limits and methods of measurement EN 55011, class B (conducted emissions), EN 55022, class B EN 61000-6-4
	Information technology equipment - Immunity characteristics - Limits and methods of measurement EN 55024, EN 61000-6-2, EN 61000-4-3
	Industrial-process control systems - Part 2: Guidance for inspection and routine testing EN 61131-2

B: Additional information

Additional information

For more information, please refer to the JetSym Online Help.
Please also refer to the following application-oriented manuals:

- *File system*
 - FTP server has been implemented in JC-970MC.
 - This manual describes how to store and load application programs.
 - *System registers*
 - Realtime clock, runtime register and interface monitoring have been implemented in JC-970MC.
 - *User-programmable PRIM interfaces*
 - Contains information about the freely programmable Ethernet interface
 - *Jetter Ethernet system bus*
 - Describes the architecture of TCP/UDP-IP communication between Jetter devices.
 - *JX3 system*
 - Describes engineering and connection of the JX3-IO system to a Jetter controller.
-

C: Index

A

Additional information • 216
Automatic copying of controller data • 37, 179

C

CE directives, standards and certifications • 215
Components of the JC-970MC • 19
Control elements • 58

D

Digital inputs
 Current/voltage diagram • 23
 Insulation voltage • 24
 Transition time 0-1/1-0 • 22
 Type 3 • 22
Digital outputs
 Propagation delay • 23
Disposal of obsolete equipment • 10

E

EDS
 EDS file "eds.ini" • 93
 EDS registers • 96
E-mail • 143
E-mail feature
 Configuring • 144
 Generating • 152
 Registers • 162
 Registers - Overview • 163
 Sending e-mails • 161
 Using names for IP addresses • 81
EMC
 Instructions on EMC • 12

I

Initial commissioning • 87
Intended use • 10
Internal power supply
 Buffering • 105
IP address
 Change • 73
 Determining network information by means of
 JetIPScan • 65
 Making changes using JetIPScan • 74
 Making settings at runtime • 80
 Setting configuration values to be non-volatile • 77
 Setting the IP address automatically by means of a
 USB flash drive • 79
 Setting the IP address using config.ini • 76

J

Jacks
 DisplayPort • 38
 Ethernet 1 • 34
 Ethernet 2 • 35
 Ethernet 3 • 35
 JX6-IO16CB • 50
 JX6-SV1 • 49
 RS-232 • 39
 SDCARD • 38
 USB 1 and USB 2 • 36, 37
 X81 • 40
 X82 • 40
JX2 system bus
 Cable • 45
 Interfaces of the variant -E01 • 41
 Interfaces X91/X92 • 42
 Line lengths and baud rates • 47
 Terminal assignment • 43
JX6-I/O submodules
 Local submodules (variant -E01) • 48

L

LEDs
 Controller (GP) • 53
 Status LEDs • 57
LEDs indicating various states • 52

M

Mechanical installation
 Fastening the controller JC-970MC • 30
Memory types • 102
Modbus/TCP • 168
 Client • 175, 177
 Server • 169
Mode selector S11 • 61
Modifications • 10
Motion control • 199

N

Nameplate • 92

O

Operating parameters
 Environment and mechanics • 214
Operating system update • 185
 Controller • 186
 Modules • 191
Order reference - JC-970MC • 18

P

Personnel qualification • 10
Physical dimensions • 25
Power supply

Index

- Power consumption • 212
- Rated voltage • 212
- Voltage dips • 212
- Voltage range • 212
- Product descriptions
 - JC-970MC • 16
- Programming local JX6-I/O submodules • 124
 - Combi module JX6-SV1 • 132
 - JX6-IO16CB • 127
 - Sample program • 139
- PWR button • 59

Q

- Quick reference • 200

R

- Real-time clock • 123
- Register number
 - CANopen[®] modules on the JX2 system bus • 119
 - JX2 slave modules on the JX2 system bus • 116
 - JX2-I/O modules on the JX2 system bus • 117
 - JX3-I/O modules on the JX2 system bus • 117
 - local JX6-I/O modules • 117
- Removing
 - Removing a controller JC-970MC • 31
- Repairs • 10
- RSQ button • 60

S

- Safety instructions • 9
- Setting up a static route • 83
- Shipping • 10
- Slot numbering • 114
- Sorting data • 167

T

- Technical specifications • 212
- Terminals
 - Power supply • 33

U

- Usage other than intended • 10

V

- Version registers • 97

W

- Windows
 - Off-the-shelf Windows system • 198

Jetter AG
Graeterstrasse 2
71642 Ludwigsburg | Germany

Phone +49 7141 2550-0
Fax +49 7141 2550-425
info@jetter.de
www.jetter.de

We automate your success.