

NANO-C
Version Update
from V3.00 to V3.01



Edition 1.00

Jetter AG reserves the right to make alterations to its products in the interest of technical progress. These alterations need not be documented in every single case.

This manual and the information contained herein have been compiled with due diligence. However, Jetter AG assumes no liability for printing or other errors or damages arising from such errors.

The brand names and product names used in this document are trademarks or registered trademarks of the respective title owner.

Table of Contents

1	Introduction	4
2	Expansions	5
2.1	Display Instructions	5
2.2	Register for Milliseconds	6
2.3	System Bus	6
2.3.1	Further modules	6
2.3.2	Function and power-level terminals at the JX-SIO	10
2.3.3	Special flags for the system bus	11
2.3.4	Access to JX-SIO analog values	11
2.4	Monitoring the activities of interfaces	12
2.4.1	Register for monitoring the activities of interfaces	13
2.4.2	Special flag for monitoring the activities of interfaces	15
3	Eliminated Software Bugs	16
3.1	User Interfaces	16
3.1.1	Behaviour during start-up	16
3.1.2	JX-SIO inputs and outputs	16
3.2	Display Instructions	16
3.3	Network Operation	16
3.4	Application Program RAM-> Flash	16
3.5	System Bus	16
3.5.1	Erroneous behaviour of the analog outputs in Smart I/O modules	16

1 Introduction

Overview of Version Updates			
Version	Function	expanded	corrected
V3.01	Display Instructions	✓	✓
	Cursor Position		
	Special Registers	✓	
	Time of creating the application program		
	Timer for Milliseconds		
	System Bus	✓	✓
	Festo CPX and SMC valve terminal have been integrated		
	Function- and Power Level Terminals JX-SIO		
	LCD-, PC- and JETWay-Interface Monitoring	✓	✓
User Interfaces		✓	
No "Data Error" After Power-On			
Networking via JETWay	✓	✓	
V3.00	System bus	✓	✓
	Special registers	✓	
	Display instructions	✓	
	Special functions	✓	
	Application program management		✓
	Floating Point Registers		✓

By updating the operating version to V 3.01, the NANO-C is provided with a number of new functions.

Important!



During the operating system update, the power supply of the NANO-C must not be interrupted.

2 Expansions

2.1 Display Instructions

If display instructions are to be used in order to output texts and register values via PRIM interface or a JX2-SER1 expansion module, the cursor position must be considered. In front of each display instruction, voids, dependent on the cursor position, will be output now.

For using display instructions, the following issues must be considered:

- The text that is to be output, must always begin at cursor position 1.
 - If the value of the cursor position is greater than 1, voids will be output as ASCII code 20_{hex} up to the start of the text.
 - For diverting the display instructions onto the Prim interface, device "9" must be selected.
 - For diverting the display instructions onto the JX2-SER1 expansion module, device "11" must be selected. The module number of the expansion module will be output in register 2838.

Beispiel 1: Output on a JX2-SER1 Expansion Module

On a JX2-SER1 module, texts and register contents are output in different ways.

```

// ASCII-sequence in HEX on a JX2-SER1
DISPLAY_TEXT (11, 1, "Hello") // 48 61 6C 6C 6F
DISPLAY_TEXT (11, 3, "Hello") // 20 20 48 61 6C 6C 6F

REG_LOAD (1400, 1234) // Register for output
REG_LOAD (2810, 0) // Quantity of post-comma-places
// (default)
REG_LOAD (2812, 8) // Field width (default)
REG_LOAD (2816, 0) // Sign suppression (default)
// ASCII-sequence in HEX on a JX2-SER1
DISPLAY_REG (11, 1, 1400) // 20 20 20 20 31 32 33 34
DISPLAY_REG (11, 3, 1400) // 20 20 20 20 20 20 31 32 33 34

```

2.2 Register for Milliseconds

Register 2037: Timer for Milliseconds	
Function	Description
Read	present value of the timer for milliseconds Value after reset: 0
Write	Illegal
Value range	0 – 65535

The NANO-C will increment the millisecond timer by one every millisecond. It will start automatically after switching on the NANO-C. Stopping the timer is not possible.

2.3 System Bus

2.3.1 Further modules

Besides modules produced by Jetter AG, modules produced by other manufacturers can also be connected to the system bus of the NANO-C. In general, these modules are handled like a JX-SIO module.

The following modules are supported by a NANO-C of the software version 3.01:

Further modules at the system bus	
Manufacturer	Product Designation
Bürkert GmbH & Co. KG	Valve terminal type 8640  Bürkert_BI_100_user information
Festo AG & Co.	CPV10-GE-CO2-8 CPV14-GE-CO2-8 CPV18-GE-CO2-8 CPX-FB14  Festo_BI_100_user information
SMC Pneumatik GmbH	SI-unit EX120 - SCA1 SI-unit EX121 - SCA1 SI-unit EX122 - SCA1  SMC_BI_100_user information

The modules produced by other manufacturers are recognized and commissioned automatically. Another commissioning software will not be needed. For connecting these modules, please consider the operating instructions of the respective manufacturers. In addition, user information has been provided by Jetter AG, in which the operation of these modules being connected to the Jetter system bus is described.


2.3.1.1 Register- and IO-Numbers

The inputs and outputs of further system bus modules can be accessed with the help of the I/O instructions of the JetSym language. The registers of these modules can also be accessed with the help of these register instructions.

The individual I/Os and registers are distinguished by their numbering.

I/O- and Register Areas	
Area	Description
IN 7000 ... IN 7999	digital inputs of further modules
OUT 7000 ... OUT 7999	digital outputs of further modules
Reg 5000 ... Reg 5999	I/O register overlay of digital and analog inputs
Reg 6000 ... Reg 6999	I/O register overlay of digital and analog outputs
Reg 7000 ... Reg 7999	Registers for configuring and diagnose

Coding of I/O numbers



Coding of the registers for I/O register overlay and for analog inputs



Coding of the registers for I/O register overlay and for analog outputs



Coding of the registers for configuring and diagnose



2.3.1.2 Module Array

All further modules that have been recognized, will be stored in the module array by an unambiguous code. The module array can be accessed via registers 2015 and 2016.

Register 2015: Pointer unto Module Array	
Function	Description
Read	selected module
Write	select a certain module
Value range	0 through amount of I/O modules
Value after reset	0

Register 2016: Module Array																																																			
Function	Description																																																		
Read	<p>Module Array</p> <p>2015 = 0 -> 2016 = amount of modules</p> <p>2015 = 1 -> 2016 = Code of the first module</p> <p>2015 = 2 -> 2016 = Code of the second module</p> <p>Code:</p> <p>JX2-I/O Modules</p> <table style="width: 100%; border-collapse: collapse;"> <tr><td style="width: 5%;">0</td><td>JX2-OD8</td></tr> <tr><td>1</td><td>JX2-ID8</td></tr> <tr><td>2</td><td>JX2-IO16</td></tr> <tr><td>3</td><td>JX2-IA4</td></tr> <tr><td>4</td><td>JX2-OA4</td></tr> <tr><td>5</td><td>JX2-CNT1</td></tr> <tr><td>6</td><td>JX2-PRN1</td></tr> <tr><td>7</td><td>JX2-SER1</td></tr> </table> <p>JX-SIO and further modules</p> <table style="width: 100%; border-collapse: collapse;"> <tr><td style="width: 5%;">64</td><td>JX-SIO</td></tr> <tr><td>65</td><td>Festo CPV Direct</td></tr> <tr><td>66</td><td>Festo Terminal CPX</td></tr> <tr><td>67</td><td>Buerkert valve terminal type 8640 SMC SI-unit EX12# - SCA1</td></tr> </table> <p>JX2 slave modules</p> <table style="width: 100%; border-collapse: collapse;"> <tr><td style="width: 5%;">128</td><td>JX2-SV1</td></tr> <tr><td>129</td><td>CAN-DIMA</td></tr> <tr><td>130</td><td>JX2-SM2</td></tr> <tr><td>131</td><td>JX2-SM1D</td></tr> <tr><td>132</td><td>JX2-PID1</td></tr> <tr><td>133</td><td>JX2-PROFI1</td></tr> <tr><td>135</td><td>JetMove 200 Series</td></tr> <tr><td>136</td><td>JX2-ProfIM</td></tr> <tr><td>146</td><td>JetMove 600 series</td></tr> </table> <p>Dummy-modules</p> <table style="width: 100%; border-collapse: collapse;"> <tr><td style="width: 5%;">252</td><td>JX-SIO dummy-module</td></tr> <tr><td>253</td><td>JX2-Slave dummy-module</td></tr> <tr><td>254</td><td>JX2-I/O dummy-module</td></tr> <tr><td>255</td><td>Not identified</td></tr> </table>	0	JX2-OD8	1	JX2-ID8	2	JX2-IO16	3	JX2-IA4	4	JX2-OA4	5	JX2-CNT1	6	JX2-PRN1	7	JX2-SER1	64	JX-SIO	65	Festo CPV Direct	66	Festo Terminal CPX	67	Buerkert valve terminal type 8640 SMC SI-unit EX12# - SCA1	128	JX2-SV1	129	CAN-DIMA	130	JX2-SM2	131	JX2-SM1D	132	JX2-PID1	133	JX2-PROFI1	135	JetMove 200 Series	136	JX2-ProfIM	146	JetMove 600 series	252	JX-SIO dummy-module	253	JX2-Slave dummy-module	254	JX2-I/O dummy-module	255	Not identified
0	JX2-OD8																																																		
1	JX2-ID8																																																		
2	JX2-IO16																																																		
3	JX2-IA4																																																		
4	JX2-OA4																																																		
5	JX2-CNT1																																																		
6	JX2-PRN1																																																		
7	JX2-SER1																																																		
64	JX-SIO																																																		
65	Festo CPV Direct																																																		
66	Festo Terminal CPX																																																		
67	Buerkert valve terminal type 8640 SMC SI-unit EX12# - SCA1																																																		
128	JX2-SV1																																																		
129	CAN-DIMA																																																		
130	JX2-SM2																																																		
131	JX2-SM1D																																																		
132	JX2-PID1																																																		
133	JX2-PROFI1																																																		
135	JetMove 200 Series																																																		
136	JX2-ProfIM																																																		
146	JetMove 600 series																																																		
252	JX-SIO dummy-module																																																		
253	JX2-Slave dummy-module																																																		
254	JX2-I/O dummy-module																																																		
255	Not identified																																																		
Write	Illegal																																																		
Value range	0 - 255																																																		
Value after reset	Quantity of expansion modules																																																		

2.3.2 Function and power-level terminals at the JX-SIO

Besides digital and analog I/O terminals, function and power-level terminals can also be connected to the JX-SIO. Below, only the term "function terminal" will be used for both function and power-level terminals.

The following function terminals are supported by the JX-SIO:

- IB IL 400 MLR 1-8A
- IB IL 400 ELR 1-3A
- IB IL 400 ELR R-3A
- INLINE CAM by Deutschmann Automation GmbH

JX-SIO Function Terminals: Register Survey	
Register Number	Description
7x04	Index of function terminals
7x05	Status of function terminals
7x06	Input data of function terminals
7x07	Output data of function terminals

The communication between CPU and function terminals has been described in detail in the user information on Smart I/O modules.




Fig. 1 Smart I/O module with function terminal INLINE CAM and power-level terminal IB IL 400 MLR 1-8A

2.3.3 Special flags for the system bus

With the help of a special flag, the NANO-C indicates certain errors. This makes a detailed error analysis possible. After start-up, the NANO-C will clear all special flags.

Survey of the special flags for the system bus	
Special Flag	Description
2048	Timeout at access to a JX2-I/O module
2049	Timeout at access to a JX2 slave-module
2050	Timeout at access to a JX2-I/O module
2065	Error signalling at output driver errors has been activated.
2067	Fatal system bus error
2068	Errors have accumulated at the system bus interface
2270	Timeout at access to a JX-SIO which is not active
2272	Access to an unknown JX-SIO-register
2273	Access to a register which is not supported by this JX-SIO, e.g. configuration of an analog input, although there is no analog input terminal
2274	Timeout at JX-SIO monitoring
2275	JX-SIO has carried out an internal reset, which means it is not ready for operation
2276	Overflow at a read access to a 32-bit register

2.3.4 Access to JX-SIO analog values

Up to now, registers 5x60 through 5x71, as well as registers 6x60 through 6x71 have been written, respectively read, while a REGISTER instruction was being processed.

In order to achieve an increase in performance, the NANO-C reads all analog inputs in the background, when all tasks have been processed. If special flag 2059 has been set, the analog inputs are even read after each task switch.

All changed analog outputs are written to the JX-SIO at the end of a task.

2.4 Monitoring the activities of interfaces

With the help of two special flags per interface, the activities of any connected communication partner that is communicating with the NANO-C via LCD, PC or JETWay interface, can be monitored through the application program. This way it can be checked, whether, for example, there is still a connection to an operating and display module.

Note

Monitoring the interface activity by PRIM via special flag is not possible for user-programmable interfaces.

The first special flag will be set by the operating system, when a valid telegram has been received. A monitoring time can be set in a register; it will be started simultaneously with receiving the telegram. Any further telegram will re-start the monitoring time.

Another special flag can be set by the user. If no valid telegrams are received any more, both special flags will be reset when the monitoring time has elapsed. As the second special flag has not been set by the operating system, the user can check whether the connection had been interrupted for a short time. In this case, the NANO-C would, after an interruption, reset the first special flag only for a short instance and after this set it again immediately.

The monitoring time can be defined via register by the user for each interface individually. By setting the monitoring time to zero, activity monitoring will be switched off.

For activity monitoring, cyclic data exchange on the interface must be active.

If operator panels, such as LCD9, LCD 34, LCD 19, ... are used, the monitoring time should not be set to less than 200 ms. If values smaller than 200 ms are set, errors might be reported in multi-display mode or in big-sized user interfaces in spite of active communication.

In process monitoring systems – such as VIADUKT or JETLink, as well as in JetSym – the interrogation time can either be set or else communication can be stopped altogether. This must be considered for activity monitoring.




Fig. 2 Monitoring of the LCD interface

2.4.1 Register for monitoring the activities of interfaces

Register 2956: Monitoring time of the PC interface	
Function	Description
Read	present monitoring time in milliseconds
Write	new monitoring time in milliseconds Note Monitoring the interface activity is always deactivated for user-programmable (PRIM) interfaces.
Value range	0 .. 65535
Value after reset	0 (no monitoring)

Register 2957: Monitoring time of the LCD interface	
Function	Description
Read	present monitoring time in milliseconds
Write	new monitoring time in milliseconds Note Monitoring the interface activity is always deactivated for user-programmable (PRIM) interfaces.
Value range	0 .. 65535
Value after reset	0 (no monitoring)

Register 2958: Monitoring time of the JETWay interface	
Function	Description
Read	present monitoring time in milliseconds
Write	new monitoring time in milliseconds Note Monitoring the interface activity is always deactivated for user-programmable (PRIM) interfaces.
Value range	0 .. 65535
Value after reset	0 (no monitoring)

Register 10019: Amount of errors on the PC interface	
Function	Description
Read	present amount of errors on the PC interface Note The error-count is not supported, if PRIM interfaces are used.
Write	reset the error counter
Value range	0 – 65535
Value after reset	0

Register 10039: Amount of errors on the LCD interface	
Function	Description
Read	present amount of errors on the LCD interface Note The error-count is not supported, if PRIM interfaces are used.
Write	reset the error counter
Value range	0 – 65535
Value after reset	0

Each time a character has been received on the PC and the LCD interface, the NANO-C checks, whether an error has occurred during transmission. The error counts will be incremented by one, if the following errors have occurred:

- Overrun Error** The UART of the interface received characters, although the receiving buffer had already been full.
- Parity Error** The parity of the received character was not correct.
- Framing Error** The received character had no valid stop bit.

2.4.2 Special flag for monitoring the activities of interfaces

Special flag 2090 through 2095: Monitoring the activities of interfaces		
Special Flag	Interface	Description
2090	PC interface	operating system flag 0 = no valid telegrams 1 = the interface is active
2091		user flag 0 = no valid telegrams to be set by the user
2092	LCD interface	operating system flag 0 = no valid telegrams 1 = the interface is active
2093		user flag 0 = no valid telegrams to be set by the user
2094	JETWay interface	operating system flag 0 = no valid telegrams 1 = the interface is active
2095		user flag 0 = no valid telegrams to be set by the user

3 Eliminated Software Bugs

3.1 User Interfaces

3.1.1 Behaviour during start-up

Starting from operating system version 3.00 of the NANO-C, the text "data error" would appear on a connected user interface at power-up. This was mainly dependent on the duration of the power-on delay and did not influence the functioning of the user interface. Starting from operating system version 3.01, the text "P-SPS timeout" will be shown on the user interface, until the initialising phase of the NANO-C has been completed.

3.1.2 JX-SIO inputs and outputs

The digital inputs and outputs of the JX-SIO expansion modules with the I/O numbers 7001 through 7964 can now be read and written via user interface.

3.2 Display Instructions

When registers are mapped onto a JX2-SER1 or a JX"-PRN1 module with the help of `DISPLAY_REG`, the amount of characters to be edited will be limited to the field width set in register 2812 "Field width for the display of interregisters". Up to version 3.00, 10 characters would always be edited.

3.3 Network Operation

The NANO-C will only accept a token in a JETWay network, if it has been configured as a master. The token will be passed on among the individual masters belonging to a JETWay network.

3.4 Application Program RAM-> Flash

Now, the copying process of the application program from RAM into flash is interrupted by the NANO-C; this way, further data can be exchanged via serial interfaces due to the interruption.

Especially in the programming system JetSym, setting a long timeout time for the interface will not be necessary.

3.5 System Bus

3.5.1 Erroneous behaviour of the analog outputs in Smart I/O modules

For Smart I/O modules, erroneous behaviour of the analog outputs can be configured. The Smart I/O modules will recognize an interruption of the system bus connection to the NANO-C and will then output the configured values at the analog outputs.

Up to version 3.00, the configuring data would not be transmitted correctly; at the analog outputs value 0000_{hex} would always be output.